

USER MANUAL

ProDAQ LXI Instruments

ProDAQ 6100

LXI Function Card Carrier



PUBLICATION NUMBER: 6100-XX-UM-1030



Copyright, © 2020, Bustec Production, Ltd.

Bustec Production, Ltd.
Bustec House, Shannon Business Park, Shannon, Co. Clare, Ireland
Tel: +353 (0) 61 707100, FAX: +353 (0) 61 707106

PROPRIETARY NOTICE

This document and the technical data herein disclosed, are proprietary to Bustec Production Ltd., and shall not, without express written permission of Bustec Production Ltd, be used, in whole or in part to solicit quotations from a competitive source or used for manufacture by anyone other than Bustec Production Ltd. The information herein has been developed at private expense, and may only be used for operation and maintenance reference purposes or for purposes of engineering evaluation and incorporation into technical specifications and other documents, which specify procurement of products from Bustec Production Ltd.. This document is subject to change without further notification. Bustec Production Ltd. Reserve the right to change both the hardware and software described herein.

Table of Contents

1. Introduction	7
1.1. Overview	7
1.2. Features	8
1.2.1. IEEE 1588 Enabled System-on-a-chip CPU	8
1.2.2. Function Card Interface	8
1.2.3. IEEE1588 Precision Time Protocol	9
1.2.4. Voltage Reference Plug-in	9
1.2.5. LXI Trigger Bus	9
1.2.6. High-voltage Option	9
2. Specifications	11
2.1. Available Versions	11
2.2. Function Card Interface	11
2.3. Network Interface	11
2.4. LXI Device Capabilities	11
2.5. IEEE 1588	12
2.6. LXI Trigger Interface (Optional)	12
2.7. Environmental Specifications	12
2.8. Power Supply	12
3. Getting Started	13
3.1. Unpacking and Inspection	13
3.2. Front Panel Switches and Indicators	13
3.3. Rear Panel Switches and Connectors	14
3.3.1. ProDAQ 6100 V1	14
3.3.2. ProDAQ 6100 V2	14
3.4. Installing ProDAQ Function Cards	15
3.4.1. Opening the ProDAQ 6100 Enclosure	15
3.4.2. Removing a ProDAQ Function Card	17
3.4.3. Installing a ProDAQ Function Card	18
3.4.4. Closing the ProDAQ 6100 Enclosure	20
3.5. Preparing the ProDAQ 6100 for first use	23
3.5.1. Network Considerations	23
3.5.2. Required Software	24
3.5.3. Network Discovery	24
3.5.4. Accessing the Instrument	27
4. WEB Page Operation	28
4.1. Instrument Home Page	28
4.2. IP Configuration	29
4.3. Synchronization Configuration	31
4.4. Function Cards & Options	34
4.4.1. Function Cards	34
4.4.2. Options	36

4.5. Device Status	39
4.5.1. Advanced Status	40
4.6. System Log	41
4.7. Device Configuration	42
4.7.1. General Settings	42
4.7.2. LXI Trigger Settings	43
4.7.3. Security Settings	44
4.8. Datasheet	44
4.9. Manual	45
5. IVI Instrument Driver	46
5.1. Assumptions	46
5.2. Error and Status Information	46
5.3. How to use this manual	46
5.4. IVI-C Driver Functions	46
5.5. IVI-C Driver Function Details	49
5.5.1. bu6100_allocDram	49
5.5.2. bu6100_assert1588trig	51
5.5.3. bu6100_CheckAttributeViBoolean	53
5.5.4. bu6100_CheckAttributeViInt32	55
5.5.5. bu6100_CheckAttributeViReal64	57
5.5.6. bu6100_CheckAttributeViSession	59
5.5.7. bu6100_CheckAttributeViString	61
5.5.8. bu6100_ClearError	63
5.5.9. bu6100_ClearInterchangeWarnings	65
5.5.10. bu6100_close	66
5.5.11. bu6100_config1588ppp	67
5.5.12. bu6100_configTrig	69
5.5.13. bu6100_Disable	71
5.5.14. bu6100_error_message	72
5.5.15. bu6100_error_query	73
5.5.16. bu6100_fcRead	75
5.5.17. bu6100_fcRead32	77
5.5.18. bu6100_fcReadBlock	80
5.5.19. bu6100_fcReadBlock32	83
5.5.20. bu6100_fcReadBlock64	86
5.5.21. bu6100_fcReset	89
5.5.22. bu6100_fcWrite	91
5.5.23. bu6100_fcWrite32	93
5.5.24. bu6100_fcWriteBcast	96
5.5.25. bu6100_fcWriteBlock	98
5.5.26. bu6100_fcWriteBlock32	100
5.5.27. bu6100_fcWriteBlock64	102
5.5.28. bu6100_freeDram	105
5.5.29. bu6100_get1588config	106
5.5.30. bu6100_get1588status	109
5.5.31. bu6100_get1588timing	111
5.5.32. bu6100_GetAttributeViBoolean	114
5.5.33. bu6100_GetAttributeViInt32	116
5.5.34. bu6100_GetAttributeViReal64	118
5.5.35. bu6100_GetAttributeViSession	120

5.5.36.	bu6100_GetAttributeViString _____	122
5.5.37.	bu6100_getCBstatus _____	125
5.5.38.	bu6100_getConfigCB _____	128
5.5.39.	bu6100_GetError _____	131
5.5.40.	bu6100_getFcCclk _____	134
5.5.41.	bu6100_GetNextCoercionRecord _____	136
5.5.42.	bu6100_GetNextInterchangeWarning _____	138
5.5.43.	bu6100_getTrigStatus _____	141
5.5.44.	bu6100_getVoltRefInfo _____	143
5.5.45.	bu6100_getVoltRefOutput _____	145
5.5.46.	bu6100_identify _____	146
5.5.47.	bu6100_init _____	147
5.5.48.	bu6100_InitWithOptions _____	151
5.5.49.	bu6100_installIrqHandler _____	156
5.5.50.	bu6100_installIrqWatcher _____	159
5.5.51.	bu6100_InvalidAllAttributes _____	162
5.5.52.	bu6100_IviLxiSync_AddArmAlarm _____	163
5.5.53.	bu6100_IviLxiSync_AddArmSource _____	164
5.5.54.	bu6100_IviLxiSync_AddEvent _____	165
5.5.55.	bu6100_IviLxiSync_AddTriggerAlarm _____	166
5.5.56.	bu6100_IviLxiSync_AddTriggerSource _____	167
5.5.57.	bu6100_IviLxiSync_ArmTrigger _____	168
5.5.58.	bu6100_IviLxiSync_ClearEventLog _____	169
5.5.59.	bu6100_IviLxiSync_ClearTriggerLog _____	170
5.5.60.	bu6100_IviLxiSync_ConfigureArmAlarm _____	171
5.5.61.	bu6100_IviLxiSync_ConfigureArmSource _____	174
5.5.62.	bu6100_IviLxiSync_ConfigureEvent _____	177
5.5.63.	bu6100_IviLxiSync_ConfigureTriggerAlarm _____	180
5.5.64.	bu6100_IviLxiSync_ConfigureTriggerLog _____	183
5.5.65.	bu6100_IviLxiSync_ConfigureTriggerSource _____	184
5.5.66.	bu6100_IviLxiSync_DisableAllArmAlarms _____	186
5.5.67.	bu6100_IviLxiSync_DisableAllArmSources _____	187
5.5.68.	bu6100_IviLxiSync_DisableAllEvents _____	188
5.5.69.	bu6100_IviLxiSync_DisableAllTriggerAlarms _____	189
5.5.70.	bu6100_IviLxiSync_GetArmAlarmName _____	190
5.5.71.	bu6100_IviLxiSync_GetArmSourceName _____	192
5.5.72.	bu6100_IviLxiSync_GetEventName _____	195
5.5.73.	bu6100_IviLxiSync_GetNextEventLogEntry _____	196
5.5.74.	bu6100_IviLxiSync_GetNextTriggerLogEntry _____	197
5.5.75.	bu6100_IviLxiSync_GetNumberOfTriggerLogEntries _____	199
5.5.76.	bu6100_IviLxiSync_GetSystemTime _____	200
5.5.77.	bu6100_IviLxiSync_GetTriggerAlarmName _____	201
5.5.78.	bu6100_IviLxiSync_GetTriggerSourceName _____	203
5.5.79.	bu6100_IviLxiSync_RemoveAllCustomArmAlarms _____	205
5.5.80.	bu6100_IviLxiSync_RemoveAllCustomArmSources _____	206
5.5.81.	bu6100_IviLxiSync_RemoveAllCustomEvents _____	207
5.5.82.	bu6100_IviLxiSync_RemoveAllCustomTriggerSources _____	208
5.5.83.	bu6100_IviLxiSync_RemoveAllTriggerAlarms _____	209
5.5.84.	bu6100_IviLxiSync_RemoveArmAlarm _____	210
5.5.85.	bu6100_IviLxiSync_RemoveArmSource _____	211
5.5.86.	bu6100_IviLxiSync_RemoveEvent _____	212
5.5.87.	bu6100_IviLxiSync_RemoveTriggerAlarm _____	213
5.5.88.	bu6100_IviLxiSync_RemoveTriggerSource _____	214
5.5.89.	bu6100_IviLxiSync_SetSystemTime _____	215

5.5.90.	bu6100_killList	216
5.5.91.	bu6100_loadList	217
5.5.92.	bu6100_LockSession	220
5.5.93.	bu6100_pulseTrig	223
5.5.94.	bu6100_pulseTrigSynch	226
5.5.95.	bu6100_readBoardTemp	229
5.5.96.	bu6100_readCB	230
5.5.97.	bu6100_readDram	233
5.5.98.	bu6100_ReadInstrData	236
5.5.99.	bu6100_readSigLinesStat	237
5.5.100.	bu6100_readVRTemp	239
5.5.101.	bu6100_removeIrqService	240
5.5.102.	bu6100_reset	242
5.5.103.	bu6100_ResetInterchangeCheck	243
5.5.104.	bu6100_ResetWithDefaults	246
5.5.105.	bu6100_revision_query	247
5.5.106.	bu6100_self_test	249
5.5.107.	bu6100_set1588config	252
5.5.108.	bu6100_SetAttributeViBoolean	254
5.5.109.	bu6100_SetAttributeViInt32	257
5.5.110.	bu6100_SetAttributeViReal64	260
5.5.111.	bu6100_SetAttributeViSession	263
5.5.112.	bu6100_SetAttributeViString	266
5.5.113.	bu6100_setConfigCB	269
5.5.114.	bu6100_setFcCclk	271
5.5.115.	bu6100_setVoltRefOutput	273
5.5.116.	bu6100_startList	274
5.5.117.	bu6100_synchronizeListVars	277
5.5.118.	bu6100_UnlockSession	279
5.5.119.	bu6100_waitIrqWatcher	281
5.5.120.	bu6100_waitList	283
5.5.121.	bu6100_writeCB	285
5.5.122.	bu6100_writeDram	288
5.5.123.	bu6100_WriteInstrData	290
5.6.	IVI-C Driver Attributes	291

Table of Figures

<i>Figure 1 - ProDAQ 6100 LXI Function Card Carrier</i>	7
<i>Figure 2 - ProDAQ 6100 Block Diagram</i>	8
<i>Figure 3 - ProDAQ 6210 Rack-mount Tray</i>	23
<i>Figure 4 - LXI Discovery Tool</i>	25
<i>Figure 5 - Configuring Network Instruments</i>	25
<i>Figure 6 - Searching for Network Instruments</i>	26
<i>Figure 7 - Bustec Agent Network Device Discovery</i>	27
<i>Figure 8 - Access the instrument home page</i>	27
<i>Figure 9 - Instrument Home Page</i>	28
<i>Figure 10 - IP Configuration Page</i>	29
<i>Figure 11 - Synchronization Configuration Page (Slave Mode)</i>	31
<i>Figure 12 - Synchronization Configuration Page (Master Mode)</i>	32
<i>Figure 13 - Function Card Page</i>	34
<i>Figure 14 - Function Card Access Page</i>	35
<i>Figure 15 - Options Page</i>	36
<i>Figure 16 - Voltage Reference Calibration Data</i>	37
<i>Figure 17 - Device Status Page</i>	39
<i>Figure 18 - Advanced Status Page</i>	40
<i>Figure 19 - System Log Page</i>	41
<i>Figure 20 - Device Configuration Page</i>	42
<i>Figure 21 - General Settings Page</i>	42
<i>Figure 22 - LXI trigger Settings Page</i>	43
<i>Figure 23 - Security Settings Page</i>	44
<i>Figure 24 - Datasheet Page</i>	44
<i>Figure 25 - Manual Page</i>	45

Reference Documents

Title	Number
Bustec VISA User Manual	8200-XX-UM
ProDAQ Function Card User Manuals	
ProDAQ 6210 Rack-mount Tray Assembly Instructions	6210-XX-AI

Glossary

- DAC** - Digital-to-Analog Converter
- FIFO** - First-in First-out Memory
- Sample** - 16-bit number representing an analog value
- Motherboard** - ProDAQ Motherboard or Carrier featuring function card slots to install ProDAQ function cards in

Safety



This equipment contains voltage hazardous to human life and safety and is able to inflict personal injury. Disconnect the device from the AC line (mains) before opening the covers as described in chapter 3.4.



To operate this device, use a three-conductor power cord and an power outlet providing protective earth. Do not use a two-conductor extension cord or a three-prong/two-prong adapter.



If you replace the power cord provided, make sure that the replacement is rated for the power consumption stated in the specifications.

Do not position the device so that it is difficult to operate the disconnecting device.

If the equipment is used in a manner not specified by the manufacturer, its safety may be impaired.

Waste Electrical and Electronic Equipment (WEEE)



This product complies with the WEEE Directive 2002/96/EC marking requirement. The affixed product label indicates that you must not discard this electrical product in domestic household waste.

Product Category: Monitoring and Control Instrumentation

To return unwanted products, contact Bustec Ltd.

1. Introduction

1.1. Overview

The ProDAQ 6100 LXI Function Card Carrier provides access to up to four ProDAQ Function Cards through a standard Gigabit LAN interface. Its small form factor and connectivity combined with the flexibility of the ProDAQ function cards lets you create multifunction instruments where your application needs them. Simply connect the ProDAQ 6100 to your network and use the standard software drivers or the embedded Web server to integrate it into your application.

The ProDAQ 6100 is a fully compliant LXI Class B device (Class A with the optional LXI Trigger Interface), providing a standardized Gigabit LAN interface, a synchronization API and support for the IEEE 1588 protocol. The IEEE 1588 interface allows devices to execute triggered functions equivalent to those available over GPIB and with similar or better timing accuracy.

The optional trigger interface allows connecting LXI devices by a physical daisy chain or star configuration. It is based on an 8-channel multipoint LVDS signaling system that allows devices to be sources and/or receivers of trigger and clock signals. Using a Wired-OR configuration allows multiple devices to respond to a trigger signal or share a common clock.



Figure 1 - ProDAQ 6100 LXI Function Card Carrier

1.2. Features

1.2.1. IEEE 1588 Enabled System-on-a-chip CPU

The ProDAQ 6100 utilizes the Freescale QUICC Engine™ technology and Enhanced Triple Speed Ethernet Controller (eTSEC), which are the first Freescale communications interfaces to optimize IEEE 1588 PTP in hardware. These new interfaces time-stamp Ethernet packets at the physical/datalink layer the instant they enter or leave the device. This results in the highest possible timing accuracy for PowerQUICC® devices that implement the increasingly popular IEEE 1588 protocol.




Figure 2 - ProDAQ 6100 Block Diagram

The Freescale MPC8313 PowerQUICC II Pro Communications Processor combines a powerful e300 PowerPC core with a complete set of peripherals and interfaces, such as a DDR2 memory interface, a PCI local bus, a high-speed USB interface and a 10/100/1000 Ethernet controller.

1.2.2. Function Card Interface

The ProDAQ 6100 can host up to four of the standard ProDAQ function cards. Each function card is connected to the carrier board via the function card interface, which provides a separate interface to each function card consisting of

- A 16-bit multiplexed address/data bus
- Up to two trigger in lines
- Up to two trigger out lines
- A voltage reference bus
- Supply voltages

The address/data bus allows the ProDAQ 6100 access to the internal registers and memory areas of the function card. Each function card occupies an address space of 64 kWords. Due to the separate interfaces, the ProDAQ 6100 can access simultaneously several function cards (Word, Double-word or Quad-word access).

The trigger in/out lines can be routed either to other function cards, the optional LXI trigger bus or the CPU for processing. The trigger routing facility in the function card interface utilizes a separate trigger node per trigger sink, where each node can be enabled to receive triggers from each trigger source available in the system. In this way one-to-one, n-to-one, one-to-n as well as n-to-n connections are possible. Additional nodes allow to route triggers to the processor for interrupt generation or the internal distribution of clock signals.

1.2.3. IEEE1588 Precision Time Protocol

The ProDAQ 6100 implements the precision time protocol according to IEEE 1588-2008 (version 2) for clock synchronization. It can operate as both master and slave and allows the internally generated clock of 100 MHz to be conditioned down to an accuracy of 30 ns. The synchronized clock can be routed to the function cards to be used as clock for the data acquisition and generation.

1.2.4. Voltage Reference Plug-in

The ProDAQ 6100 allows installing a ProDAQ 3202 High-precision Voltage Reference Plug-in module. The reference voltage generated by the plug-in module is distributed internally via the voltage reference bus to each function card. ProDAQ function cards utilize this reference voltage in their input stages to allow an end-to-end calibration without disconnection from the device under test. The voltage reference bus is accessible as well via a dual 2mm test jack connector on the rear. This allows recalibrating the ProDAQ 3202 Voltage Reference Plug-in without removing it from the ProDAQ 6100, or, if no plug-in is installed, to feed an external reference voltage into the system.

1.2.5. LXI Trigger Bus

The ProDAQ 6100 features an optional LXI (LAN eXtensions for Instrumentation) trigger bus on the rear panel of the instrument. The LXI Trigger Bus consists of eight shielded twisted-pair wires that can be used to distribute M-LVDS signals between groups of devices connected in either a daisy-chain, star, or hybrid-star configuration. The bus consists of two identical ports connected in parallel. The bus can be used to distribute high-speed event signals, clocks or similar between devices.

1.2.6. High-voltage Option

The ProDAQ 6100 can be equipped with two different power supply options. The standard version supplies function card with digital and analog supply voltages of -2V, -5.2V, +5V, $\pm 12V$ and $\pm 15V$. The optional high-voltage version adds another supply voltage of $\pm 24V$, which is necessary for some function cards to allow generating wide-range output signals or driving ICP sensors.

2. Specifications

2.1. Available Versions

Versions	6100-AA LXI Carrier 6100-AB LXI Carrier with HV Power Supply Option 6100-BA LXI Carrier with LXI Trigger Interface 6100-BB LXI Carrier with LXI Trigger Interface and HV Power Supply Option
----------	---

2.2. Function Card Interface

Number of Slots	4
Supported card configurations	<ul style="list-style-type: none"> • four single-wide function cards or • two double-wide function cards or • one double-wide and two single-wide function cards
Interface Width	16/32 bit
Interface Speed	Up to 120 MB/s

2.3. Network Interface

Type	10/100/1000 Base-T (IEEE 802.3 compliant)
Auto-MDIX	yes
Connector Type	RJ45
Protocols	TCP/IP, HTTP, VXI-11, IEEE1588, mDNS

2.4. LXI Device Capabilities

LXI Class Compliance	6100-AA: LXI Class B 6100-AB: LXI Class B 6100-BA: LXI Class A 6100-BB: LXI Class A
LXI Version	1.3
Programmatic Interface	Embedded Web Interface VXI-11 Device, Instrument Discovery IVI/VXIplug&play compatible driver

2.5. IEEE 1588

Version	IEEE 1588-2008
Profile	Compatible with LXI IEEE 1588 Profile 1.0
Clock Class	Ordinary clock
Time Source	Internal oscillator
Timestamp Accuracy	10 ns

2.6. LXI Trigger Interface (Optional)

No. Trigger Line	8
Type	M-LVDS, LXI Class A Trigger Bus compatible
Input Trigger Pulse Width	20 ns minimum
Connector	25-pin Molex Micro-D

2.7. Environmental Specifications

Temperature	0 °C to +50 °C (operational) -40 °C to +70 °C (storage only)
Humidity	5% - 95% (non-condensing)

2.8. Power Supply

Input Voltage	85-265 VAC, 47-63 Hz
Current Consumption	1.6 A max.
Fuses	2A Slow-Blow

3. Getting Started

3.1. Unpacking and Inspection


The ProDAQ 6100 is shipped in an antistatic package to prevent any damage from electrostatic discharge (ESD). Proper ESD handling procedures must always be used when packing, unpacking or installing any ProDAQ device or ProDAQ function card:

- Ground yourself via a grounding strap or similar, e.g. by holding to a grounded object.
- Discharge the package by touching it to a grounded object, before removing the module from the package.
- Remove the ProDAQ module from its carton, preserving the factory packaging as much as possible.
- Inspect the ProDAQ module for any defect or damage. Immediately notify the carrier if any damage is apparent.

3.2. Front Panel Switches and Indicators

The ProDAQ 6100 features the following switches and indicators on its front panel:

The "Power"- switch can be used to toggle the ProDAQ 6100 between standby and operation



mode. The "PWR" indicator shows the mode by toggling between orange (standby) and green (operation). To switch off the ProDAQ 6100 completely, use the power switch integrated into the IEC inlet on the rear panel.

The "LAN" indicator is a bi-color LED. It is used to identify the ProDAQ 6100 via its WEB interface or its Soft Front Panel and to indicate a LAN failure. When used for LAN identification, it flashes green, while a LAN failure is indicated by a constant red light. During normal operation, it shows a constant green light.


The "1588" indicator shows the status of the clock used for the Precision Time Protocol. If it is off, the ProDAQ 6100 is neither master nor slave and uses the internal clock. If it shows a constant green light, the ProDAQ 6100 is in slave mode and its clock is synchronized with a master clock it is connected to. If it is flashing green once every second, it is master to other devices, but not the grandmaster and when it is flashing once every two seconds, it is master and also grandmaster. A failure is indicated by a constant red light.

The ProDAQ 6100 can host up to four singlewide or two doublewide ProDAQ function cards. Single wide function cards can be installed in either of the four function card positions, while double wide function cards need to be installed either in function card position one and three or two and four.

3.3. Rear Panel Switches and Connectors

3.3.1. ProDAQ 6100 V1

The rear panel of the ProDAQ 6100 V1 features the following switches and connectors:



LAN RJ45 10/100/1000 BASE-TX port with Auto-MDIX

USB USB 2.0 OTG port


VREF Dual 2mm test socket. When a ProDAQ 3202 Voltage Reference Plug-in module is installed in the ProDAQ 6100, it can be used to monitor the voltage reference output. If no plug-in is installed, it can be used to feed in a calibration voltage to be used on the ProDAQ function cards installed in the ProDAQ 6100.

TRIGGER Dual LXI LVDS trigger port (optional)

The IEC Inlet can be used to connect the ProDAQ 6100 to the mains. It also features the master on/off switch and the main fuses.

3.3.2. ProDAQ 6100 V2

The rear panel of the ProDAQ 6100 V1 features the following switches and connectors:



LAN RJ45 10/100/1000 BASE-TX port with Auto-MDIX

USB USB 2.0 host port

VREF Dual 2mm test socket. When a ProDAQ 3202 Voltage Reference Plug-in module is installed in the ProDAQ 6100, it can be used to monitor the voltage reference output. If no plug-in is installed, it can be used to feed in a calibration voltage to be used on the ProDAQ function cards installed in the ProDAQ 6100.

TRIGGER Dual LXI LVDS trigger port (optional)

The IEC Inlet can be used to connect the ProDAQ 6100 to the mains. It also features the main fuses.

3.4. Installing ProDAQ Function Cards

If the ProDAQ 6100 is bought together with the ProDAQ function cards, the function cards will be pre-installed in the company to your specification. If you want to install additional cards or exchange installed cards, use the following disassembling/assembling procedure.

WARNING


Disconnect the ProDAQ 6100 from the mains before opening the enclosure!

WARNING


Proper ESD handling procedures must always be used when packing, unpacking or installing any ProDAQ device or ProDAQ function card. Ground yourself via a grounding strap or similar, e.g. by holding to a grounded object and discharge the package by touching it to a grounded object, before removing the module from the package.

3.4.1. Opening the ProDAQ 6100 Enclosure


Remove the up to eight M2.5x6mm Panhead screws (①) attaching the front bezel to the function cards (If there is no function card installed in a slot and a blanking panel is used to cover the front bezel opening, do not remove its screws before detaching the front bezel). Then remove the two M3x6mm Countersunk screws (②) attaching the front bezel to the enclosure.




Slide the front bezel off (③) as shown below:



Remove the M3x6mm Countersunk screw (④) attaching the function card cover to the enclosure:




Slide the function card cover off (⑤) as shown below:




3.4.2. Removing a ProDAQ Function Card

The ProDAQ Function Cards are mounted inside the ProDAQ 6100 directly on the main PCB. The function cards positions two and four are located on top of the PCB and the positions one and three below. The function cards are mounted face down, e.g. the front-panel connectors as well as the motherboard connectors are underneath the PCB when mounted.

If you need to remove an installed function card before installing a new one, remove the three M3x6mm screws (①) mounting them to the base board (six M3x6mm screws for a double wide function card).




Remove the function card by pulling it (②) straight and evenly upward (or downward for a function card mounted on the bottom of the main PCB). Do not tilt the function card when doing so as it




might damage the connectors connecting it to the ProDAQ 6100 PCB.

3.4.3. Installing a ProDAQ Function Card

To install a ProDAQ Function Card into the ProDAQ 6100 LXI Function Card Carrier, you must first remove the front bezel and the function card cover as shown previously (see paragraph 3.4.1 Opening the ProDAQ 6100 Enclosure). Make sure that the M3x6mm screws and washers are removed from the PCB standoffs (①):




Position the function card over the function card slot you want to install it to (②), carefully aligning the connectors connecting it to the ProDAQ 6100 PCB and push it down until it seats fully onto the



standoffs of the ProDAQ 6100 PCB:


Use three M3x6mm panhead screws and washers (③) to attach the function card to the ProDAQ




6100 PCB (six screws and washers for a double wide function card):

3.4.4. Closing the ProDAQ 6100 Enclosure


To close the enclosure after installing or removing a ProDAQ function card, first slide back on the function card cover (①):




and attach it with a M3x6mm Torx screw to the enclosure:




Make sure that the cutouts for the function card connectors in the front bezel are properly opened or covered by filler panels to match the installed function cards. Slide the front bezel back on (3)



and attach it to the enclosure by two M3x6 countersunk screws





Attach the function cards to the front bezel using up to eight M2.5x6 panhead screws.

Warning

Using other screw types or lengths may permanently damage the instrument and/or cause electrical shorts!

3.5. Preparing the ProDAQ 6100 for first use

The ProDAQ 6100 can be used on a tabletop or mounted on a ProDAQ 6210 tray in a standard 19" rack.




Figure 3 - ProDAQ 6210 Rack-mount Tray

Please refer to the ProDAQ 6210 assembly instructions which can be downloaded from the Bustec web site (see <https://www.bustec.com/support/manuals/>) for details on how to install the tray and the ProDAQ 6100 into it..

Once the unit is in its place, connect the ProDAQ 6100 to your network via a 10/100/1000-Mbit switch or directly to your host computer using a CAT5e Ethernet cable, connect the IEC inlet on the rear to a mains outlet and turn the device on.

During the configuration of the network port the LAN LED on the front blinks green. Once the port is configured, the LAN LED shows either a constant green light showing that the network setup was finished successfully and the ProDAQ 6100 is now accessible via the LAN or a constant red indicating a failure.

3.5.1. Network Considerations

By default the ProDAQ 6100 uses DHCP to configure its network interface. If no DHCP server is found in the network, it will attempt to obtain a network address using AutoIP. AutoIP addresses are allocated from the reserved range 169.254.0.0 -169.254.255.255. The ProDAQ 6100 will first try to use the address 169.254.x.y, where <x> and <y> are the two last octets of the devices MAC address. If the address is already in use, a new pair of <x> and <y> will be generated using a random number generator. By using the embedded web interface, the ProDAQ 6100 can also be configured to use a static IP address.

Note

The usage of AutoIP is only recommended for direct connections between the ProDAQ 6100 and a host computer.

If there is a dynamic DNS server available in the network, the instrument can be also accessed via its hostname. The default hostname is:

ProDAQ6100-<serial number>.<domain>

Where:

<serial number> is the 8-digit serial number of the device,
<domain> is defined by the Dynamic DNS server.

When using a multicast DNS tool, the domain is set to "local". The host name can be also statically configured via the embedded web interface.

To reset the instruments network settings to the default configuration, press the recessed LAN reset button on the rear panel (see 3.3: Rear Panel Switches and Connectors).

3.5.2. Required Software

To operate not only the ProDAQ 6100 LXI Function Card Carrier itself, but also the ProDAQ Function Cards installed in it, you will need to install the Bustec VISA library on your computer. It can be downloaded from the Bustec web site at <https://www.bustec.com/support/drivers/>. The Bustec VISA library can be installed stand-alone, providing access to LXI, VXI, LAN-or USB based instruments; or in parallel to VISA libraries of other vendors.

For more details regarding the installation and use of the Bustec VISA library, please refer to the Bustec VISA user manual.

Note

Make sure that the access of the VISA library, its tools, the function card soft front panels or your application is not blocked by the firewall of the host computer.

3.5.3. Network Discovery

Once the ProDAQ 6100 is connected to a network and was assigned an IP address, there are several tools and ways to discover and access it.

LXI Discovery Tool

The LXI Discovery Tool is a standalone tool provided by the LXI Consortium. It uses the VXI-11 protocol or mDNS service discovery to discover LXI instruments in your LAN subnet. mDNS service recovery requires to install the Apple Bonjour Printer Services.




Figure 4 - LXI Discovery Tool

When discovery via the VXI11 protocol is used, each discovered device is queried using the “*IDN?” SCPI command. The device then responds with manufacturer, model, serial number, and firmware version as shown in the left screen shot. If mDNS service discovery is used, the mDNS service name is used as instrument description, as shown in the screen shot on the right.

For more information and downloading the LXI discovery tool, visit the web site of the LXI Consortium at <https://lxistandard.org/Resources/LXIDiscoveryTool.aspx>.

Bustec VISA

The Bustec VISA library contains a configuration tool which allows you to search, identify and configure network instruments. To view already known network instruments or add new, select the “Network Instruments” tab in the configuration utilities main dialog. All known network instruments will be displayed in the “Instrument Descriptor” list in the main dialog.




Figure 5 – Configuring Network Instruments

To search for network instruments located in your subnet, select the “Find Instruments ...” button to the right of the list of instrument descriptors. This opens the “Find Network Instruments” dialog, where you can set search parameters and perform the search.




Figure 6 - Searching for Network Instruments

To be found, the network instruments must comply to the VXI-11 standard and provide internal “VXI” (VXI-11.1), “GPIB” (VXI-11.2) or “INST” (VXI-11.3) interfaces and they must be able to respond to the “*IDN?” query. By checking/unchecking the boxes in front of the entries in the interface list the search can be limited to a particular type or set of types of interfaces. By setting the interface number ranges the search is limited to the selected range of interface numbers.

After selecting the “Search for Instruments” button, the utility uses network broadcasts to search for the instruments. Each instrument is then sent an “*IDN?” query and the results are shown in the “Find Network Instruments” dialog.

After a successful search, select the “Add All” button below the list to add all network instruments found to the list of known instruments or select instruments from the list and the “Add Selected” button to add only the instruments selected. The “Cancel” button allows you to close the dialog without adding any instrument.

If you run the Bustec VISA Agent you can discover the ProDAQ 6100 using mDNS discovery. The Bustec VISA Agent is a background task that monitors hot-plug events for ProDAQ VXIbus Interfaces and mDNS services published by LXI Devices. The agent can be accessed via its icon in the system tray.

If you select the icon, a popup menu is shown which allows access to the different applications included in the Bustec VISA installation and shows discovered network devices.




Figure 7 - Bustec Agent Network Device Discovery

As with the LXI Discovery Tool provided by the consortium, the mDNS discovery requires the installation of the Apple Bonjour Printer Services.

For more information, refer to the Bustec VISA User Manual.

3.5.4. Accessing the Instrument

Once the instrument was successfully discovered, you can access and configure the instrument via its web interface by a web browser using the instruments IP or mDNS host name.




Figure 8 - Access the instrument home page

4. WEB Page Operation

The ProDAQ 6100 features an embedded web server, which allows you to configure and operate the ProDAQ 6100 by using a standard web browser from any host computer in your network. To make use of the complete functionality of the embedded web interface, the browser will need to have its JavaScript support enabled.

4.1. Instrument Home Page

The instrument home page shows general information about the device like model number, manufacturer, serial number, and revisions.




Figure 9 - Instrument Home Page

From here you can navigate to the different categories and pages by using the menu on the left side. For security reasons, all pages except of the instruments home page are protected by username and password, which can be configured on the "Device Configuration" -> "Security Settings" page. Upon delivery, the username is set to "admin" and password to "1234".

The <On/Off> button on the instrument home page allows you to identify physically the ProDAQ 6100 you are connected to. When you click onto the button, the LAN status indicator on the front bezel will start flashing. A second click switches the LAN indicator off again.

4.2. IP Configuration

The IP Configuration Page allows you to change the settings for the ProDAQ 6100's LAN interface.




Figure 10 - IP Configuration Page

The IP Configuration page shows the current settings assigned for the instruments LAN interface and allows you to change and store the following settings:

Hostname User defined hostname for the device (without domain).

Clear this value to revert to factory default.

Note: Multicast DNS domain is always: “.local”. Dynamic DNS domain depends on the network configuration.

User Description User defined description of the device – it is displayed on the Home Page along with user defined Asset Number (see Device Configuration).

Clear this value to revert to factory default.

Current IP configuration Displays currently assigned: IP Address, Subnet Mask, Default Gateway and DNS servers.

TCP/IP mode	<p>Specifies whether the device shall use a DHCP server in the network, or AutoIP protocol to automatically obtain the IP configuration, or maybe the static IP configuration defined in the form below.</p> <p>More than one option may be selected. The priority is as follows: DHCP → AutoIP → Static. For example, if DHCP and Static are selected and DHCP fails, the Static configuration is set.</p>
IP Address	<p>If "Static IP" was selected as the TCP/IP mode, this field allows assignment of a static IP address to the ProDAQ 6100s LAN interface.</p>
Subnet mask	<p>If "Static IP" was selected as the TCP/IP mode, this field allows assignment of a static subnet mask address to the ProDAQ 6100s LAN interface.</p>
Default Gateway	<p>If "Static IP" was selected as the TCP/IP mode, this field allows assignment of a static default gateway for the routing of IP packets.</p>
DNS Servers	<p>If "Static IP" was selected as the TCP/IP mode, these two fields allow you to specify the DNS server the ProDAQ 6100 will use for name resolving. If "DHCP" was selected as the TCP/IP mode, then it is possible to select whether the DNS servers' IP addresses shall be acquired automatically (DHCP) or user-defined (Static).</p>
MTU	<p>Maximum Transmission Unit (MTU) – maximum size (in bytes) of an IP packet that can be transmitted without fragmentation (including IP headers, but excluding headers from lower levels in the protocol stack).</p> <p>The default value for a typical network is 1500 B. It can be defined as high as 9000 B (jumbo frames). For correct interoperability, the whole network must have the same MTU.</p> <p>For best performance, it is recommended to configure the network to work with as high MTU as possible.</p>
mDNS Service Name	<p>User defined name of mDNS services that are advertised by the ProDAQ 6100 device.</p> <p>Clear this value to revert to factory default.</p>

The device has a LAN reset mechanism that restores all the IP and IEEE1588 configuration back to factory defaults. In order to reset the settings press the "RST" button that can be found in the rear panel of the ProDAQ 6100.

4.3. Synchronization Configuration

The ProDAQ 6100 uses IEEE 1588-2008 (version 2) for clock synchronization. The Synchronization Configuration page shows the current IEEE 1588 status and allows its configuration. You can also configure here whether the LXI triggers of the device shall act as bias in Wired-Or trigger chain.




Figure 11 - Synchronization Configuration Page (Slave Mode)

IEEE 1588 domain

Specifies the IEEE 1588 domain number – logical part of the network in which the device should work. Default domain is 0.

IEEE 1588 mode

Specifies the priority of the device for the master clock selection procedure. “Slave only” mode ensures that the device cannot become a master clock in any network – it is always slave. “Highest priority” mode means that the device has highest chances of becoming a master. It may remain slave however if there is another device in the network with highest priority defined that advertises itself as having a better clock accuracy. The “Automatic” mode on the other hand relies only on the best clock selection

algorithm.

Delay asymmetry

For better performance, this parameter should reflect the network architecture that affects the difference between the time a packet gets from one device to another and the return time.

If the return time is longer – the value should be positive. By default this value is 0 ns.

Offset from Master threshold

If the “Offset from Master” value is below the user defined threshold the device is considered as synchronized.




Figure 12 - Synchronization Configuration Page (Master Mode)

The IEEE 1588 status parameters are:

Grandmaster clock Grandmaster clock ID (MAC address extended to IEEE EUI-64).

Parent clock Parent clock ID (MAC address extended to IEEE EUI-64).

State Current state of the IEEE 1588 protocol engine working on the ProDAQ 6100. Can be one of the following: INITIALIZING, FAULTY, DISABLED, LISTENING, PRE_MASTER, MASTER, PASSIVE, UNCALIBRATED.

In case of SLAVE state also the synchronization state is displayed:

SYNCHRONIZED or NOT SYNCHRONIZED.

Synchronized elapsed time	Time in seconds since the device remains constantly synchronized (considering the “Offset from Master threshold”).
Current PTP time	Shows the current IEEE 1588 time kept by the device. Seconds since midnight, January 1 st , 1970 (represented as “seconds.fractional seconds”). Additionally a formatted date is also displayed.
Current local time	Local system time kept by the system clock on the device. It may differ from the PTP time when the PTP state is not Master.
Grandmaster traceability to UTC	Displays a string defined by IEEE 1588 standard that defines how the grandmaster clock is related to the Universal Coordinated Time (UTC).
Mean path delay	The average value of time in which the packet gets to the Master and the time the response gets back from Master.
Variance of parent clock	This value is unavailable.
Offset from Master	Current observed difference between the Master and the Slave clock.
Observed drift	An implementation specific value which is related to the precision of the clock oscillator.

Please note that only the parameters that are relevant to the current IEEE 1588 state are displayed on the page (see Figure 11 and Figure 12).

The “LXI Domain” parameter displays the LXI domain number used in the module-to-module data communication (LXI Sync messages).

In the “Wired Trigger Parameters” section it is possible to select whether a trigger line on the LXI trigger bus is enabled to act as a bias for a Wired-OR chain. In any Wired-Or chain there shall be exactly one device acting as a bias for the chain.

4.4. Function Cards & Options

The pages under “Function Cards & Options” show the functions cards and options like for example the ProDAQ 3202 Voltage Reference Plug-in installed in the ProDAQ 6100.

4.4.1. Function Cards

The first page, “Function Cards”, gives an overview about the function cards installed. Each function card is listed with its model number, description and serial number (when available).

The screenshot shows a web browser window displaying the LXI - Bustec Ltd. - ProDAQ 6100 LXI Function Card Carrier interface. The page title is "Function Cards & Options \ Function Cards". The interface includes a navigation menu on the left with options like Home, Network Settings, Sync Configuration, Function Cards & Options (selected), Function Cards, Options, Device Status, Device Configuration, and Documentation. The main content area features a table of installed function cards:

Position	Model	Description	Serial No.	
1	-	No Function Card installed	-	More ...
2	ProDAQ 3416-BA	16-Channel Sigma-Delta ADC	10487872	More ...
3	ProDAQ 3550	2-Channel Fast DAC/AWG	n/a	More ...
4	ProDAQ 3808-RA	8-Channel Counter/Timer/Frequency Meter	00114078	More ...

Below the table is a "Back" button. The footer of the page contains "Copyright © 1997-2016 Bustec Ltd." and "www.bustec.com".

Figure 13 - Function Card Page

Selecting the “More ...” button for one of the function cards opens the next page (see below), which allows a basic read/write access to the function card registers.

Function Card Register Access

The “Register Access” page allows basic read/write access of the function card registers.




Figure 14 - Function Card Access Page

To read a function card register, enter the register address in the “Register Address” field or use the “+”/“-” buttons to change/set the desired address and then select the “Read” button below. After completion of the read operation, the “Read Data” field display the data read from the register and the “Returned Status” field shows whether the operation was successful or not.

To write to a function card register, you need to specify the value to write in addition to the register address in the “Data to Write” field. After you have entered or changed both the address and data to write, select the “Write” button below. After completion of the write operation, the “Returned Status” field shows whether the operation was successful or not.

4.4.2. Options

The second page “Options”, shows all options installed in the ProDAQ 6100.




Figure 15 - Options Page

Selecting the “More ...” button to the right of the listed option opens a page that shows the details for the option, like for example the calibration data for the ProDAQ 3202 Voltage Reference Plug-in.

ProDAQ 3202 Voltage Reference Plug-In

The ProDAQ 3202 Voltage Reference Plug-in module provides a set of highly stable voltages that can be used to calibrate the ProDAQ function cards and signal conditioning cards and modules on-the-fly before any measurement without disconnecting any sensor cables. The output voltage of the ProDAQ 3202 is distributed via the internal voltage reference bus to the function cards and via the I/O cables further on to the ProDAQ signal conditioning cards and modules, where it then can be switched into the input of the front-most input circuitry. The software drivers use this feature to provide fully automated calibration routines to the user.

During calibration the output voltages of the ProDAQ 3202 are not adjusted. Instead the precise value measured is stored in an on-board EEPROM and used by the calibration routines. This provides a better precision and what is more, a higher stability than provided by an adjustable circuitry.

The table shown in on the “Voltage Reference” page (Figure 16) lists all voltages by their nominal values and stored calibrated values. It also shows both the current temperature and the temperature at the last calibration. Please note that this is the temperature measured on the ProDAQ 3202 Voltage Reference Plug-in and not the ambient temperature.

The “Calibrate ...” bottom to the right of each voltage listing allows the re-calibration of the particular setting by the user. To do so, a precision voltage meter must be connected to the voltage reference monitor output of the ProDAQ 6100 (see 3.3: Rear Panel Switches and Connectors, “VREF”).




Figure 16 - Voltage Reference Calibration Data

WARNING

Changing the calibration values of the ProDAQ 3202 will directly influence the precision of any measurements taken. Please make sure that you use a calibrated voltage meter providing at least the accuracy stated in the ProDAQ 3202 datasheet.

Note

When calibrating the voltage settings it is of utmost importance that the ProDAQ 6100 with the ProDAQ 3202 was warmed up at least for one hour. This applies also when doing measurements. Only then can be guaranteed that all parts of the system are equally warmed up and that the drift caused by temperature changes is minimized.


WARNING

While using the following procedure to calibrate the ProDAQ 3202, please make sure that the ProDAQ 6100 it is installed in is not otherwise used or accessed. Interrupting the process may cause invalid data to be stored and may require to


recalibrate the ProDAQ 3202 again.

Calibration Procedure

When selecting one of the “Calibrate ...” buttons to the right of a voltage listed, the following pop-up will be shown:



When selecting “OK”, the ProDAQ 3202 is set to generate the selected voltage and the output is enabled, allowing you to measure the voltage. On the next page shown the new measured voltage can be entered:



The “Refresh” button allows updating the information regarding temperature and uptime shown on the page. “Back” allows navigating back to the previous page.

If a new calibration voltage shall be stored, the measured value must be entered into the input field provided and the “Write” button must be selected. The data in the input field must be entered as floating point value followed by a unit, either “V” or “mV”.

After confirming the value in the next dialog, the value is stored together with the current date and temperature in the onboard EEPROM of the ProDAQ 6100, the ProDAQ 3202 output is switched back to ground and the page providing the listing of calibration data is shown.

Please note that the calibration data in the EEPROM of the ProDAQ 3202 is stored as 32-bit floating point values, so the resolution for the nominal values +9V, -9V, +4.5V and -4.5V is 119 nV and for all other nominal values 119 pV. The setting stored will be rounded to the nearest possible value of the number entered.

To calibrate additional settings, one of the other “Calibrate ...” buttons in the table can be selected, invoking the procedure for one of the other values. When finished calibrating, the ProDAQ 6100 needs to be restarted to re-read the values from the EEPROM of the ProDAQ 3202.

4.5. Device Status

The Device Status page display the general status of the device and allows access to more detailed information as well.




Figure 17 - Device Status Page

4.5.1. Advanced Status

The Advanced Status page allows you to review the output of a number of embedded tools to analyze the device status in more details.




Figure 18 - Advanced Status Page

Figure 18 shows an example of the Advanced Status page showing the output of the embedded “ifconfig” command. To select any of the available advanced status information, select one of the items from the list and select the “Refresh” button.

The following advanced status information is currently available:

- ifconfig** Displays the output of the embedded “ifconfig” command, showing the settings for the Ethernet interface as seen by the operating system.

- route** Displays the output of the embedded “route” command, showing the kernel routing table.

- resolv.conf** Shows the contents of the “resolv.conf” file containing the current name server settings.

- hosts** Shows the contents of the local “hosts” file.

- device.conf** Shows the contents of the device.conf file as created by the embedded web interface. This file stores the information specified by the IP setup page.

- device and firmware revision** Shows the current revisions of the different parts of the system.

4.6. System Log

The System Log page shows the contents of the system log. Any housekeeping or debugging information will be entered here by the operating system. To get an up-to-date status, press the "Refresh" button below.




Figure 19 - System Log Page

4.7. Device Configuration

The Device Configuration page allows you to change several parameters of the internal configuration of the device. In addition it allows you to reboot the device or update its firmware.




Figure 20 - Device Configuration Page

The device configuration is split up into several sub-items. Click on one of the “Change ...” buttons to the right of the different sections to access them. To reboot the device, select the “Reboot Device” button. A reboot may take up to 30 seconds to complete. To update the firmware, select the “Firmware Update” button to access the Firmware Update page.

4.7.1. General Settings

This page allows you to change the system time and assign an asset number to the device, which will be shown on the instrument home page.




Figure 21 - General Settings Page

4.7.2. LXI Trigger Settings

This Page allows configuration of the LXI triggers. For each of the 8 triggers it is possible to set a driver mode and, if the driver is enabled, also the state of the trigger line (Asserted or De-asserted). Additionally the current trigger status is displayed.




Figure 22 - LXI trigger Settings Page

The driver for a trigger line may operate in one of the following modes:

Disabled

LXI devices that are not taking part in trigger operation shall have their drivers disabled.

Driven

This provides point-to-multipoint operation. One device initiates a trigger event to one or more receiving devices. This mode uses one driver per LXI Device for each LXI Trigger Bus channel.

Wired-OR

This is a multipoint-to-multipoint operation. One or more devices initiate a trigger event to one or more receiving devices. In this mode, the event can be initiated by the first device to trigger (first device to recognize an event starts others to perform tasks), or the last device to trigger (last device ready initiates others to perform tasks).

Wired-OR Bias

The Wired-OR Mode requires one device to be configured as the Wired-OR Bias Device to provide a bias for the LXI Trigger Bus channel.

If the driver for a particular trigger line is enabled either as “Driven”, “Wired-OR” or “Wired-OR Bias”, it can be asserted or de-asserted using the control in the “Settings” column of the table.

The “Status” column fields always display the current status of the trigger lines. Select the “Refresh” button below to get an up-to-date status.

4.7.3. Security Settings

On this page you can change the password that is used to protect the pages of the ProDAQ 6100. Please type in your old password, the new one and confirm it by re-typing.




Figure 23 - Security Settings Page

4.8. Datasheet

The datasheet page displays the datasheet for the ProDAQ 6100 LXI Function Card carrier.




Figure 24 - Datasheet Page

4.9. Manual

The Manual page displays the manual for the ProDAQ 6100 or allows you to download it onto your computer. You will need to have the Adobe Acrobat plug-in for your browser installed to view the manual in-line.




Figure 25 - Manual Page

5. IVI Instrument Driver

The ProDAQ 6100 LXI Function Card Carrier is provided with a IVI-C Specific Driver. The IVI-C driver is written in conformance with IVI-3.1 Driver Architecture Specification (Rev. 2.2) and IVI-3.15 IviLxiSync Specification (Rev 1.0). IVI Class specification version is 2.0. The driver contains functions for opening, configuring, taking measurements from, and closing the instrument.

5.1. Assumptions

To successfully use this device, the following conditions must be met:

- The device must be connected to the LAN over LAN port;
- The device must have proper IP configuration (IP address, Subnet Mask, Default Gateway, etc.);
- The computer, where the IVI driver is used, should have the VISA and IVI Shared components installed and properly configured;

5.2. Error and Status Information

Each function in this instrument driver returns a status code that either indicates success or describes an error or warning condition. Your program should examine the status code returned by each call to an instrument driver function to determine if an error occurred.

The general meaning of the status code is:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

The description of each instrument driver function lists possible error codes and their meanings.

5.3. How to use this manual

Use this document as a programming reference manual. It describes each function for the ProDAQ 6100 LXI Function Card Carrier instrument. The functions appear in alphabetical order, with a description of the function and its C syntax, a description of each parameter, and a list of possible error codes.

5.4. IVI-C Driver Functions

Class/Panel Name:	Function Name:
Initialize	bu6100_init
Initialize With Options	bu6100_InitWithOptions
Configuration Functions	
Set/Get/Check Attribute	
Set Attribute	
Set Attribute ViInt32	bu6100_SetAttributeViInt32
Set Attribute ViReal64	bu6100_SetAttributeViReal64
Set Attribute ViString	bu6100_SetAttributeViString
Set Attribute ViBoolean	bu6100_SetAttributeViBoolean
Set Attribute ViSession	bu6100_SetAttributeViSession
Get Attribute	

Get Attribute ViInt32	bu6100_GetAttributeViInt32
Get Attribute ViReal64	bu6100_GetAttributeViReal64
Get Attribute ViString	bu6100_GetAttributeViString
Get Attribute ViBoolean	bu6100_GetAttributeViBoolean
Get Attribute ViSession	bu6100_GetAttributeViSession
Check Attribute	
Check Attribute ViInt32	bu6100_CheckAttributeViInt32
Check Attribute ViReal64	bu6100_CheckAttributeViReal64
Check Attribute ViString	bu6100_CheckAttributeViString
Check Attribute ViBoolean	bu6100_CheckAttributeViBoolean
Check Attribute ViSession	bu6100_CheckAttributeViSession
Function Card Functions	
Select Function Card CCLK	bu6100_setFcCclk
Get Function Card CCLK	bu6100_getFcCclk
Triggers and Interrupts Functions	
Configure Trigger Lines	bu6100_configTrig
Install Interrupt Handler	bu6100_installIrqHandler
Install Interrupt Watcher	bu6100_installIrqWatcher
Remove Interrupt Service	bu6100_removeIrqService
Configure 1588 PPP	bu6100_config1588ppp
Voltage Reference Functions	
Get Voltage Reference Info	bu6100_getVoltRefInfo
1588 Functions	
Get 1588 Configuration	bu6100_get1588config
Set 1588 Configuration	bu6100_set1588config
DRAM Functions	
Allocate DRAM segment	bu6100_allocDram
Free DRAM segment	bu6100_freeDram
Circular Buffer Functions	
Set CB Configuration	bu6100_setConfigCB
Get CB Configuration	bu6100_getConfigCB
LxiSync Functions	
Arm	
Alarm	
Add Arm Alarm	bu6100_IviLxiSync_AddArmAlarm
Configure Arm Alarm	bu6100_IviLxiSync_ConfigureArmAlarm
Disable All Arm Alarms	bu6100_IviLxiSync_DisableAllArmAlarms
Get Arm Alarm Name	bu6100_IviLxiSync_GetArmAlarmName
Remove All Custom Arm Alarms	bu6100_IviLxiSync_RemoveAllCustomArmAlarms
Remove Arm Alarm	bu6100_IviLxiSync_RemoveArmAlarm
Source	
Add Arm Source	bu6100_IviLxiSync_AddArmSource
Configure Arm Source	bu6100_IviLxiSync_ConfigureArmSource
Disable All Arm Sources	bu6100_IviLxiSync_DisableAllArmSources
Get Arm Source Name	bu6100_IviLxiSync_GetArmSourceName
Remove All Custom Arm Sources	bu6100_IviLxiSync_RemoveAllCustomArmSources
Remove Arm Source	bu6100_IviLxiSync_RemoveArmSource
Event	
Add Event	bu6100_IviLxiSync_AddEvent
Configure Event	bu6100_IviLxiSync_ConfigureEvent
Disable All Events	bu6100_IviLxiSync_DisableAllEvents
Get Event Name	bu6100_IviLxiSync_GetEventName
Remove All Custom Events	bu6100_IviLxiSync_RemoveAllCustomEvents
Remove Event	bu6100_IviLxiSync_RemoveEvent
Trigger	
Alarm	
Add Trigger Alarm	bu6100_IviLxiSync_AddTriggerAlarm
Configure Trigger Alarm	bu6100_IviLxiSync_ConfigureTriggerAlarm
Disable All Trigger Alarms	bu6100_IviLxiSync_DisableAllTriggerAlarms
Get Trigger Alarm Name	bu6100_IviLxiSync_GetTriggerAlarmName
Remove All Trigger Alarms	bu6100_IviLxiSync_RemoveAllTriggerAlarms
Remove Trigger Alarm	bu6100_IviLxiSync_RemoveTriggerAlarm
Source	
Add Trigger Source	bu6100_IviLxiSync_AddTriggerSource
Configure Trigger Source	bu6100_IviLxiSync_ConfigureTriggerSource
Get Trigger Source Name	bu6100_IviLxiSync_GetTriggerSourceName
Remove All Custom Trigger Sources	bu6100_IviLxiSync_RemoveAllCustomTriggerSources
Remove Trigger Source	bu6100_IviLxiSync_RemoveTriggerSource
Arm Trigger	bu6100_IviLxiSync_ArmTrigger
Event Log	
Clear Event Log	bu6100_IviLxiSync_ClearEventLog
Get Next Event Log Entry	bu6100_IviLxiSync_GetNextEventLogEntry
Configure Trigger Log	bu6100_IviLxiSync_ConfigureTriggerLog
Clear Trigger Log	bu6100_IviLxiSync_ClearTriggerLog
Get Number Of Trigger Log Entries	bu6100_IviLxiSync_GetNumberOfTriggerLogEntries
Get Next Trigger Log Entry	bu6100_IviLxiSync_GetNextTriggerLogEntry

Time	
Get System Time	bu6100_IviLxiSync_GetSystemTime
Set System Time	bu6100_IviLxiSync_SetSystemTime
Action/Status Functions	
Function Card Functions	
Reset Function Card	bu6100_fcReset
Triggers and Interrupts Functions	
Pulse Trigger	bu6100_pulseTrig
Assert 1588 Trigger	bu6100_assert1588trig
Pulse Triggers Synchronously	bu6100_pulseTrigSynch
Wait for Interrupt Watcher	bu6100_waitIrqWatcher
Read Trigger Status	bu6100_getTrigStatus
Read Signal Lines Status	bu6100_readSigLinesStat
Voltage Reference Functions	
Set Voltage Reference Output	bu6100_setVoltRefOutput
Get Voltage Reference Output	bu6100_getVoltRefOutput
Read Volt. Ref. Temperature	bu6100_readVRTemp
1588 Functions	
Get 1588 Status	bu6100_get1588status
Get 1588 Timing	bu6100_get1588timing
List Control	
Load List	bu6100_loadList
Start List	bu6100_startList
Kill List	bu6100_killList
Wait List	bu6100_waitList
Synchronize List Variables	bu6100_synchronizeListVars
Circular Buffer Functions	
Get CB Status	bu6100_getCBstatus
Data Functions	
Function Card Access Functions	
Read from Function Card	bu6100_fcRead
Read32 from Function Cards	bu6100_fcRead32
Write to Function Card	bu6100_fcWrite
Write32 to Function Card	bu6100_fcWrite32
Broadcast Write to Func. Cards	bu6100_fcWriteBcast
Read Block from Function Card	bu6100_fcReadBlock
Write Block to Function Card	bu6100_fcWriteBlock
Read Blck32 from Function Cards	bu6100_fcReadBlock32
Write Block32 to Function Cards	bu6100_fcWriteBlock32
Read Block64 from Function Card	bu6100_fcReadBlock64
Write Block64 to Function Cards	bu6100_fcWriteBlock64
DRAM Functions	
Read DRAM	bu6100_readDram
Write DRAM	bu6100_writeDram
Circular Buffer Functions	
Read From CB	bu6100_readCB
Write To CB	bu6100_writeCB
Utility Functions	
Reset	bu6100_reset
Reset With Defaults	bu6100_ResetWithDefaults
Disable	bu6100_Disable
Self-Test	bu6100_self_test
Revision Query	bu6100_revision_query
Error-Query	bu6100_error_query
Error Message	bu6100_error_message
Invalidate All Attributes	bu6100_InvalidateAllAttributes
Error Info	
Get Error	bu6100_GetError
Clear Error	bu6100_ClearError
Coercion Info	
Get Next Coercion Record	bu6100_GetNextCoercionRecord
Interchangeability Info	
Get Next Interchange Warning	bu6100_GetNextInterchangeWarning
Clear Interchange Warnings	bu6100_ClearInterchangeWarnings
Reset Interchange Check	bu6100_ResetInterchangeCheck
Locking	
Lock Session	bu6100_LockSession
Unlock Session	bu6100_UnlockSession
Instrument I/O	
Write Instrument Data	bu6100_WriteInstrData
Read Instrument Data	bu6100_ReadInstrData
Identify Instrument	bu6100_identify
Read Board Temperature	bu6100_readBoardTemp
Close	bu6100_close

5.5. IVI-C Driver Function Details

5.5.1. bu6100_allocDram

```
ViStatus bu6100_allocDram (ViSession instrumentHandle, ViInt32 size,
                          ViPInt32 offset);
```

Purpose

Allocates the segment of DRAM in the ProDAQ 6100 module.

Parameter List

instrumentHandle

Variable Type ViSession

The Instrument Handle is used to identify the unique session or communication channel between the driver and the instrument.

If more than one instrument of the same model type is used, this Handle will be used to differentiate between them.

size

Variable Type ViInt32

Specifies the number of 32-bit words to be allocated in the 6100 Module DRAM.

offset

Variable Type ViInt32 (passed by reference)

Returns the offset of the allocated DRAM memory segment. This address can be used directly in functions bu6100_readDram() or bu6100_writeDram as an "Offset" parameter.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors

BFFF0000 to BFFFFFFF	VISA	Errors
BFFC0000 to BFFCFFFF	VXIPInP	Driver Errors

5.5.2. bu6100_assert1588trig

```
ViStatus bu6100_assert1588trig (ViSession instrumentHandle,
                               ViReal64 timeSeconds,
                               ViReal64 timeFractional);
```

Purpose

This function configures the 1588 trigger to be asserted at the specified 1588 time

Parameter List

instrumentHandle

Variable Type ViSession

The Instrument Handle is used to identify the unique session or communication channel between the driver and the instrument.

If more than one instrument of the same model type is used, this Handle will be used to differentiate between them.

timeSeconds

Variable Type ViReal64

Specifies the seconds portion of the 1588 time when the trigger should be asserted.

timeFractional

Variable Type ViReal64

Specifies the fractional portion of the 1588 time when the trigger should be asserted.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.3. bu6100_CheckAttributeViBoolean

```
ViStatus bu6100_CheckAttributeViBoolean (ViSession instrumentHandle,
                                         ViChar _VI_FAR channelName[],
                                         ViAttr attributeID,
                                         ViBoolean attributeValue);
```

Purpose

This function checks the validity of a value you specify for a ViBoolean attribute.

Parameter List

instrumentHandle

Variable Type ViSession

The ViSession handle that you obtain from the bu6100_init or bu6100_InitWithOptions function. The handle identifies a particular instrument session.

Default Value: None

channelName

Variable Type ViChar[]

If the attribute is channel-based, this parameter specifies the name of the channel on which to check the attribute value. If the attribute is not channel-based, then pass VI_NULL or an empty string.

Valid Channel Names: 1

Default Value: ""

attributeID

Variable Type ViAttr

Pass the ID of an attribute.

From the function panel window, you can use this control as follows.

- Click on the control or press <ENTER>, <spacebar>, or <ctrl-down arrow>, to display a dialog box containing a hierarchical list of the available attributes. Attributes whose value cannot be set are dim. Help text is shown for each attribute. Select an attribute by double-clicking on it or by selecting it and then pressing <ENTER>.

Read-only attributes appear dim in the list box. If you select a read-only attribute, an error message appears.

A ring control at the top of the dialog box allows you to see all IVI attributes or only the attributes of the ViBoolean type. If you choose to see all IVI attributes, the data types appear to the right of the attribute names in the list box. Attributes with data types other than ViBoolean are dim. If you select an attribute data type that is dim, LabWindows/CVI transfers you to the function panel for the corresponding function that is consistent with the data type.

- If you want to enter a variable name, press <CTRL-T> to change this ring control to a manual input box.
- If the attribute in this ring control has named constants as valid values, you can view the constants by moving to the Attribute Value control and pressing <ENTER>.

attributeValue

Variable Type ViBoolean

Pass the value which you want to verify as a valid value for the attribute.

From the function panel window, you can use this control as follows.

- If the attribute currently showing in the Attribute ID ring control has constants as valid values, you can view a list of the constants by pressing <ENTER> on this control. Select a value by double-clicking on it or by selecting it and then pressing <ENTER>.

Note: Some of the values might not be valid depending on the current settings of the instrument session.

Default Value: none

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.4. bu6100_CheckAttributeViInt32

```
ViStatus bu6100_CheckAttributeViInt32 (ViSession instrumentHandle,
                                       ViChar _VI_FAR channelName[],
                                       ViAttr attributeID,
                                       ViInt32 attributeValue);
```

Purpose

This function checks the validity of a value you specify for a ViInt32 attribute.

Parameter List

instrumentHandle

Variable Type ViSession

The ViSession handle that you obtain from the bu6100_init or bu6100_InitWithOptions function. The handle identifies a particular instrument session.

Default Value: None

channelName

Variable Type ViChar[]

If the attribute is channel-based, this parameter specifies the name of the channel on which to check the attribute value. If the attribute is not channel-based, then pass VI_NULL or an empty string.

Valid Channel Names: 1

Default Value: ""

attributeID

Variable Type ViAttr

Pass the ID of an attribute.

From the function panel window, you can use this control as follows.

- Click on the control or press <ENTER>, <spacebar>, or <ctrl-down arrow>, to display a dialog box containing a hierarchical list of the available attributes. Attributes whose value cannot be set are dim. Help text is shown for each attribute. Select an attribute by double-clicking on it or by selecting it and then pressing <ENTER>.

Read-only attributes appear dim in the list box. If you select a read-only attribute, an error message appears.

A ring control at the top of the dialog box allows you to see all IVI attributes or only the attributes of the ViInt32 type. If you choose to see all IVI attributes, the data types appear to the right of the attribute names in the list box. Attributes with data types other than ViInt32 are dim. If you select an attribute data type that is dim, LabWindows/CVI transfers you to the function panel for the corresponding function that is consistent with the data type.

- If you want to enter a variable name, press <CTRL-T> to change this ring control to a manual input box.
- If the attribute in this ring control has named constants as valid values, you can view the constants by moving to the Attribute Value control and pressing <ENTER>.

attributeValue

Variable Type ViInt32

Pass the value which you want to verify as a valid value for the attribute.

From the function panel window, you can use this control as follows.

- If the attribute currently showing in the Attribute ID ring control has constants as valid values, you can view a list of the constants by pressing <ENTER> on this control. Select a value by double-clicking on it or by selecting it and then pressing <ENTER>.

Note: Some of the values might not be valid depending on the current settings of the instrument session.

Default Value: none

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.5.

bu6100_CheckAttributeViReal64

```
ViStatus bu6100_CheckAttributeViReal64 (ViSession instrumentHandle,
                                       ViChar _VI_FAR channelName[],
                                       ViAttr attributeID,
                                       ViReal64 attributeValue);
```

Purpose

This function checks the validity of a value you specify for a ViReal64 attribute.

Parameter List**instrumentHandle**

Variable Type ViSession

The ViSession handle that you obtain from the bu6100_init or bu6100_InitWithOptions function. The handle identifies a particular instrument session.

Default Value: None

channelName

Variable Type ViChar[]

If the attribute is channel-based, this parameter specifies the name of the channel on which to check the attribute value. If the attribute is not channel-based, then pass VI_NULL or an empty string.

Valid Channel Names: 1

Default Value: ""

attributeID

Variable Type ViAttr

Pass the ID of an attribute.

From the function panel window, you can use this control as follows.

- Click on the control or press <ENTER>, <spacebar>, or <ctrl-down arrow>, to display a dialog box containing a hierarchical list of the available attributes. Attributes whose value cannot be set are dim. Help text is shown for each attribute. Select an attribute by double-clicking on it or by selecting it and then pressing <ENTER>.

Read-only attributes appear dim in the list box. If you select a read-only attribute, an error message appears.

A ring control at the top of the dialog box allows you to see all IVI attributes or only the attributes of the ViReal64 type. If you choose to see all IVI attributes, the data types appear to the right of the attribute names in the list box. Attributes with data types other than ViReal64 are dim. If you select an attribute data type that is dim, LabWindows/CVI transfers you to the function panel for the corresponding function that is consistent with the data type.

- If you want to enter a variable name, press <CTRL-T> to change this ring control to a manual input box.
- If the attribute in this ring control has named constants as valid values, you can view the constants by moving to the Attribute Value control and pressing <ENTER>.

attributeValue

Variable Type ViReal64

Pass the value which you want to verify as a valid value for the attribute.

From the function panel window, you can use this control as follows.

- If the attribute currently showing in the Attribute ID ring control has constants as valid values, you can view a list of the constants by pressing <ENTER> on this control. Select a value by double-clicking on it or by selecting it and then pressing <ENTER>.

Note: Some of the values might not be valid depending on the current settings of the instrument session.

Default Value: none

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.6. bu6100_CheckAttributeViSession

```
ViStatus bu6100_CheckAttributeViSession (ViSession instrumentHandle,
                                         ViChar _VI_FAR channelName[],
                                         ViAttr attributeID,
                                         ViSession attributeValue);
```

Purpose

This function checks the validity of a value you specify for a ViSession attribute.

Parameter List

instrumentHandle

Variable Type ViSession

The ViSession handle that you obtain from the bu6100_init or bu6100_InitWithOptions function. The handle identifies a particular instrument session.

Default Value: None

channelName

Variable Type ViChar[]

If the attribute is channel-based, this parameter specifies the name of the channel on which to check the attribute value. If the attribute is not channel-based, then pass VI_NULL or an empty string.

Valid Channel Names: 1

Default Value: ""

attributeID

Variable Type ViAttr

Pass the ID of an attribute.

From the function panel window, you can use this control as follows.

- Click on the control or press <ENTER>, <spacebar>, or <ctrl-down arrow>, to display a dialog box containing a hierarchical list of the available attributes. Attributes whose value cannot be set are dim. Help text is shown for each attribute. Select an attribute by double-clicking on it or by selecting it and then pressing <ENTER>.

Read-only attributes appear dim in the list box. If you select a read-only attribute, an error message appears.

A ring control at the top of the dialog box allows you to see all IVI attributes or only the attributes of the ViSession type. If you choose to see all IVI attributes, the data types appear to the right of the attribute names in the list box. Attributes with data types other than ViSession are dim. If you select an attribute data type that is dim, LabWindows/CVI transfers you to the function panel for the corresponding function that is consistent with the data type.

- If you want to enter a variable name, press <CTRL-T> to change this ring control to a manual input box.
- If the attribute in this ring control has named constants as valid values, you can view the constants by moving to the Attribute Value control and pressing <ENTER>.

attributeValue

Variable Type ViSession

Pass the value which you want to verify as a valid value for the attribute.

From the function panel window, you can use this control as follows.

- If the attribute currently showing in the Attribute ID ring control has constants as valid values, you can view a list of the constants by pressing <ENTER> on this control. Select a value by double-clicking on it or by selecting it and then pressing <ENTER>.

Note: Some of the values might not be valid depending on the current settings of the instrument session.

Default Value: none

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.7. bu6100_CheckAttributeViString

```
ViStatus bu6100_CheckAttributeViString (ViSession instrumentHandle,
                                       ViChar _VI_FAR channelName[],
                                       ViAttr attributeID,
                                       ViChar _VI_FAR attributeValue[]);
```

Purpose

This function checks the validity of a value you specify for a ViString attribute.

Parameter List

instrumentHandle

Variable Type ViSession

The ViSession handle that you obtain from the bu6100_init or bu6100_InitWithOptions function. The handle identifies a particular instrument session.

Default Value: None

channelName

Variable Type ViChar[]

If the attribute is channel-based, this parameter specifies the name of the channel on which to check the attribute value. If the attribute is not channel-based, then pass VI_NULL or an empty string.

Valid Channel Names: 1

Default Value: ""

attributeID

Variable Type ViAttr

Pass the ID of an attribute.

From the function panel window, you can use this control as follows.

- Click on the control or press <ENTER>, <spacebar>, or <ctrl-down arrow>, to display a dialog box containing a hierarchical list of the available attributes. Attributes whose value cannot be set are dim. Help text is shown for each attribute. Select an attribute by double-clicking on it or by selecting it and then pressing <ENTER>.

Read-only attributes appear dim in the list box. If you select a read-only attribute, an error message appears.

A ring control at the top of the dialog box allows you to see all IVI attributes or only the attributes of the ViString type. If you choose to see all IVI attributes, the data types appear to the right of the attribute names in the list box. Attributes with data types other than ViString are dim. If you select an attribute data type that is dim, LabWindows/CVI transfers you to the function panel for the corresponding function that is consistent with the data type.

- If you want to enter a variable name, press <CTRL-T> to change this ring control to a manual input box.
- If the attribute in this ring control has named constants as valid values, you can view the constants by moving to the Attribute Value control and pressing <ENTER>.

attributeValue

Variable Type ViChar[]

Pass the value which you want to verify as a valid value for the attribute.

From the function panel window, you can use this control as follows.

- If the attribute currently showing in the Attribute ID ring control has constants as valid values, you can view a list of the constants by pressing <ENTER> on this control. Select a value by double-clicking on it or by selecting it and then pressing <ENTER>.

Note: Some of the values might not be valid depending on the current settings of the instrument session.

Default Value: none

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.8. bu6100_ClearError

```
ViStatus bu6100_ClearError (ViSession instrumentHandle);
```

Purpose

This function clears the error code and error description for the IVI session. If the user specifies a valid IVI session for the `instrument_handle` parameter, this function clears the error information for the session. If the user passes `VI_NULL` for the `Vi` parameter, this function clears the error information for the current execution thread. If the `Vi` parameter is an invalid session, the function does nothing and returns an error. The function clears the error code by setting it to `VI_SUCCESS`. If the error description string is non-NULL, the function de-allocates the error description string and sets the address to `VI_NULL`.

Maintaining the error information separately for each thread is useful if the user does not have a session handle to pass to the `bu6100_GetError` function, which occurs when a call to `bu6100_init` or `bu6100_InitWithOptions` fails.

Parameter List

`instrumentHandle`

Variable Type `ViSession`

The `ViSession` handle that you obtain from the `bu6100_init` or `bu6100_InitWithOptions` function. The handle identifies a particular instrument session.

Default Value: None

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the `bu6100_error_message` function. To obtain additional information about the error condition, call the `bu6100_GetError` function. To clear the error information from the driver, call the `bu6100_ClearError` function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.9. bu6100_ClearInterchangeWarnings

```
ViStatus bu6100_ClearInterchangeWarnings (ViSession instrumentHandle);
```

Purpose

This function clears the list of current interchange warnings.

Parameter List

instrumentHandle

Variable Type ViSession

The ViSession handle that you obtain from the bu6100_init or bu6100_initWithOptions function. The handle identifies a particular instrument session.

Default Value: None

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.10. bu6100_close

```
ViStatus bu6100_close (ViSession instrumentHandle);
```

Purpose

This function performs the following operations:

- Closes the instrument I/O session.
- Destroys the instrument driver session and all of its attributes.
- Deallocates any memory resources the driver uses.

Notes:

- (1) You must unlock the session before calling bu6100_close.
- (2) After calling bu6100_close, you cannot use the instrument driver again until you call bu6100_init or bu6100_InitWithOptions.

Parameter List

instrumentHandle

Variable Type ViSession

The ViSession handle that you obtain from the bu6100_init or bu6100_InitWithOptions function. The handle identifies a particular instrument session.

Default Value: None

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.11. bu6100_config1588ppp

```
ViStatus bu6100_config1588ppp (ViSession instrumentHandle,
                               ViReal64 startTimeSeconds,
                               ViReal64 startTimeFractional,
                               ViReal64 period);
```

Purpose

This function configures the 1588 pulse-per-period signal. This signal will start at the specified time with the specified period.

Parameter List

instrumentHandle

Variable Type ViSession

The Instrument Handle is used to identify the unique session or communication channel between the driver and the instrument.

If more than one instrument of the same model type is used, this Handle will be used to differentiate between them.

startTimeSeconds

Variable Type ViReal64

Specifies the seconds portion of the 1588 time when the ppp signal should be asserted for the first time.
Default Value: 0.0

startTimeFractional

Variable Type ViReal64

Specifies the fractional portion of the 1588 time when the ppp signal should be asserted for the first time.
Default Value: 0.0

period

Variable Type ViReal64

Specifies the period of the ppp signal in seconds.
Default Value: 500.0E-9 (500 nanoseconds)

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the `bu6100_error_message` function. To obtain additional information about the error condition, call the `bu6100_GetError` function. To clear the error information from the driver, call the `bu6100_ClearError` function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.12. bu6100_configTrig

```
ViStatus bu6100_configTrig (ViSession instrumentHandle,
                           ViInt16 triggerSource,
                           ViInt16 triggerDestination,
                           ViBoolean function);
```

Purpose

Connects/Disconnects two trigger lines specified by the controls Trigger Source and Trigger Output

Parameter List

instrumentHandle

Variable Type ViSession

The Instrument Handle is used to identify the unique session or communication channel between the driver and the instrument.

If more than one instrument of the same model type is used, this Handle will be used to differentiate between them.

triggerSource

Variable Type ViInt16

The source of trigger line.

Any source may be chosen for each of the trigger outputs except that if an attempt is made to select a trigger input for its own output then an error will be returned.

Valid Values:

bu3100_FCTrigOutA1	0	FC 1 Trigger Output A
bu3100_FCTrigOutA2	1	FC 2 Trigger Output A
bu3100_FCTrigOutA3	2	FC 3 Trigger Output A
bu3100_FCTrigOutA4	3	FC 4 Trigger Output A
bu3100_FCTrigOutB1	8	FC 1 Trigger Output B
bu3100_FCTrigOutB2	9	FC 2 Trigger Output B
bu3100_FCTrigOutB3	10	FC 3 Trigger Output B
bu3100_FCTrigOutB4	11	FC 4 Trigger Output B
bu3100_LXITrigIn0	16	LXI Trig In 0
bu3100_LXITrigIn1	17	LXI Trig In 1
bu3100_LXITrigIn2	18	LXI Trig In 2
bu3100_LXITrigIn3	19	LXI Trig In 3
bu3100_LXITrigIn4	20	LXI Trig In 4
bu3100_LXITrigIn5	21	LXI Trig In 5
bu3100_LXITrigIn6	22	LXI Trig In 6
bu3100_LXITrigIn7	23	LXI Trig In 7
bu3100_CLK10	26	CLK10 (10MHz)
bu3100_CLK5	27	CLK10/2 (5MHz)
bu3100_CLK2	28	CLK10/5 (2MHz)
bu3100_IEEE1588_PPP	29	IEEE1588 Pulse Per Period Line
bu3100_IEEE1588_TRG	30	IEEE1588 Trigger Line

triggerDestination

Variable Type ViInt16

Selects the trigger destination.

Valid Values:

bu3100_FCTrigInA1	0	FC 1 Trigger Input A
bu3100_FCTrigInA2	1	FC 2 Trigger Input A
bu3100_FCTrigInA3	2	FC 3 Trigger Input A
bu3100_FCTrigInA4	3	FC 4 Trigger Input A

bu3100_FCTrigInB1	8	FC 1 Trigger Input B
bu3100_FCTrigInB2	9	FC 2 Trigger Input B
bu3100_FCTrigInB3	10	FC 3 Trigger Input B
bu3100_FCTrigInB4	11	FC 4 Trigger Input B
bu3100_LXITrigOut0	16	LXITrig0
bu3100_LXITrigOut1	17	LXITrig1
bu3100_LXITrigOut2	18	LXITrig2
bu3100_LXITrigOut3	19	LXITrig3
bu3100_LXITrigOut4	20	LXITrig4
bu3100_LXITrigOut5	21	LXITrig5
bu3100_LXITrigOut6	22	LXITrig6
bu3100_LXITrigOut7	23	LXITrig7

function

Variable Type ViBoolean

Specifies the operation on selected trigger lines.

Valid Values:

- VI_FALSE (Disconnect)
- VI_TRUE (Connect)

Default Value:

- VI_TRUE (Connect)

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
-----	-----
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types	
-----	-----	-----
3FFA0000 to 3FFA1FFF	IVI	Warnings
3FFF0000 to 3FFFFFFF	VISA	Warnings
3FFC0000 to 3FFCFFFF	VXIPnP	Driver Warnings
BFFA0000 to BFFA1FFF	IVI	Errors
BFFF0000 to BFFFFFFF	VISA	Errors
BFFC0000 to BFFCFFFF	VXIPnP	Driver Errors

5.5.13. bu6100_Disable

```
ViStatus bu6100_Disable (ViSession instrumentHandle);
```

Purpose

This function places the instrument in a quiescent state where it has minimal or no impact on the system to which it is connected.

Parameter List

instrumentHandle

Variable Type ViSession

The ViSession handle that you obtain from the bu6100_init or bu6100_initWithOptions function. The handle identifies a particular instrument session.

Default Value: None

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.14. bu6100_error_message

```
ViStatus bu6100_error_message (ViSession instrumentHandle,
                              ViStatus errorCode,
                              ViChar _VI_FAR errorMessage[]);
```

Purpose

This function converts a status code returned by an instrument driver function into a user-readable string.

Parameter List

instrumentHandle

Variable Type ViSession

The ViSession handle that you obtain from the bu6100_init or bu6100_initWithOptions function. The handle identifies a particular instrument session.

You can pass VI_NULL for this parameter. This is useful when one of the initialize functions fail.

Default Value: VI_NULL

errorCode

Variable Type ViStatus

Pass the Status parameter that is returned from any of the instrument driver functions.

Default Value: 0 (VI_SUCCESS)

errorMessage

Variable Type ViChar[]

Returns the user-readable message string that corresponds to the status code you specify.

You must pass a ViChar array with at least 256 bytes.

Return Value

Reports the status of this operation.

This function can return only three possible status codes:

Status	Description
0	No error (the call was successful).
3FFF0085	Unknown status code (warning).
BFFF000A	Invalid parameter (Error Message buffer is VI_NULL).

5.5.15. bu6100_error_query

```
ViStatus bu6100_error_query (ViSession instrumentHandle,
                             ViPInt32 errorCode,
                             ViChar _VI_FAR errorMessage[]);
```

Purpose

This function reads an error code and a message from the instrument's error queue.

Parameter List

instrumentHandle

Variable Type ViSession

The ViSession handle that you obtain from the bu6100_init or bu6100_initWithOptions function. The handle identifies a particular instrument session.

Default Value: None

errorCode

Variable Type ViInt32 (passed by reference)

Returns the error code read from the instrument's error queue.

errorMessage

Variable Type ViChar[]

Returns the error message string read from the instrument's error message queue.

You must pass a ViChar array with at least 256 bytes.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings

3FFC0000 to 3FFCFFFF	VXIPnP	Driver Warnings
BFFA0000 to BFFA1FFF	IVI	Errors
BFFF0000 to BFFFFFFF	VISA	Errors
BFFC0000 to BFFCFFFF	VXIPnP	Driver Errors

5.5.16. bu6100_fcRead

```
ViStatus bu6100_fcRead (ViSession instrumentHandle, ViInt16 functionCard,
                       ViInt32 offset, ViPInt16 readData);
```

Purpose

Performs a read of single 16-bit word from a Function Card

Parameter List

instrumentHandle

Variable Type ViSession

The Instrument Handle is used to identify the unique session or communication channel between the driver and the instrument.

If more than one instrument of the same model type is used, this Handle will be used to differentiate between them.

functionCard

Variable Type ViInt16

The function card to access.

Valid Values: 1, 2, 3, 4

Default Value: 1

offset

Variable Type ViInt32

Offset within the address space of the Function Card

Default Value: 0x0000

readData

Variable Type ViInt16 (passed by reference)

Value received from the Function Card.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings

3FFC0000 to 3FFCFFFF	VXIPnP	Driver Warnings
BFFA0000 to BFFA1FFF	IVI	Errors
BFFF0000 to BFFFFFFF	VISA	Errors
BFFC0000 to BFFCFFFF	VXIPnP	Driver Errors

5.5.17. bu6100_fcRead32

```
ViStatus bu6100_fcRead32 (ViSession instrumentHandle,
                          ViInt16 functionCards, ViInt32 offset,
                          ViPInt32 readData);
```

Purpose

Performs a read of single 32-bit word from a Function Card

Parameter List

instrumentHandle

Variable Type ViSession

The Instrument Handle is used to identify the unique session or communication channel between the driver and the instrument.

If more than one instrument of the same model type is used, this Handle will be used to differentiate between them.

functionCards

Variable Type ViInt16

The function cards to access.

Valid Values:

FC 1-3	BU6100_FC_1_3	0
FC 2-4	BU6100_FC_2_4	1
FC 1-2	BU6100_FC_1_2	4
FC 3-4	BU6100_FC_3_4	5

In the case of reading from Function Cards 1-3 or 2-4:
The data from the Function Cards 1 and 2 will be placed to lower 16 bit of each 32-bit word of data buffer.
The data from the Function Cards 3 and 4 will be placed to upper 16 bit of each 32-bit word of data buffer.

In the case of reading from Function Cards 1-2 or 3-4:
The data from the Function Cards 1 and 3 will be placed to lower 16 bit of each 32-bit word of data buffer.
The data from the Function Cards 2 and 4 will be placed to upper 16 bit of each 32-bit word of data buffer.

Default Value: 0 (BU6100_FC_1_3)

offset

Variable Type ViInt32

Offset within the address space of the Function Card.

Default Value: 0x0000

readData

Variable Type ViInt32 (passed by reference)

Value received from the Function Card.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the

bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.18. bu6100_fcReadBlock

```
ViStatus bu6100_fcReadBlock (ViSession instrumentHandle,  
                             ViInt16 functionCard, ViInt32 offset,  
                             ViInt32 count, ViInt16 _VI_FAR readData[]);
```

Purpose

Reads a block of 16-bit words from the Function Card.

Parameter List

instrumentHandle

Variable Type ViSession

The Instrument Handle is used to identify the unique session or communication channel between the driver and the instrument.

If more than one instrument of the same model type is used, this Handle will be used to differentiate between them.

functionCard

Variable Type ViInt16

The function card to access.

Valid Values: 1, 2, 3, 4

Default Value: 1

offset

Variable Type ViInt32

Starting address of Function Card Memory / Address of FIFO register within the address space of the Function Card.

Default Value: 0x0000

count

Variable Type ViInt32

Number of elements of data (16-bit words) to read from the specified Function Card. If count is greater than 1 the function performs block read.

Default Value: 1

readData

Variable Type ViInt16[]

An array to receive the block of data read from the Function Card.

This array must be declared at least as large as the number of elements to be read from the instrument - failure to do so may result in a system failure.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.19. bu6100_fcReadBlock32

```
ViStatus bu6100_fcReadBlock32 (ViSession instrumentHandle,
                               ViInt16 functionCards, ViInt32 offset,
                               ViInt32 count,
                               ViInt32 _VI_FAR readData32[]);
```

Purpose

Reads a block of 32-bit words from two Function Cards.

Parameter List

instrumentHandle

Variable Type ViSession

The Instrument Handle is used to identify the unique session or communication channel between the driver and the instrument.

If more than one instrument of the same model type is used, this Handle will be used to differentiate between them.

functionCards

Variable Type ViInt16

The function cards to access.

Valid Values:

FC 1-3	BU6100_FC_1_3	0
FC 2-4	BU6100_FC_2_4	1
FC 1-2	BU6100_FC_1_2	4
FC 3-4	BU6100_FC_3_4	5

In the case of reading from Function Cards 1-3 or 2-4:

The data from the Function Cards 1 and 2 will be placed to lower 16 bit of each 32-bit word of data buffer.

The data from the Function Cards 3 and 4 will be placed to upper 16 bit of each 32-bit word of data buffer.

In the case of reading from Function Cards 1-2 or 3-4:

The data from the Function Cards 1 and 3 will be placed to lower 16 bit of each 32-bit word of data buffer.

The data from the Function Cards 2 and 4 will be placed to upper 16 bit of each 32-bit word of data buffer.

Default Value: 0 (BU6100_FC_1_3)

offset

Variable Type ViInt32

Starting address of Function Card Memory / Address of FIFO register within the address space of the Function Card. The same offset will be used for both Function Cards.

Default Value: 0x0000

count

Variable Type ViInt32

Number of elements of data to read from the specified Function Cards.

This number of 16-bit elements will be read from each function card. And this number of 32-bit elements will be placed in the read buffer upon successive completion of the function call.

Default Value: 1

readData32

Variable Type ViInt32[]

An array to read the block of data from the Function Cards.

Lower 16 bit in each 32-bit word in this buffer will contain the data from the first function card (Function Card 1).

Upper 16 bit in each 32-bit word in this buffer will contain the data from the second function card (Function Card 2).

This array must be declared at least as large as the number of elements to be read from the instrument - failure to do so may result in a system failure.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the `bu6100_error_message` function. To obtain additional information about the error condition, call the `bu6100_GetError` function. To clear the error information from the driver, call the `bu6100_ClearError` function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.20. bu6100_fcReadBlock64

```
ViStatus bu6100_fcReadBlock64 (ViSession instrumentHandle,  
                               ViInt32 offset, ViInt32 count,  
                               ViInt32 _VI_FAR readData64[]);
```

Purpose

Reads a block of 64-bit words from four Function Cards.
The data from Function Card 1 will be placed to bits 0-15;
The data from Function Card 2 will be placed to bits 16-31;
The data from Function Card 3 will be placed to bits 32-47;
The data from Function Card 4 will be placed to bits 48-63;

Parameter List

instrumentHandle

Variable Type ViSession

The Instrument Handle is used to identify the unique session or communication channel between the driver and the instrument.

If more than one instrument of the same model type is used, this Handle will be used to differentiate between them.

offset

Variable Type ViInt32

Starting address of Function Card Memory / Address of FIFO register within the address space of the Function Card. The same offset will be used for both Function Cards.

Default Value: 0x0000

count

Variable Type ViInt32

Number of 64-bit elements of data to read from the specified Function Cards.

Default Value: 1

readData64

Variable Type ViInt32[]

An array to read the block of data from the Function Cards.

In the case of reading from the Function Cards 1, 3, 5, 7 or 2, 4, 6, 8 data will be arranged in the following way:

FC1, FC2 - First word, lower 16 bit;
FC3, FC4 - First word, upper 16 bit;
FC5, FC6 - Second word, lower 16 bit;
FC7, FC8 - Second word, upper 16 bit;

In the case of reading from the Function Cards 1, 2, 3, 4 or 5, 6, 7, 8 data will be placed in the following way:

FC1, FC5 - First word, lower 16 bit;
FC2, FC6 - First word, upper 16 bit;
FC3, FC7 - Second word, lower 16 bit;
FC4, FC8 - Second word, upper 16 bit;

This array must be declared at least as large as the double number of 64-bit elements to be read from the instrument (Count*2) - failure to do so may result in a system failure.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the `bu6100_error_message` function. To obtain additional information about the error condition, call the `bu6100_GetError` function. To clear the error information from the driver, call the `bu6100_ClearError` function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.21. bu6100_fcReset

```
ViStatus bu6100_fcReset (ViSession instrumentHandle,
                        ViInt16 functionCardMask, ViInt16 function);
```

Purpose

Reset the function cards at the selected locations.

Parameter List

instrumentHandle

Variable Type ViSession

The Instrument Handle is used to identify the unique session or communication channel between the driver and the instrument.

If more than one instrument of the same model type is used, this Handle will be used to differentiate between them.

functionCardMask

Variable Type ViInt16

Specifies the Function Cards to reset.

Bit 0 corresponds to FC 1

.....

Bit 3 corresponds to FC 4

"1" written to appropriate bit means that function card should be reset.

Default Value: 0

function

Variable Type ViInt16

Specifies which action will be taken on Function Card Reset lines.

Valid Values:

BU6100_RESET_DEASSERT	0	De-asserts reset lines previously asserted by fcReset(vi, fcMask, bu3100_RESET_ASSERT) function call. After de-asserting reset lines the program should wait at least bu3100_FC_RESET_WAIT seconds before any access to the function cards.
BU6100_RESET_ASSERT	1	Asserts the reset lines on the selected function cards. The reset lines should be de-asserted later by function call fcReset(vi, fcMask, bu3100_RESET_DEASSERT) The program should wait at least bu3100_FC_RESET_DOWN seconds before de-assert the reset lines.
BU6100_RESET_PULSE	2	Performs complete reset cycle on the selected function cards: Asserts reset lines, waits bu3100_FC_RESET_DOWN seconds, de-asserts reset lines, and then waits bu3100_FC_RESET_WAIT seconds.

Default Value: 0 (BU6100_RESET_DEASSERT)

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the `bu6100_error_message` function. To obtain additional information about the error condition, call the `bu6100_GetError` function. To clear the error information from the driver, call the `bu6100_ClearError` function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.22. bu6100_fcWrite

```
ViStatus bu6100_fcWrite (ViSession instrumentHandle,
                        ViInt16 functionCard, ViInt32 offset,
                        ViInt16 writeData);
```

Purpose

Writes a single 16-bit word to the Function Card.

Parameter List

instrumentHandle

Variable Type ViSession

The Instrument Handle is used to identify the unique session or communication channel between the driver and the instrument.

If more than one instrument of the same model type is used, this Handle will be used to differentiate between them.

functionCard

Variable Type ViInt16

The function card to access.

Valid Values: 1, 2, 3, 4

Default Value: 1

offset

Variable Type ViInt32

Offset within the address space of the Function Card.

Default Value: 0x0000

writeData

Variable Type ViInt16

16-bit word of data to be written to the specified function card

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.23. bu6100_fcWrite32

```
ViStatus bu6100_fcWrite32 (ViSession instrumentHandle,
                          ViInt16 functionCards, ViInt32 offset,
                          ViInt32 writeData);
```

Purpose

Writes a single 32-bit word to the Function Card.

Parameter List

instrumentHandle

Variable Type ViSession

The Instrument Handle is used to identify the unique session or communication channel between the driver and the instrument.

If more than one instrument of the same model type is used, this Handle will be used to differentiate between them.

functionCards

Variable Type ViInt16

The function cards to access.

Valid Values:

FC 1-3	BU6100_FC_1_3	0
FC 2-4	BU6100_FC_2_4	1
FC 1-2	BU6100_FC_1_2	4
FC 3-4	BU6100_FC_3_4	5

In the case of writing to Function Cards 1-3 or 2-4:

The lower 16 bit of data will be placed to the Function Cards 1 and 2.

The upper 16 bit of data will be placed to the Function Cards 3 and 4.

In the case of writing to Function Cards 1-2 or 3-4:

The lower 16 bit of data will be placed to the Function Cards 1 and 3.

The upper 16 bit of data will be placed to the Function Cards 2 and 4.

Default Value: 0 (BU6100_FC_1_3)

offset

Variable Type ViInt32

Offset within the address space of the Function Card.

Default Value: 0x0000

writeData

Variable Type ViInt32

32-bit word of data to be written to the specified function card

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.24. bu6100_fcWriteBcast

```
ViStatus bu6100_fcWriteBcast (ViSession instrumentHandle,
                             ViInt16 functionCardMask, ViInt32 offset,
                             ViInt16 writeData);
```

Purpose

Simultaneously writes a single 16-bit word to multiple Function Cards.

Parameter List

instrumentHandle

Variable Type ViSession

The Instrument Handle is used to identify the unique session or communication channel between the driver and the instrument.

If more than one instrument of the same model type is used, this Handle will be used to differentiate between them.

functionCardMask

Variable Type ViInt16

Specifies to which Function Cards Data will be written.

Bit 0 corresponds to Function Card 1
 ...
 Bit 3 corresponds to Function Card 4

Default Value: 0

offset

Variable Type ViInt32

Offset within the address space of each Function Card.

Default Value: 0x0000

writeData

Variable Type ViInt16

16-bit word of data to be written to all specified Function Cards.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.25. bu6100_fcWriteBlock

```
ViStatus bu6100_fcWriteBlock (ViSession instrumentHandle,  
                             ViInt16 functionCard, ViInt32 offset,  
                             ViInt32 count,  
                             ViInt16 _VI_FAR writeData[]);
```

Purpose

Writes a block of 16-bit words to the Function Card.

Parameter List

instrumentHandle

Variable Type ViSession

The Instrument Handle is used to identify the unique session or communication channel between the driver and the instrument.

If more than one instrument of the same model type is used, this Handle will be used to differentiate between them.

functionCard

Variable Type ViInt16

The function card to access.

Valid Values: 1, 2, 3, 4

Default Value: 1

offset

Variable Type ViInt32

Starting address of Function Card Memory / Address of FIFO register within the address space of the Function Card.

Default Value: 0x0000

count

Variable Type ViInt32

Number of elements of data to write to the specified Function Card. If count is greater than 1 the function performs block write.

Default Value: 1

writeData

Variable Type ViInt16[]

An array to write the block of data read to the Function Card.

This array must be declared at least as large as the number of elements to be written to the instrument - failure to do so may result in a system failure.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.26. bu6100_fcWriteBlock32

```
ViStatus bu6100_fcWriteBlock32 (ViSession instrumentHandle,
                                ViInt16 functionCards, ViInt32 offset,
                                ViInt32 count,
                                ViInt32 _VI_FAR writeData32[]);
```

Purpose

Writes a block of 32-bit words to two Function Cards.

Parameter List

instrumentHandle

Variable Type ViSession

The Instrument Handle is used to identify the unique session or communication channel between the driver and the instrument.

If more than one instrument of the same model type is used, this Handle will be used to differentiate between them.

functionCards

Variable Type ViInt16

The function cards to access.

Valid Values:

FC 1-3	BU6100_FC_1_3	0
FC 2-4	BU6100_FC_2_4	1
FC 1-2	BU6100_FC_1_2	4
FC 3-4	BU6100_FC_3_4	5

In the case of writing to Function Cards 1-3 or 2-4:
The lower 16 bit of data will be placed to the Function Cards 1 and 2.
The upper 16 bit of data will be placed to the Function Cards 3 and 4.

In the case of writing to Function Cards 1-2 or 3-4:
The lower 16 bit of data will be placed to the Function Cards 1 and 3.
The upper 16 bit of data will be placed to the Function Cards 2 and 4.

Default Value: 0 (BU6100_FC_1_3)

offset

Variable Type ViInt32

Starting address of Function Card Memory / Address of FIFO register within the address space of the Function Card. The same offset will be used for both Function Cards.

Default Value: 0x0000

count

Variable Type ViInt32

Number of elements of data to write to the specified Function Cards. This control specifies the number of 32-bit elements in the write buffer. Each function card will get this number of 16-bit elements.

Default Value: 1

writeData32

Variable Type ViInt32[]

An array to write the block of data read to the Function Card.

Lower 16 bit in each 32-bit word in this buffer should contain the data for the first function card (Function Card 1).
Upper 16 bit in each 32-bit word in this buffer should contain the data for the second function card (Function Card 2).

This array must be declared at least as large as the number of elements to be written to the instrument - failure to do so may result in a system failure.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the `bu6100_error_message` function. To obtain additional information about the error condition, call the `bu6100_GetError` function. To clear the error information from the driver, call the `bu6100_ClearError` function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.27. bu6100_fcWriteBlock64

```
ViStatus bu6100_fcWriteBlock64 (ViSession instrumentHandle,
                                ViInt32 offset, ViInt32 count,
                                ViInt32 _VI_FAR writeData64[]);
```

Purpose

Writes a block of 32-bit words to two Function Cards.
 The data from Function Card 1 will be placed to bits 0-15;
 The data from Function Card 2 will be placed to bits 16-31;
 The data from Function Card 3 will be placed to bits 32-47;
 The data from Function Card 4 will be placed to bits 48-63;

Parameter List

instrumentHandle

Variable Type ViSession

The Instrument Handle is used to identify the unique session or communication channel between the driver and the instrument.

If more than one instrument of the same model type is used, this Handle will be used to differentiate between them.

offset

Variable Type ViInt32

Starting address of Function Card Memory / Address of FIFO register within the address space of the Function Card. The same offset will be used for both Function Cards.

Default Value: 0x0000

count

Variable Type ViInt32

Number of elements of data to write to the specified Function Cards. This control specifies the number of 64-bit elements in the write buffer. Each function card will get this number of 16-bit elements.

Default Value: 1

writeData64

Variable Type ViInt32[]

An array to write the block of data read to the Function Card.

In the case of writing to the Function Cards 1, 3, 5, 7 or 2, 4, 6, 8 data should be arranged in the following way:

FC1, FC2 - First word, lower 16 bit;
 FC3, FC4 - First word, upper 16 bit;
 FC5, FC6 - Second word, lower 16 bit;
 FC7, FC8 - Second word, upper 16 bit;

In the case of writing to the Function Cards 1, 2, 3, 4 or 5, 6, 7, 8 data should be placed in the following way:

FC1, FC5 - First word, lower 16 bit;
 FC2, FC6 - First word, upper 16 bit;
 FC3, FC7 - Second word, lower 16 bit;
 FC4, FC8 - Second word, upper 16 bit;

This array must be declared at least as large as the double number of 64-bit elements to be read from the instrument (Count*2) - failure to do so may result in a system failure.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver

function to determine if an error occurred.

To obtain a text description of the status code, call the `bu6100_error_message` function. To obtain additional information about the error condition, call the `bu6100_GetError` function. To clear the error information from the driver, call the `bu6100_ClearError` function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.28. bu6100_freeDram

```
ViStatus bu6100_freeDram (ViSession instrumentHandle, ViInt32 offset);
```

Purpose

Deallocates the DRAM segment previously allocated by allocDRAM function

Parameter List

instrumentHandle

Variable Type ViSession

The Instrument Handle is used to identify the unique session or communication channel between the driver and the instrument.

If more than one instrument of the same model type is used, this Handle will be used to differentiate between them.

offset

Variable Type ViInt32

Selects the offset of the memory segment within the DRAM to be deallocated

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.29. bu6100_get1588config

```
ViStatus bu6100_get1588config (ViSession instrumentHandle,
                               ViPInt32 enabled, ViPInt32 threshold,
                               ViPInt32 clock_divider, ViPInt32 pid_p,
                               ViPInt32 pid_i, ViPInt32 pid_d);
```

Purpose

This function returns the configuration of the 1588 interface of the ProDAQ 6100 module.

Parameter List

instrumentHandle

Variable Type ViSession

The Instrument Handle is used to identify the unique session or communication channel between the driver and the instrument.

If more than one instrument of the same model type is used, this Handle will be used to differentiate between them.

enabled

Variable Type ViInt32 (passed by reference)

This parameter returns whether the 1588 interface of the ProDAQ 6100 module is disabled, enabled or enabled in slave-only mode. In the slave-only mode the 6100 will never take a role of the 1588 clock master.

Possible values are:

BU6100_1588_DISABLED	0	1588 interface is disabled;
BU6100_1588_ENABLED	1	1588 interface is enabled;
BU6100_1588_ENABLED_SLAVE_ONLY	2	1588 interface is enabled as a slave-only device;

threshold

Variable Type ViInt32 (passed by reference)

This parameter returns the synchronization threshold (in nanoseconds). It is used when the 6100 module operates as a 1588 slave device. If the offset from the 1588 Master is less than the specified threshold, the module is considered as synchronized. If the offset is bigger than the threshold, the module status will be "not synchronized".

clock_divider

Variable Type ViInt32 (passed by reference)

This parameter returns the content of the TCLK divider of the 1588 interface.

pid_p

Variable Type ViInt32 (passed by reference)

This parameter returns the 'p' coefficient of the PTP PID control loop.

pid_i

Variable Type ViInt32 (passed by reference)

This parameter returns the 'i' coefficient of the PTP PID control loop.

pid_d

Variable Type ViInt32 (passed by reference)

This parameter returns the 'd' coefficient of the PTP PID control loop.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the `bu6100_error_message` function. To obtain additional information about the error condition, call the `bu6100_GetError` function. To clear the error information from the driver, call the `bu6100_ClearError` function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.30. bu6100_get1588status

```
ViStatus bu6100_get1588status (ViSession instrumentHandle,
                               ViPInt32 port_state,
                               ViChar _VI_FAR parent_uuid[],
                               ViChar _VI_FAR grandmaster_uuid[],
                               ViChar _VI_FAR grandmasterTraceability[],
                               ViChar _VI_FAR subdomain[],
                               ViPInt32 variance);
```

Purpose

This function returns the status of the 1588 interface of the ProDAQ 6100 module.

Parameter List

instrumentHandle

Variable Type ViSession

The Instrument Handle is used to identify the unique session or communication channel between the driver and the instrument.

If more than one instrument of the same model type is used, this Handle will be used to differentiate between them.

port_state

Variable Type ViInt32 (passed by reference)

This parameter returns the state of the 1588 port. Possible values are:

BU6100_1588_PORT_INITIALIZING	0
BU6100_1588_PORT_FAULTY	1
BU6100_1588_PORT_DISABLED	2
BU6100_1588_PORT_LISTENING	3
BU6100_1588_PORT_PRE_MASTER	4
BU6100_1588_PORT_MASTER	5
BU6100_1588_PORT_PASSIVE	6
BU6100_1588_PORT_UNCALIBRATED	7
BU6100_1588_PORT_SLAVE_SYNC	8
BU6100_1588_PORT_SLAVE_NOT_SYNCH	9

parent_uuid

Variable Type ViChar[]

This parameter returns the parent 6-bytes mac address string in the format: xx:xx:xx:xx:xx:xx. The buffer should be allocated prior to the function call with the appropriate size. This parameter can be NULL pointer.

grandmaster_uuid

Variable Type ViChar[]

This parameter returns the grandmaster 6-bytes mac address string in the format: xx:xx:xx:xx:xx:xx. The buffer should be allocated prior to the function call with the appropriate size. This parameter can be NULL pointer.

grandmasterTraceability

Variable Type ViChar[]

This parameter returns the current grandmaster traceability to UTC: GPS, NTP, HAND or ATOM (Vendors can define others).

subdomain

Variable Type ViChar[]

This parameter returns the current subdomain name: `_DFLT`, `_ALT1`, `_ALT2...` and so on.

variance

Variable Type ViInt32 (passed by reference)

This parameter returns the current observed variance of the parent clock (in ns).

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the `bu6100_error_message` function. To obtain additional information about the error condition, call the `bu6100_GetError` function. To clear the error information from the driver, call the `bu6100_ClearError` function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.31. bu6100_get1588timing

```
ViStatus bu6100_get1588timing (ViSession instrumentHandle,
                             ViPReal64 PTP_time,
                             ViChar _VI_FAR localTime[],
                             ViPReal64 mastertoSlave_delay,
                             ViPReal64 slavetoMaster_delay,
                             ViPReal64 oneWay_delay,
                             ViPReal64 offset_from_master,
                             ViPReal64 observed_drift);
```

Purpose

This function returns the values of various timing parameters of 1588 synchronization.

Parameter List

instrumentHandle

Variable Type ViSession

The Instrument Handle is used to identify the unique session or communication channel between the driver and the instrument.

If more than one instrument of the same model type is used, this Handle will be used to differentiate between them.

PTP_time

Variable Type ViReal64 (passed by reference)

This parameter returns the current PTP time in seconds since January 1, 1970.

localTime

Variable Type ViChar[]

Returns the current local date/time in 24-character UNIX-format.

mastertoSlave_delay

Variable Type ViReal64 (passed by reference)

Returns the master-to-slave delay in seconds. This value is valid only when the board operates as a PTP slave.

slavetoMaster_delay

Variable Type ViReal64 (passed by reference)

Returns the slave-to-master delay in seconds. This value is valid only when the board operates as a PTP slave.

oneWay_delay

Variable Type ViReal64 (passed by reference)

Returns the one-way delay in seconds. This value is valid only when the board operates as a PTP slave.

offset_from_master

Variable Type ViReal64 (passed by reference)

Returns the offset from master in seconds. This value is valid only when the board operates as a PTP slave.

observed_drift

Variable Type ViReal64 (passed by reference)

Returns the observed clock drift in seconds. This value is valid only

when the board operates as a PTP slave.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the `bu6100_error_message` function. To obtain additional information about the error condition, call the `bu6100_GetError` function. To clear the error information from the driver, call the `bu6100_ClearError` function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.32. bu6100_GetAttributeViBoolean

```
ViStatus bu6100_GetAttributeViBoolean (ViSession instrumentHandle,
                                       ViChar _VI_FAR channelName[],
                                       ViAttr attributeID,
                                       ViPBoolean attributeValue);
```

Purpose

This function queries the value of a ViBoolean attribute.

You can use this function to get the values of instrument- specific attributes and inherent IVI attributes. If the attribute represents an instrument state, this function performs instrument I/O in the following cases:

- State caching is disabled for the entire session or for the particular attribute.
- State caching is enabled and the currently cached value is invalid.

Parameter List

instrumentHandle

Variable Type ViSession

The ViSession handle that you obtain from the bu6100_init or bu6100_InitWithOptions function. The handle identifies a particular instrument session.

Default Value: None

channelName

Variable Type ViChar[]

If the attribute is channel-based, this parameter specifies the name of the channel on which to obtain the value of the attribute. If the attribute is not channel-based, then pass VI_NULL or an empty string.

Valid Channel Names: 1

Default Value: ""

attributeID

Variable Type ViAttr

Pass the ID of an attribute.

From the function panel window, you can use this control as follows.

- Click on the control or press <ENTER>, <spacebar>, or <ctrl-down arrow>, to display a dialog box containing a hierarchical list of the available attributes. Help text is shown for each attribute. Select an attribute by double-clicking on it or by selecting it and then pressing <ENTER>.

A ring control at the top of the dialog box allows you to see all IVI attributes or only the attributes of the ViBoolean type. If you choose to see all IVI attributes, the data types appear to the right of the attribute names in the list box. Attributes with data types other than ViBoolean are dim. If you select an attribute data type that is dim, LabWindows/CVI transfers you to the function panel for the corresponding function that is consistent with the data type.

- If you want to enter a variable name, press <CTRL-T> to change this ring control to a manual input box.

- If the attribute in this ring control has named constants as valid values, you can view the constants by moving to the Attribute Value control and pressing <ENTER>.

attributeValue

Variable Type ViBoolean (passed by reference)

Returns the current value of the attribute. Pass the address of a ViBoolean variable.

From the function panel window, you can use this control as follows.

- If the attribute currently showing in the Attribute ID ring control has named constants as valid values, you can view a list of the constants by pressing <ENTER> on this control. Select a value by double-clicking on it or by selecting it and then pressing <ENTER>.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.33. bu6100_GetAttributeViInt32

```
ViStatus bu6100_GetAttributeViInt32 (ViSession instrumentHandle,
                                     ViChar _VI_FAR channelName[],
                                     ViAttr attributeID,
                                     ViPInt32 attributeValue);
```

Purpose

This function queries the value of a ViInt32 attribute.

You can use this function to get the values of instrument- specific attributes and inherent IVI attributes. If the attribute represents an instrument state, this function performs instrument I/O in the following cases:

- State caching is disabled for the entire session or for the particular attribute.
- State caching is enabled and the currently cached value is invalid.

Parameter List

instrumentHandle

Variable Type ViSession

The ViSession handle that you obtain from the bu6100_init or bu6100_InitWithOptions function. The handle identifies a particular instrument session.

Default Value: None

channelName

Variable Type ViChar[]

If the attribute is channel-based, this parameter specifies the name of the channel on which to obtain the value of the attribute. If the attribute is not channel-based, then pass VI_NULL or an empty string.

Valid Channel Names: 1

Default Value: ""

attributeID

Variable Type ViAttr

Pass the ID of an attribute.

From the function panel window, you can use this control as follows.

- Click on the control or press <ENTER>, <spacebar>, or <ctrl-down arrow>, to display a dialog box containing a hierarchical list of the available attributes. Help text is shown for each attribute. Select an attribute by double-clicking on it or by selecting it and then pressing <ENTER>.

A ring control at the top of the dialog box allows you to see all IVI attributes or only the attributes of the ViInt32 type. If you choose to see all IVI attributes, the data types appear to the right of the attribute names in the list box. Attributes with data types other than ViInt32 are dim. If you select an attribute data type that is dim, LabWindows/CVI transfers you to the function panel for the corresponding function that is consistent with the data type.

- If you want to enter a variable name, press <CTRL-T> to change this ring control to a manual input box.

- If the attribute in this ring control has named constants as valid values, you can view the constants by moving to the Attribute Value control and pressing <ENTER>.

attributeValue

Variable Type ViInt32 (passed by reference)

Returns the current value of the attribute. Pass the address of a ViInt32 variable.

From the function panel window, you can use this control as follows.

- If the attribute currently showing in the Attribute ID ring control has named constants as valid values, you can view a list of the constants by pressing <ENTER> on this control. Select a value by double-clicking on it or by selecting it and then pressing <ENTER>.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.34. bu6100_GetAttributeViReal64

```
ViStatus bu6100_GetAttributeViReal64 (ViSession instrumentHandle,
                                     ViChar _VI_FAR channelName[],
                                     ViAttr attributeID,
                                     ViPReal64 attributeValue);
```

Purpose

This function queries the value of a ViReal64 attribute.

You can use this function to get the values of instrument- specific attributes and inherent IVI attributes. If the attribute represents an instrument state, this function performs instrument I/O in the following cases:

- State caching is disabled for the entire session or for the particular attribute.
- State caching is enabled and the currently cached value is invalid.

Parameter List

instrumentHandle

Variable Type ViSession

The ViSession handle that you obtain from the bu6100_init or bu6100_InitWithOptions function. The handle identifies a particular instrument session.

Default Value: None

channelName

Variable Type ViChar[]

If the attribute is channel-based, this parameter specifies the name of the channel on which to obtain the value of the attribute. If the attribute is not channel-based, then pass VI_NULL or an empty string.

Valid Channel Names: 1

Default Value: ""

attributeID

Variable Type ViAttr

Pass the ID of an attribute.

From the function panel window, you can use this control as follows.

- Click on the control or press <ENTER>, <spacebar>, or <ctrl-down arrow>, to display a dialog box containing a hierarchical list of the available attributes. Help text is shown for each attribute. Select an attribute by double-clicking on it or by selecting it and then pressing <ENTER>.

A ring control at the top of the dialog box allows you to see all IVI attributes or only the attributes of the ViReal64 type. If you choose to see all IVI attributes, the data types appear to the right of the attribute names in the list box. Attributes with data types other than ViReal64 are dim. If you select an attribute data type that is dim, LabWindows/CVI transfers you to the function panel for the corresponding function that is consistent with the data type.

- If you want to enter a variable name, press <CTRL-T> to change this ring control to a manual input box.

- If the attribute in this ring control has named constants as valid values, you can view the constants by moving to the Attribute Value control and pressing <ENTER>.

attributeValue

Variable Type ViReal64 (passed by reference)

Returns the current value of the attribute. Pass the address of a ViReal64 variable.

From the function panel window, you can use this control as follows.

- If the attribute currently showing in the Attribute ID ring control has named constants as valid values, you can view a list of the constants by pressing <ENTER> on this control. Select a value by double-clicking on it or by selecting it and then pressing <ENTER>.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.35. bu6100_GetAttributeViSession

```
ViStatus bu6100_GetAttributeViSession (ViSession instrumentHandle,
                                       ViChar _VI_FAR channelName[],
                                       ViAttr attributeID,
                                       ViPSession attributeValue);
```

Purpose

This function queries the value of a ViSession attribute.

You can use this function to get the values of instrument- specific attributes and inherent IVI attributes. If the attribute represents an instrument state, this function performs instrument I/O in the following cases:

- State caching is disabled for the entire session or for the particular attribute.
- State caching is enabled and the currently cached value is invalid.

Parameter List

instrumentHandle

Variable Type ViSession

The ViSession handle that you obtain from the bu6100_init or bu6100_InitWithOptions function. The handle identifies a particular instrument session.

Default Value: None

channelName

Variable Type ViChar[]

If the attribute is channel-based, this parameter specifies the name of the channel on which to obtain the value of the attribute. If the attribute is not channel-based, then pass VI_NULL or an empty string.

Valid Channel Names: 1

Default Value: ""

attributeID

Variable Type ViAttr

Pass the ID of an attribute.

From the function panel window, you can use this control as follows.

- Click on the control or press <ENTER>, <spacebar>, or <ctrl-down arrow>, to display a dialog box containing a hierarchical list of the available attributes. Help text is shown for each attribute. Select an attribute by double-clicking on it or by selecting it and then pressing <ENTER>.

A ring control at the top of the dialog box allows you to see all IVI attributes or only the attributes of the ViSession type. If you choose to see all IVI attributes, the data types appear to the right of the attribute names in the list box. Attributes with data types other than ViSession are dim. If you select an attribute data type that is dim, LabWindows/CVI transfers you to the function panel for the corresponding function that is consistent with the data type.

- If you want to enter a variable name, press <CTRL-T> to change this ring control to a manual input box.

- If the attribute in this ring control has named constants as valid values, you can view the constants by moving to the Attribute Value control and pressing <ENTER>.

attributeValue

Variable Type ViSession (passed by reference)

Returns the current value of the attribute. Pass the address of a ViSession variable.

From the function panel window, you can use this control as follows.

- If the attribute currently showing in the Attribute ID ring control has named constants as valid values, you can view a list of the constants by pressing <ENTER> on this control. Select a value by double-clicking on it or by selecting it and then pressing <ENTER>.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.36. bu6100_GetAttributeViString

```
ViStatus bu6100_GetAttributeViString (ViSession instrumentHandle,
ViChar _VI_FAR channelName[],
ViAttr attributeID,
ViInt32 bufferSize,
ViChar _VI_FAR attributeValue[]);
```

Purpose

This function queries the value of a ViString attribute.

You can use this function to get the values of instrument- specific attributes and inherent IVI attributes. If the attribute represents an instrument state, this function performs instrument I/O in the following cases:

- State caching is disabled for the entire session or for the particular attribute.
- State caching is enabled and the currently cached value is invalid.

You must provide a ViChar array to serve as a buffer for the value. You pass the number of bytes in the buffer as the Buffer Size parameter. If the current value of the attribute, including the terminating NUL byte, is larger than the size you indicate in the Buffer Size parameter, the function copies Buffer Size - 1 bytes into the buffer, places an ASCII NUL byte at the end of the buffer, and returns the buffer size you must pass to get the entire value. For example, if the value is "123456" and the Buffer Size is 4, the function places "123" into the buffer and returns 7.

If you want to call this function just to get the required buffer size, you can pass 0 for the Buffer Size and VI_NULL for the Attribute Value buffer.

If you want the function to fill in the buffer regardless of the number of bytes in the value, pass a negative number for the Buffer Size parameter.

Parameter List

instrumentHandle

Variable Type ViSession

The ViSession handle that you obtain from the bu6100_init or bu6100_InitWithOptions function. The handle identifies a particular instrument session.

Default Value: None

channelName

Variable Type ViChar[]

If the attribute is channel-based, this parameter specifies the name of the channel on which to obtain the value of the attribute. If the attribute is not channel-based, then pass VI_NULL or an empty string.

Valid Channel Names: 1

Default Value: ""

attributeID

Variable Type ViAttr

Pass the ID of an attribute.

From the function panel window, you can use this control as follows.

- Click on the control or press <ENTER>, <spacebar>, or <ctrl-down arrow>, to display a dialog box containing a hierarchical list of the available attributes. Help text is shown for each attribute. Select an attribute by double-clicking on it or by selecting it and then pressing <ENTER>.

A ring control at the top of the dialog box allows you to see all IVI attributes or only the attributes of the ViString type. If you choose to see all IVI attributes, the data types appear to the right of the attribute names in the list box. Attributes with data types other than ViString are dim. If you select an attribute data type that is dim, LabWindows/CVI transfers you to the function panel for the corresponding function that is consistent with the data type.

- If you want to enter a variable name, press <CTRL-T> to change this ring control to a manual input box.
- If the attribute in this ring control has named constants as valid values, you can view the constants by moving to the Attribute Value control and pressing <ENTER>.

bufferSize

Variable Type ViInt32

Pass the number of bytes in the ViChar array you specify for the Attribute Value parameter.

If the current value of the attribute, including the terminating NUL byte, contains more bytes than you indicate in this parameter, the function copies Buffer Size - 1 bytes into the buffer, places an ASCII NUL byte at the end of the buffer, and returns the buffer size you must pass to get the entire value. For example, if the value is "123456" and the Buffer Size is 4, the function places "123" into the buffer and returns 7.

If you pass a negative number, the function copies the value to the buffer regardless of the number of bytes in the value.

If you pass 0, you can pass VI_NULL for the Attribute Value buffer parameter.

Default Value: 512

attributeValue

Variable Type ViChar[]

The buffer in which the function returns the current value of the attribute. The buffer must be of type ViChar and have at least as many bytes as indicated in the Buffer Size parameter.

If the current value of the attribute, including the terminating NUL byte, contains more bytes than you indicate in this parameter, the function copies Buffer Size - 1 bytes into the buffer, places an ASCII NUL byte at the end of the buffer, and returns the buffer size you must pass to get the entire value. For example, if the value is "123456" and the Buffer Size is 4, the function places "123" into the buffer and returns 7.

If you specify 0 for the Buffer Size parameter, you can pass VI_NULL for this parameter.

From the function panel window, you can use this control as follows.

- If the attribute currently showing in the Attribute ID ring control has named constants as valid values, you can view a list of the constants by pressing <ENTER> on this control. Select a value by double-clicking on it or by selecting it and then pressing <ENTER>.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the `bu6100_error_message` function. To obtain additional information about the error condition, call the `bu6100_GetError` function. To clear the error information from the driver, call the `bu6100_ClearError` function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.37. bu6100_getCBstatus

```
ViStatus bu6100_getCBstatus (ViSession instrumentHandle,
                             ViInt16 functionCard, ViPInt32 n_ofSamples,
                             ViPBoolean overflow);
```

Purpose

This function returns the current status of the Circular Buffer for particular Function Card.

Parameter List

instrumentHandle

Variable Type ViSession

The Instrument Handle is used to identify the unique session or communication channel between the driver and the instrument.

If more than one instrument of the same model type is used, this Handle will be used to differentiate between them.

functionCard

Variable Type ViInt16

Specifies the Function Card for which the Circular Buffer will be configured.

Valid Values: 1, 2, 3, 4

Default Value: 1

n_ofSamples

Variable Type ViInt32 (passed by reference)

This parameter returns the number of 32-bit words currently stored in the Circular Buffer.

overflow

Variable Type ViBoolean (passed by reference)

This parameter tells whether overflow of the Circular Buffer happened.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.38. bu6100_getConfigCB

```
ViStatus bu6100_getConfigCB (ViSession instrumentHandle,
                             ViInt16 functionCard, ViPInt32 function,
                             ViPInt32 FIFOAddress, ViPInt32 address,
                             ViPInt32 length, ViPInt32 threshold);
```

Purpose

This function returns the configuration of the Circular Buffer for particular Function Card.

Parameter List

instrumentHandle

Variable Type ViSession

The Instrument Handle is used to identify the unique session or communication channel between the driver and the instrument.

If more than one instrument of the same model type is used, this Handle will be used to differentiate between them.

functionCard

Variable Type ViInt16

Specifies the Function Card for which the Circular Buffer will be configured.

Valid Values: 1, 2, 3, 4.

function

Variable Type ViInt32 (passed by reference)

This parameter returns the type of access to Circular Buffer which will be performed by DSP.

Possible values are:

bu3100_LIST_READ16	0	16-bit Packed block read
bu3100_LIST_READ32	1	32-bit block read
bu3100_LIST_READ64	2	64-bit block read
bu3100_LIST_WRITE16	3	16-bit packed block write
bu3100_LIST_WRITE32	4	32-bit block write
bu3100_LIST_WRITE64	5	64-bit block write

FIFOAddress

Variable Type ViInt32 (passed by reference)

This parameter returns the Address of Function Card FIFO in the Function Card address space.

address

Variable Type ViInt32 (passed by reference)

This parameter returns the Starting Address of the Circular Buffer in bu6100 DRAM.

length

Variable Type ViInt32 (passed by reference)

This parameter specifies the length of the Circular Buffer in 32-bit words.

threshold

Variable Type ViInt32 (passed by reference)

This parameter returns the threshold value - the number of 32-bit words, after collection of which the DSP will send a signal

(interrupt) to the VXI host.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the `bu6100_error_message` function. To obtain additional information about the error condition, call the `bu6100_GetError` function. To clear the error information from the driver, call the `bu6100_ClearError` function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.39. bu6100_GetError

```
ViStatus bu6100_GetError (ViSession instrumentHandle, ViPStatus code,
                          ViInt32 bufferSize,
                          ViChar _VI_FAR description[]);
```

Purpose

This function retrieves and then clears the IVI error information for the session or the current execution thread. One exception exists: If the BufferSize parameter is 0, the function does not clear the error information. By passing 0 for the buffer size, the caller can ascertain the buffer size required to get the entire error description string and then call the function again with a sufficiently large buffer.

If the user specifies a valid IVI session for the InstrumentHandle parameter, Get Error retrieves and then clears the error information for the session. If the user passes VI_NULL for the InstrumentHandle parameter, this function retrieves and then clears the error information for the current execution thread. If the InstrumentHandle parameter is an invalid session, the function does nothing and returns an error. Normally, the error information describes the first error that occurred since the user last called bu6100_GetError or bu6100_ClearError.

Parameter List

instrumentHandle

Variable Type ViSession

The ViSession handle that you obtain from the bu6100_init or bu6100_InitWithOptions function. The handle identifies a particular instrument session.

Default Value: None

code

Variable Type ViStatus (passed by reference)

Returns the error code for the session or execution thread.

If you pass 0 for the Buffer Size, you can pass VI_NULL for this parameter.

bufferSize

Variable Type ViInt32

Pass the number of bytes in the ViChar array you specify for the Description parameter.

If the error description, including the terminating NUL byte, contains more bytes than you indicate in this parameter, the function copies BufferSize - 1 bytes into the buffer, places an ASCII NUL byte at the end of the buffer, and returns the buffer size you must pass to get the entire value. For example, if the value is "123456" and the Buffer Size is 4, the function places "123" into the buffer and returns 7.

If you pass a negative number, the function copies the value to the buffer regardless of the number of bytes in the value.

If you pass 0, you can pass VI_NULL for the Description buffer parameter.

Default Value: None

description

Variable Type ViChar[]

Returns the error description for the IVI session or execution thread. If there is no description, the function returns an empty string.

The buffer must contain at least as many elements as the value you specify with the Buffer Size parameter. If the error description, including the terminating NUL byte, contains more bytes than you indicate with the Buffer Size parameter, the function copies Buffer Size - 1 bytes into the buffer, places an ASCII NUL byte at the end of the buffer, and returns the buffer size you must pass to get the entire value. For example, if the value is "123456" and the Buffer Size is 4, the function places "123" into the buffer and returns 7.

If you pass 0 for the Buffer Size, you can pass VI_NULL for this parameter.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.40. bu6100_getFcCclk

```
ViStatus bu6100_getFcCclk (ViSession instrumentHandle,
                          ViInt16 functionCard, ViPInt32 CCLKSource);
```

Purpose

This function returns the source of the Common Clock (CCLK) for the given Function Card.

Parameter List

instrumentHandle

Variable Type ViSession

The Instrument Handle is used to identify the unique session or communication channel between the driver and the instrument.

If more than one instrument of the same model type is used, this Handle will be used to differentiate between them.

functionCard

Variable Type ViInt16

The function card to access.
Valid Values: 1, 2, 3, 4.

CCLKSource

Variable Type ViInt32 (passed by reference)

Returns the source for the Function Card Common Clock. Possible values are:

- BU6100_CCLK_0 0 CCLK Disabled and forced to '0'
- BU6100_CCLK_1 1 CCLK Disabled and forced to '1'
- BU6100_CCLK_10 2 CCLK Connected to CLK10
- BU6100_CCLK_5 3 CCLK Connected to CLK10/2
- BU6100_CCLK_2 4 CCLK Connected to CLK10/5
- BU6100_CCLK_1588_PPP 5 CCLK Connected to IEEE1588_PPP

- BU6100_CCLK_LXI_TRG_0 8 CCLK Connected to LXI Trig 0
- BU6100_CCLK_LXI_TRG_1 9 CCLK Connected to LXI Trig 1
- BU6100_CCLK_LXI_TRG_2 10 CCLK Connected to LXI Trig 2
- BU6100_CCLK_LXI_TRG_3 11 CCLK Connected to LXI Trig 3
- BU6100_CCLK_LXI_TRG_4 12 CCLK Connected to LXI Trig 4
- BU6100_CCLK_LXI_TRG_5 13 CCLK Connected to LXI Trig 5
- BU6100_CCLK_LXI_TRG_6 14 CCLK Connected to LXI Trig 6
- BU6100_CCLK_LXI_TRG_7 15 CCLK Connected to LXI Trig 7

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.41. bu6100_GetNextCoercionRecord

```
ViStatus bu6100_GetNextCoercionRecord (ViSession instrumentHandle,
                                       ViInt32 bufferSize,
                                       ViChar _VI_FAR coercionRecord[]);
```

Purpose

This function returns the coercion information associated with the IVI session. This function retrieves and clears the oldest instance in which the instrument driver coerced a value you specified to another value.

If you set the BU6100_ATTR_RECORD_COERCIONS attribute to VI_TRUE, the instrument driver keeps a list of all coercions it makes on ViInt32 or ViReal64 values you pass to instrument driver functions. You use this function to retrieve information from that list.

If the next coercion record string, including the terminating NUL byte, contains more bytes than you indicate in this parameter, the function copies Buffer Size - 1 bytes into the buffer, places an ASCII NUL byte at the end of the buffer, and returns the buffer size you must pass to get the entire value. For example, if the value is "123456" and the Buffer Size is 4, the function places "123" into the buffer and returns 7.

If you pass a negative number, the function copies the value to the buffer regardless of the number of bytes in the value.

If you pass 0, you can pass VI_NULL for the Coercion Record buffer parameter.

The function returns an empty string in the Coercion Record parameter if no coercion records remain for the session.

Parameter List

instrumentHandle

Variable Type ViSession

The ViSession handle that you obtain from the bu6100_init function. The handle identifies a particular instrument session.

Default Value: None

bufferSize

Variable Type ViInt32

Pass the number of bytes in the ViChar array you specify for the Coercion Record parameter.

If the next coercion record string, including the terminating NUL byte, contains more bytes than you indicate in this parameter, the function copies Buffer Size - 1 bytes into the buffer, places an ASCII NUL byte at the end of the buffer, and returns the buffer size you must pass to get the entire value. For example, if the value is "123456" and the Buffer Size is 4, the function places "123" into the buffer and returns 7.

If you pass a negative number, the function copies the value to the buffer regardless of the number of bytes in the value.

If you pass 0, you can pass VI_NULL for the Coercion Record buffer parameter.

Default Value: None

coercionRecord

Variable Type ViChar[]

Returns the next coercion record for the IVI session. If there are

no coercion records, the function returns an empty string.

The buffer must contain at least as many elements as the value you specify with the Buffer Size parameter. If the next coercion record string, including the terminating NUL byte, contains more bytes than you indicate with the Buffer Size parameter, the function copies Buffer Size - 1 bytes into the buffer, places an ASCII NUL byte at the end of the buffer, and returns the buffer size you must pass to get the entire value. For example, if the value is "123456" and the Buffer Size is 4, the function places "123" into the buffer and returns 7.

This parameter returns an empty string if no coercion records remain for the session.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.42. bu6100_GetNextInterchangeWarning

```
ViStatus bu6100_GetNextInterchangeWarning (ViSession instrumentHandle,
                                           ViInt32 bufferSize,
                                           ViChar _VI_FAR interchangeWarning[]);
```

Purpose

This function returns the interchangeability warnings associated with the IVI session. It retrieves and clears the oldest instance in which the class driver recorded an interchangeability warning. Interchangeability warnings indicate that using your application with a different instrument might cause different behavior. You use this function to retrieve interchangeability warnings.

The driver performs interchangeability checking when the BU6100_ATTR_INTERCHANGE_CHECK attribute is set to VI_TRUE.

The function returns an empty string in the Interchange Warning parameter if no interchangeability warnings remain for the session.

In general, the instrument driver generates interchangeability warnings when an attribute that affects the behavior of the instrument is in a state that you did not specify.

Parameter List

instrumentHandle

Variable Type ViSession

The ViSession handle that you obtain from the bu6100_init or bu6100_InitWithOptions function. The handle identifies a particular instrument session.

Default Value: None

bufferSize

Variable Type ViInt32

Pass the number of bytes in the ViChar array you specify for the Interchange Warning parameter.

If the next interchangeability warning string, including the terminating NUL byte, contains more bytes than you indicate in this parameter, the function copies Buffer Size - 1 bytes into the buffer, places an ASCII NUL byte at the end of the buffer, and returns the buffer size you must pass to get the entire value. For example, if the value is "123456" and the Buffer Size is 4, the function places "123" into the buffer and returns 7.

If you pass a negative number, the function copies the value to the buffer regardless of the number of bytes in the value.

If you pass 0, you can pass VI_NULL for the Interchange Warning buffer parameter.

Default Value: None

interchangeWarning

Variable Type ViChar[]

Returns the next interchange warning for the IVI session. If there are no interchange warnings, the function returns an empty string.

The buffer must contain at least as many elements as the value you specify with the Buffer Size parameter. If the next interchangeability warning string, including the terminating NUL byte, contains more bytes than you indicate with the Buffer Size parameter, the function copies Buffer Size - 1 bytes into the buffer, places an ASCII NUL byte at the end of the buffer, and returns the

buffer size you must pass to get the entire value. For example, if the value is "123456" and the Buffer Size is 4, the function places "123" into the buffer and returns 7.

This parameter returns an empty string if no interchangeability warnings remain for the session.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the `bu6100_error_message` function. To obtain additional information about the error condition, call the `bu6100_GetError` function. To clear the error information from the driver, call the `bu6100_ClearError` function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.43. bu6100_getTrigStatus

```
ViStatus bu6100_getTrigStatus (ViSession instrumentHandle,
                               ViPInt32 sourceTriggerStatus,
                               ViPInt32 triggerNodeStatus);
```

Purpose

Reads the current status of all Trigger lines on ProDAQ 6100 module.

Parameter List

instrumentHandle

Variable Type ViSession

The Instrument Handle is used to identify the unique session or communication channel between the driver and the instrument.

If more than one instrument of the same model type is used, this Handle will be used to differentiate between them.

sourceTriggerStatus

Variable Type ViInt32 (passed by reference)

Contains the current status of all source trigger lines of ProDAQ 6100 module. Return value is a bitmask:

Bit No. Name

0	FC 1 Trigger Out A
1	FC 2 Trigger Out A
2	FC 3 Trigger Out A
3	FC 4 Trigger Out A

8	FC 1 Trigger Out B
9	FC 2 Trigger Out B
10	FC 3 Trigger Out B
11	FC 4 Trigger Out B

16	LXI Trigger 0
17	LXI Trigger 1
18	LXI Trigger 2
19	LXI Trigger 3
20	LXI Trigger 4
21	LXI Trigger 5
22	LXI Trigger 6
23	LXI Trigger 7

29	IEEE1588 Trigger
30	IEEE1588 Pulse Per Period

"1" means that trigger line is active (Logical level low);
 "0" means that trigger line is inactive (Logical level high);

triggerNodeStatus

Variable Type ViInt32 (passed by reference)

Contains the current status of all trigger nodes of ProDAQ 6100 module. Return value is a bitmask:

Bit No. Name

0	FC 1 Trigger In A
1	FC 2 Trigger In A
2	FC 3 Trigger In A
3	FC 4 Trigger In A

8	FC 1 Trigger In B
9	FC 2 Trigger In B
10	FC 3 Trigger In B
11	FC 4 Trigger In B

```

16   LXI Trigger 0
17   LXI Trigger 1
18   LXI Trigger 2
19   LXI Trigger 3
20   LXI Trigger 4
21   LXI Trigger 5
22   LXI Trigger 6
23   LXI Trigger 7
    
```

"1" means that trigger node is active (Logical level low);
 "0" means that trigger node is inactive (Logical level high);

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.44. bu6100_getVoltRefInfo

```
ViStatus bu6100_getVoltRefInfo (ViSession instrumentHandle,
                               ViPInt32 nVoltages,
                               ViReal64 _VI_FAR voltages[]);
```

Purpose

Returns the list of all possible voltages generated by the voltage reference module.

Parameter List

instrumentHandle

Variable Type ViSession

The Instrument Handle is used to identify the unique session or communication channel between the driver and the instrument.

If more than one instrument of the same model type is used, this Handle will be used to differentiate between them.

nVoltages

Variable Type ViInt32 (passed by reference)

This parameter return the number of elements returned in "Voltages" output.

voltages

Variable Type ViReal64[]

This array contains the list of all possible voltages generated by the voltage reference module. It should be allocated with size 20 prior to the function call.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.45. bu6100_getVoltRefOutput

```
ViStatus bu6100_getVoltRefOutput (ViSession instrumentHandle,
                                  ViPReal64 voltage);
```

Purpose

Returns the current output voltage of Voltage Reference module.

Parameter List

instrumentHandle

Variable Type ViSession

The Instrument Handle is used to identify the unique session or communication channel between the driver and the instrument.

If more than one instrument of the same model type is used, this Handle will be used to differentiate between them.

voltage

Variable Type ViReal64 (passed by reference)

Returns the current output voltage of Voltage Reference module.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXI PnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXI PnP Driver Errors

5.5.46. bu6100_identify

```
ViStatus bu6100_identify (ViSession instrumentHandle, ViBoolean enable);
```

Purpose

This function enables/disables blinking of LAN LED on the front panel of the instrument. Using this LED can help in identifying the LXI instrument.

Parameter List

instrumentHandle

Variable Type ViSession

The Instrument Handle is used to identify the unique session or communication channel between the driver and the instrument.

If more than one instrument of the same model type is used, this Handle will be used to differentiate between them.

enable

Variable Type ViBoolean

This parameter specifies whether the LAN LED on the front panel of the instrument is blinking or not.

Valid Values:

```
VI_FALSE 0 The LAN LED is not blinking;
VI_TRUE  1 The LAN LED is blinking;
```

Default Value: VI_FALSE

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.47. bu6100_init

```
ViStatus bu6100_init (ViRsrc resourceName, ViBoolean IDQuery,
                    ViBoolean resetDevice,
                    ViPSession instrumentHandle);
```

Purpose

This function performs the following initialization actions:

- Creates a new IVI instrument driver session.
- Opens a session to the specified device using the interface and address you specify for the Resource Name parameter.
- If the ID Query parameter is set to VI_TRUE, this function queries the instrument ID and checks that it is valid for this instrument driver.
- If the Reset parameter is set to VI_TRUE, this function resets the instrument to a known state.
- Sends initialization commands to set the instrument to the state necessary for the operation of the instrument driver.
- Returns a ViSession handle that you use to identify the instrument in all subsequent instrument driver function calls.

Note: This function creates a new session each time you invoke it. Although you can open more than one IVI session for the same resource, it is best not to do so. You can use the same session in multiple program threads. You can use the bu6100_LockSession and bu6100_UnlockSession functions to protect sections of code that require exclusive access to the resource.

Parameter List

resourceName

Variable Type	ViRsrc
---------------	--------

Pass the resource name of the device to initialize.

You can also pass the name of a driver session or logical name that you configure with the IVI Configuration utility. The driver session identifies a specific device and specifies the initial settings for the session. A logical Name identifies a particular driver session.

Refer to the following table below for the exact grammar to use for this parameter. Optional fields are shown in square brackets ([]).

Syntax

```
-----
GPIB[board]::<primary address>[::secondary address]::INSTR
VXI[board]::<logical address>::INSTR
GPIB-VXI[board]::<logical address>::INSTR
ASRL<port>::INSTR
<LogicalName>
<Driver Session>
```

If you do not specify a value for an optional field, the following values are used:

Optional Field - Value

```
-----
board - 0
secondary address - none (31)
```

The following table contains example valid values for this parameter.

"Valid Value" - Description

```
-----
"GPIB::22::INSTR" - GPIB board 0, primary address 22 no
                    secondary address
```

```

"GPIB::22::5::INSTR" - GPIB board 0, primary address 22
                      secondary address 5
"GPIB1::22::5::INSTR" - GPIB board 1, primary address 22
                      secondary address 5
"VXI::64::INSTR" - VXI board 0, logical address 64
"VXI1::64::INSTR" - VXI board 1, logical address 64
"GPIB-VXI::64::INSTR" - GPIB-VXI board 0, logical address 64
"GPIB-VXI1::64::INSTR" - GPIB-VXI board 1, logical address 64
"ASRL2::INSTR" - COM port 2
"SampleInstr" - Logical name "SampleInstr"
"xyz432" - Logical Name or Driver Session "xyz432"

Default Value: "TCPIP0::192.168.168.63::inst0::INSTR"

```

IDQuery

Variable Type ViBoolean

Specify whether you want the instrument driver to perform an ID Query.

Valid Range:

VI_TRUE (1) - Perform ID Query (Default Value)
 VI_FALSE (0) - Skip ID Query

When you set this parameter to VI_TRUE, the driver verifies that the instrument you initialize is a type that this driver supports.

Circumstances can arise where it is undesirable to send an ID Query command string to the instrument. When you set this parameter to VI_FALSE, the function initializes the instrument without performing an ID Query.

resetDevice

Variable Type ViBoolean

Specify whether you want the to reset the instrument during the initialization procedure.

Valid Range:

VI_TRUE (1) - Reset Device (Default Value)
 VI_FALSE (0) - Don't Reset

instrumentHandle

Variable Type ViSession (passed by reference)

Returns a ViSession handle that you use to identify the instrument in all subsequent instrument driver function calls.

Notes:

(1) This function creates a new session each time you invoke it. This is useful if you have multiple physical instances of the same type of instrument.

(2) Avoid creating multiple concurrent sessions to the same physical instrument. Although you can create more than one IVI session for the same resource, it is best not to do so. A better approach is to use the same IVI session in multiple execution threads. You can use functions bu6100_LockSession and bu6100_UnlockSession to protect sections of code that require exclusive access to the resource.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the `bu6100_error_message` function. To obtain additional information about the error condition, call the `bu6100_GetError` function. To clear the error information from the driver, call the `bu6100_ClearError` function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.48. bu6100_InitWithOptions

```
ViStatus bu6100_InitWithOptions (ViRsrc resourceName, ViBoolean IDQuery,
                                ViBoolean resetDevice,
                                ViChar _VI_FAR optionString[],
                                ViPSession instrumentHandle);
```

Purpose

This function performs the following initialization actions:

- Creates a new IVI instrument driver and optionally sets the initial state of the following session attributes:

```
BU6100_ATTR_RANGE_CHECK
BU6100_ATTR_QUERY_INSTRUMENT_STATUS
BU6100_ATTR_CACHE
BU6100_ATTR_SIMULATE
BU6100_ATTR_RECORD_COERCIONS
```

- Opens a session to the specified device using the interface and address you specify for the Resource Name parameter.
- If the ID Query parameter is set to VI_TRUE, this function queries the instrument ID and checks that it is valid for this instrument driver.
- If the Reset parameter is set to VI_TRUE, this function resets the instrument to a known state.
- Sends initialization commands to set the instrument to the state necessary for the operation of the instrument driver.
- Returns a ViSession handle that you use to identify the instrument in all subsequent instrument driver function calls.

Note: This function creates a new session each time you invoke it. Although you can open more than one IVI session for the same resource, it is best not to do so. You can use the same session in multiple program threads. You can use the bu6100_LockSession and bu6100_UnlockSession functions to protect sections of code that require exclusive access to the resource.

Parameter List

resourceName

Variable	Type	ViRsrc
----------	------	--------

Pass the resource name of the device to initialize.

You can also pass the name of a driver session or logical name that you configure with the IVI Configuration utility. The driver session identifies a specific device and specifies the initial settings for the session. A logical name identifies a particular driver session.

Refer to the following table below for the exact grammar to use for this parameter. Optional fields are shown in square brackets ([]).

Syntax

```
-----
GPIB[board]::<primary address>[::secondary address]::INSTR
VXI[board]::<logical address>::INSTR
GPIB-VXI[board]::<logical address>::INSTR
ASRL<port>::INSTR
<LogicalName>
<Driver Session>
```

If you do not specify a value for an optional field, the following values are used:

Optional Field	Value
----------------	-------

```
-----
board - 0
```

secondary address - none (31)

The following table contains example valid values for this parameter.

```
"Valid Value" - Description
-----
"GPIB::22::INSTR" - GPIB board 0, primary address 22 no
                    secondary address
"GPIB::22::5::INSTR" - GPIB board 0, primary address 22
                    secondary address 5
"GPIB1::22::5::INSTR" - GPIB board 1, primary address 22
                    secondary address 5
"VXI::64::INSTR" - VXI board 0, logical address 64
"VXI1::64::INSTR" - VXI board 1, logical address 64
"GPIB-VXI::64::INSTR" - GPIB-VXI board 0, logical address 64
"GPIB-VXI1::64::INSTR" - GPIB-VXI board 1, logical address 64
"ASRL2::INSTR" - COM port 2
"SampleInstr" - Logical name "SampleInstr"
"xyz432" - Logical Name or Driver Session "xyz432"

Default Value: "TCPIP0::192.168.168.63::inst0::INSTR"
```

IDQuery

Variable Type ViBoolean

Specify whether you want the instrument driver to perform an ID Query.

Valid Range:
 VI_TRUE (1) - Perform ID Query (Default Value)
 VI_FALSE (0) - Skip ID Query

When you set this parameter to VI_TRUE, the driver verifies that the instrument you initialize is a type that this driver supports.

Circumstances can arise where it is undesirable to send an ID Query command string to the instrument. When you set this parameter to VI_FALSE, the function initializes the instrument without performing an ID Query.

resetDevice

Variable Type ViBoolean

Specify whether you want the to reset the instrument during the initialization procedure.

Valid Range:
 VI_TRUE (1) - Reset Device (Default Value)
 VI_FALSE (0) - Don't Reset

optionString

Variable Type ViChar[]

You can use this control to set the initial value of certain attributes for the session. The following table lists the attributes and the name you use in this parameter to identify the attribute.

Name	Attribute Defined Constant
RangeCheck	BU6100_ATTR_RANGE_CHECK
QueryInstrStatus	BU6100_ATTR_QUERY_INSTRUMENT_STATUS
Cache	BU6100_ATTR_CACHE
Simulate	BU6100_ATTR_SIMULATE
RecordCoercions	BU6100_ATTR_RECORD_COERCIONS

The format of this string is, "AttributeName=Value" where AttributeName is the name of the attribute and Value is the value to which the attribute will be set. To set multiple attributes, separate their assignments with a comma.

If you pass NULL or an empty string for this parameter, the session uses the default values for the attributes. You can override the default values by assigning a value explicitly in a string you pass for this parameter. You do not have to specify all of the attributes and may leave any of them out. If you do not specify one of the attributes, its default value will be used.

The default values for the attributes are shown below:

Attribute Name	Default Value
RangeCheck	VI_TRUE
QueryInstrStatus	VI_FALSE
Cache	VI_TRUE
Simulate	VI_FALSE
RecordCoercions	VI_FALSE

The following are the valid values for ViBoolean attributes:

True: 1, True, or VI_TRUE
 False: 0, False, or VI_FALSE

Default Value:

"Simulate=0,RangeCheck=1,QueryInstrStatus=0,Cache=1"

instrumentHandle

Variable Type ViSession (passed by reference)

Returns a ViSession handle that you use to identify the instrument in all subsequent instrument driver function calls.

Notes:

(1) This function creates a new session each time you invoke it. This is useful if you have multiple physical instances of the same type of instrument.

(2) Avoid creating multiple concurrent sessions to the same physical instrument. Although you can create more than one IVI session for the same resource, it is best not to do so. A better approach is to use the same IVI session in multiple execution threads. You can use functions bu6100_LockSession and bu6100_UnlockSession to protect sections of code that require exclusive access to the resource.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors

BFFF0000 to BFFFFFFF	VISA	Errors
BFFC0000 to BFFCFFFF	VXIPnP	Driver Errors

5.5.49. bu6100_installIrqHandler

```
ViStatus bu6100_installIrqHandler (ViSession instrumentHandle,
                                  ViInt16 source,
                                  ViAddr interruptHandler,
                                  ViAddr interruptParameter);
```

Purpose

Installs Interrupt Service Routine for the Function Card. This Interrupt Service Routine will be called every time when the Output Trigger line of the Function Card goes to active (low) state. The Output Trigger line of the Function Card should be configured for low-active polarity (where selectable) and "level" type of output (where selectable).

Upon completion, the Interrupt Service Routine should clear the Output Trigger line of the Function Card by method depending on the type of Function Card (for instance, read out FIFO or clear some bits in Function Card control register)

Parameter List

instrumentHandle

Variable Type ViSession

The Instrument Handle is used to identify the unique session or communication channel between the driver and the instrument.

If more than one instrument of the same model type is used, this Handle will be used to differentiate between them.

source

Variable Type ViInt16

The trigger line for which Interrupt Handler will be installed.

Valid Values:

bu3100_FCTrigOutA1	0	FC 1 Trigger Output A
bu3100_FCTrigOutA2	1	FC 2 Trigger Output A
bu3100_FCTrigOutA3	2	FC 3 Trigger Output A
bu3100_FCTrigOutA4	3	FC 4 Trigger Output A
bu3100_FCTrigOutB1	8	FC 1 Trigger Output B
bu3100_FCTrigOutB2	9	FC 2 Trigger Output B
bu3100_FCTrigOutB3	10	FC 3 Trigger Output B
bu3100_FCTrigOutB4	11	FC 4 Trigger Output B
bu3100_FCCircBuf1	16	FC 1 Circular Buffer
bu3100_FCCircBuf2	17	FC 2 Circular Buffer
bu3100_FCCircBuf3	18	FC 3 Circular Buffer
bu3100_FCCircBuf4	19	FC 4 Circular Buffer

interruptHandler

Variable Type ViAddr

Pointer to the interrupt service routine.

Default Value: VI_NULL

interruptParameter

Variable Type ViAddr

Pointer to any user-defined data, which will be transferred to the Interrupt Service routine in every call.

Default Value: VI_NULL

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver

function to determine if an error occurred.

To obtain a text description of the status code, call the `bu6100_error_message` function. To obtain additional information about the error condition, call the `bu6100_GetError` function. To clear the error information from the driver, call the `bu6100_ClearError` function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.50. bu6100_installIrqWatcher

```
ViStatus bu6100_installIrqWatcher (ViSession instrumentHandle,
                                   ViInt16 source);
```

Purpose

Creates the IRQ watcher for selected Function Card. After IRQ watcher is installed the function `bu6100_waitIrqWatcher` can be used to catch an interrupt events from given Function Card or from multiple Function Cards at the same time respectively.

This mechanism can be used whenever asynchronous Interrupt Handling is not applicable (for instance, LabVIEW environment).

Parameter List

instrumentHandle

Variable Type ViSession

The Instrument Handle is used to identify the unique session or communication channel between the driver and the instrument.

If more than one instrument of the same model type is used, this Handle will be used to differentiate between them.

source

Variable Type ViInt16

The trigger line for which Interrupt Watcher will be installed.

Valid Values:

<code>bu3100_FCTrigOutA1</code>	0	FC 1 Trigger Output A
<code>bu3100_FCTrigOutA2</code>	1	FC 2 Trigger Output A
<code>bu3100_FCTrigOutA3</code>	2	FC 3 Trigger Output A
<code>bu3100_FCTrigOutA4</code>	3	FC 4 Trigger Output A
<code>bu3100_FCTrigOutB1</code>	8	FC 1 Trigger Output B
<code>bu3100_FCTrigOutB2</code>	9	FC 2 Trigger Output B
<code>bu3100_FCTrigOutB3</code>	10	FC 3 Trigger Output B
<code>bu3100_FCTrigOutB4</code>	11	FC 4 Trigger Output B
<code>bu3100_FCCircBuf1</code>	16	FC 1 Circular Buffer
<code>bu3100_FCCircBuf2</code>	17	FC 2 Circular Buffer
<code>bu3100_FCCircBuf3</code>	18	FC 3 Circular Buffer
<code>bu3100_FCCircBuf4</code>	19	FC 4 Circular Buffer

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the `bu6100_error_message` function. To obtain additional information about the error condition, call the `bu6100_GetError` function. To clear the error information from the driver, call the `bu6100_ClearError` function.

The general meaning of the status code is as follows:

Value	Meaning

0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different

include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.51. bu6100_InvalidateAllAttributes

```
ViStatus bu6100_InvalidateAllAttributes (ViSession instrumentHandle);
```

Purpose

This function invalidates the cached values of all attributes for the session.

Parameter List

instrumentHandle

Variable Type ViSession

The ViSession handle that you obtain from the bu6100_init or bu6100_initWithOptions function. The handle identifies a particular instrument session.

Default Value: None

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.52. bu6100_IviLxiSync_AddArmAlarm

```
ViStatus bu6100_IviLxiSync_AddArmAlarm (ViSession instrumentHandle,
                                         ViConstString alarmName);
```

Purpose

This function creates a new arm alarm

ProDAQ 6100 does not support Arm subsystem.

Parameter List

instrumentHandle

Variable Type ViSession

Instrument handle.

alarmName

Variable Type ViConstString

Specifies the name of the arm alarm to create.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.53. bu6100_IviLxiSync_AddArmSource

```
ViStatus bu6100_IviLxiSync_AddArmSource (ViSession instrumentHandle,
                                         ViConstString sourceName);
```

Purpose

This function creates a new arm source.
 ProDAQ 6100 does not support Arm subsystem.

Parameter List

instrumentHandle
 Variable Type ViSession
 Instrument handle.

sourceName
 Variable Type ViConstString
 Specifies the name of the arm source to create.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.54. bu6100_IviLxiSync_AddEvent

```
ViStatus bu6100_IviLxiSync_AddEvent (ViSession instrumentHandle,
                                     ViConstString eventName);
```

Purpose

This function creates a new event.

Parameter List

instrumentHandle

Variable Type ViSession

Instrument handle.

eventName

Variable Type ViConstString

Specifies the name of the event to create.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the `bu6100_error_message` function. To obtain additional information about the error condition, call the `bu6100_GetError` function. To clear the error information from the driver, call the `bu6100_ClearError` function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.55. bu6100_IviLxiSync_AddTriggerAlarm

```
ViStatus bu6100_IviLxiSync_AddTriggerAlarm (ViSession instrumentHandle,
                                           ViConstString alarmName);
```

Purpose

This function creates a new trigger alarm

ProDAQ 6100 does not support custom Trigger Alarms. Only "ALARM0" is supported by ProDAQ 6100.

Parameter List

instrumentHandle

Variable Type ViSession

Instrument handle.

alarmName

Variable Type ViConstString

Specifies the name of the trigger alarm to create.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.56. bu6100_IviLxiSync_AddTriggerSource

```
ViStatus bu6100_IviLxiSync_AddTriggerSource (ViSession instrumentHandle,
                                             ViConstString sourceName);
```

Purpose

This function creates a new trigger source. ProDAQ 6100 does not support custom trigger sources.

Parameter List

instrumentHandle

Variable Type ViSession
Instrument handle.

sourceName

Variable Type ViConstString
Specifies the name of the trigger source to create.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.57. bu6100_IviLxiSync_ArmTrigger

```
ViStatus bu6100_IviLxiSync_ArmTrigger (ViSession instrumentHandle);
```

Purpose

This function arms the trigger.

Parameter List

instrumentHandle

Variable Type ViSession

Instrument handle.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.58. bu6100_IviLxiSync_ClearEventLog

```
ViStatus bu6100_IviLxiSync_ClearEventLog (ViSession instrumentHandle);
```

Purpose

This function removes all existing entries from the event log.

Parameter List

instrumentHandle

Variable Type ViSession

Instrument handle.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.59. bu6100_IviLxiSync_ClearTriggerLog

```
ViStatus bu6100_IviLxiSync_ClearTriggerLog (ViSession instrumentHandle);
```

Purpose

This function removes all existing entries from the trigger log.

Parameter List

instrumentHandle

Variable Type ViSession

Instrument handle.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.60. bu6100_IviLxiSync_ConfigureArmAlarm

```
ViStatus bu6100_IviLxiSync_ConfigureArmAlarm (ViSession instrumentHandle,
                                              ViConstString alarmName,
                                              ViBoolean enabled,
                                              ViReal64 timeSeconds,
                                              ViReal64 timeFraction,
                                              ViReal64 period,
                                              ViInt32 repeatCount);
```

Purpose

This function configures the most commonly configured attributes of the arm alarm.

ProDAQ 6100 does not support Arm subsystem.

Parameter List

instrumentHandle

Variable Type ViSession

Instrument handle.

alarmName

Variable Type ViConstString

The name of the alarm.

enabled

Variable Type ViBoolean

Enables or disables the arm alarm.

Valid Values:

 VI_FALSE 0 Alarm is disabled

 VI_TRUE 1 Alarm is enabled

Default Value: VI_FALSE

timeSeconds

Variable Type ViReal64

Specifies the seconds part of 1588 time.

timeFraction

Variable Type ViReal64

Specifies the fractional part of 1588 time.

period

Variable Type ViReal64

Specifies the period of the arm alarm.

repeatCount

Variable Type ViInt32

Specifies the number of times to repeat the trigger at the period specified by the Arm Alarm Repeat Period attribute.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information

about the error condition, call the `bu6100_GetError` function. To clear the error information from the driver, call the `bu6100_ClearError` function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.61. bu6100_IviLxiSync_ConfigureArmSource

```
ViStatus bu6100_IviLxiSync_ConfigureArmSource
    (ViSession instrumentHandle, ViConstString sourceName,
     ViBoolean enabled, ViInt32 detection);
```

Purpose

This function configures the most commonly configured attributes of the arm source sub-system.

ProDAQ 6100 does not support Arm subsystem.

Parameter List

instrumentHandle

Variable Type ViSession

Instrument handle.

sourceName

Variable Type ViConstString

Name of the arm source to configure.

enabled

Variable Type ViBoolean

Enables or disables the arm source.

Valid Values:

```
VI_FALSE    0    The Source is disabled;
VI_TRUE     1    The Source is enabled;
```

Default Value: VI_FALSE

detection

Variable Type ViInt32

Specifies the style of the arm source.

Valid Values:

BU6100_VAL_IVILXISYNC_DETECTION_RISE - Configures the LXI device to arm on the rising edge of the arm source.

BU6100_VAL_IVILXISYNC_DETECTION_FALL - Configures the LXI device to arm on the falling edge of the arm source.

BU6100_VAL_IVILXISYNC_DETECTION_HIGH - Configures the LXI device to arm while the arm source is high, that is, while it remains true.

BU6100_VAL_IVILXISYNC_DETECTION_LOW - Configures the LXI device to arm while the arm source is low, that is, while it remains false.

Default Value: BU6100_VAL_IVILXISYNC_DETECTION_RISE

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.62. bu6100_IviLxiSync_ConfigureEvent

```
ViStatus bu6100_IviLxiSync_ConfigureEvent (ViSession instrumentHandle,
                                           ViConstString eventName,
                                           ViInt32 driveMode,
                                           ViConstString source,
                                           ViConstString destinationPath,
                                           ViInt32 slope);
```

Purpose

This function configures the most commonly configured attributes of the event sub-system.

Parameter List

instrumentHandle

Variable Type ViSession

Instrument handle.

eventName

Variable Type ViConstString

Specifies the name of the event to configure.

driveMode

Variable Type ViInt32

Specifies the mode of the event.

Valid Values:

BU6100_VAL_IVILXISYNC_EVENT_DRIVEN - Enables the event in driven mode.

BU6100_VAL_IVILXISYNC_EVENT_OFF - Disables the event.

BU6100_VAL_IVILXISYNC_EVENT_WIREDOR - Enables the event in wired-OR mode.

Default Value: BU6100_VAL_IVILXISYNC_EVENT_DRIVEN

source

Variable Type ViConstString

Specifies the signal which causes an event to be transmitted.

destinationPath

Variable Type ViConstString

Specifies a list of places to send the event.

slope

Variable Type ViInt32

Specifies the slope of the event signal.

Valid Values:

BU6100_VAL_IVILXISYNC_SLOPE_RISE - The event will be transmitted with a rising edge.

BU6100_VAL_IVILXISYNC_SLOPE_FALL - The event will be transmitted with a falling edge.

Default Value: BU6100_VAL_IVILXISYNC_SLOPE_RISE

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the `bu6100_error_message` function. To obtain additional information about the error condition, call the `bu6100_GetError` function. To clear the error information from the driver, call the `bu6100_ClearError` function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.63. bu6100_IviLxiSync_ConfigureTriggerAlarm

```
ViStatus bu6100_IviLxiSync_ConfigureTriggerAlarm
(ViSession instrumentHandle, ViConstString alarmName,
 ViReal64 timeSeconds, ViReal64 timeFraction,
 ViReal64 period, ViInt32 repeatCount);
```

Purpose

This function configures the most commonly configured attributes of the trigger alarm sub-system. Only "ALARM0" is supported by ProDAQ 6100.

Parameter List

instrumentHandle

Variable Type ViSession
Instrument handle.

alarmName

Variable Type ViConstString
The name of the alarm. Only "ALARM0" is supported by ProDAQ 6100.

timeSeconds

Variable Type ViReal64
Specifies the seconds part of 1588 time.

timeFraction

Variable Type ViReal64
Specifies the fractional part of 1588 time.

period

Variable Type ViReal64
Specifies the period of the trigger alarm.

repeatCount

Variable Type ViInt32
Specifies the number of times to repeat the trigger at the period specified by the Trigger Alarm Repeat Period attribute.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status

codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.64. bu6100_IviLxiSync_ConfigureTriggerLog

```
ViStatus bu6100_IviLxiSync_ConfigureTriggerLog
    (ViSession instrumentHandle, ViInt32 logMode);
```

Purpose

This function configures the trigger log.

Parameter List

instrumentHandle

Variable Type ViSession

Instrument handle.

logMode

Variable Type ViInt32

Selects the mode for the trigger log.

Valid Values:

BU6100_LOG_DISABLED	0	No records will be added to the trigger log;
BU6100_LOG_ENABLED	1	Every trigger assert will be added to the trigger log. When the log queue will be full, the new record will not be added, but the last record will be marked with overflow flag.
BU6100_LOG_DROP	2	Every trigger assert will be added to the trigger log. When the log queue will be full, the oldest record will be overwritten with the new one.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the `bu6100_error_message` function. To obtain additional information about the error condition, call the `bu6100_GetError` function. To clear the error information from the driver, call the `bu6100_ClearError` function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.65. bu6100_IviLxiSync_ConfigureTriggerSource

```
ViStatus bu6100_IviLxiSync_ConfigureTriggerSource
(ViSession instrumentHandle, ViConstString sourceName,
 ViReal64 delay, ViInt32 detection);
```

Purpose

This function configures the most commonly configured attributes of the trigger source sub-system.

Parameter List

instrumentHandle

Variable Type ViSession

Instrument handle.

sourceName

Variable Type ViConstString

Name of the trigger source to configure.

delay

Variable Type ViReal64

Specifies the trigger source delay. The units are seconds. A negative value implies pre-trigger acquisition.

detection

Variable Type ViInt32

Specifies the slope of the trigger source.

Valid Values:

BU6100_VAL_IVILXISYNC_DETECTION_RISE - Configures the LXI device to trigger on the rising edge of the trigger source.

BU6100_VAL_IVILXISYNC_DETECTION_FALL - Configures the LXI device to trigger on the falling edge of the trigger source.

Default Value: BU6100_VAL_IVILXISYNC_DETECTION_RISE

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.66. bu6100_IviLxiSync_DisableAllArmAlarms

```
ViStatus bu6100_IviLxiSync_DisableAllArmAlarms  
    (ViSession instrumentHandle);
```

Purpose

This function disables all arm alarms.

ProDAQ 6100 does not support Arm subsystem.

Parameter List

```
instrumentHandle  
  
    Variable Type      ViSession  
  
    Instrument handle.
```

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXI PnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXI PnP Driver Errors

5.5.67. bu6100_IviLxiSync_DisableAllArmSources

```
ViStatus bu6100_IviLxiSync_DisableAllArmSources
(ViSession instrumentHandle);
```

Purpose

This function disables all arm sources.

ProDAQ 6100 does not support Arm subsystem.

Parameter List

instrumentHandle

Variable Type	ViSession
---------------	-----------

Instrument handle.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXI PnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXI PnP Driver Errors

5.5.68. bu6100_IviLxiSync_DisableAllEvents

```
ViStatus bu6100_IviLxiSync_DisableAllEvents (ViSession instrumentHandle);
```

Purpose

This function disables all events.

Parameter List

instrumentHandle

Variable Type ViSession

Instrument handle.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.69. bu6100_IviLxiSync_DisableAllTriggerAlarms

```
ViStatus bu6100_IviLxiSync_DisableAllTriggerAlarms
(ViSession instrumentHandle);
```

Purpose

This function disables all trigger alarms. Only "ALARM0" is supported by ProDAQ 6100.

Parameter List

```
instrumentHandle
    Variable Type      ViSession
    Instrument handle.
```

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.70. bu6100_IviLxiSync_GetArmAlarmName

```
ViStatus bu6100_IviLxiSync_GetArmAlarmName (ViSession instrumentHandle,
                                           ViInt32 alarmIndex,
                                           ViInt32 alarmNameBufferSize,
                                           ViChar _VI_FAR alarmName[]);
```

Purpose

This function returns the physical repeated capability identifier that corresponds to the one-based index that the user specifies. If the value that the user passes for the AlarmIndex parameter is less than one or greater than the value of the Arm Alarm Count attribute, the function returns an empty string in the AlarmName parameter and returns an error. For custom arm sources added with the Add Arm Source function, this function returns the arm source name in the original casing used when Add Arm Source was called.

ProDAQ 6100 does not support Arm subsystem.

Parameter List

instrumentHandle

Variable Type ViSession
Instrument handle.

alarmIndex

Variable Type ViInt32
A one-based index that defines which name to return.

alarmNameBufferSize

Variable Type ViInt32
The number of bytes in the ViChar array that the user specifies for the AlarmName parameter.

alarmName

Variable Type ViChar[]
The buffer into which the function returns the alarm name that corresponds to the index the user specifies. The caller may pass VI_NULL for this parameter if the AlarmNameBufferSize parameter is 0.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.71. bu6100_IviLxiSync_GetArmSourceName

```
ViStatus bu6100_IviLxiSync_GetArmSourceName (ViSession instrumentHandle,
                                             ViInt32 sourceIndex,
                                             ViInt32 sourceNameBufferSize,
                                             ViChar _VI_FAR sourceName[]);
```

Purpose

This function returns the physical repeated capability identifier that corresponds to the one-based index that the user specifies. If the value that the user passes for the SourceIndex parameter is less than one or greater than the value of the Arm Source Count attribute, the function returns an empty string in the SourceName parameter and returns an error. For custom arm sources added with the Add Arm Source function, this function returns the arm source name in the original casing used when Add Arm Source was called.

ProDAQ 6100 does not support Arm subsystem.

Parameter List

instrumentHandle

Variable Type ViSession

Instrument handle.

sourceIndex

Variable Type ViInt32

A one-based index that defines which name to return.

sourceNameBufferSize

Variable Type ViInt32

The number of bytes in the ViChar array that the user specifies for the SourceName parameter.

sourceName

Variable Type ViChar[]

The buffer into which the function returns the source name that corresponds to the index the user specifies. The caller may pass VI_NULL for this parameter if the SourceNameBufferSize parameter is 0.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
-----	-----
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.72. bu6100_IviLxiSync_GetEventName

```
ViStatus bu6100_IviLxiSync_GetEventName (ViSession instrumentHandle,
                                         ViInt32 eventIndex,
                                         ViInt32 eventNameBufferSize,
                                         ViChar _VI_FAR eventName[]);
```

Purpose

This function returns the physical repeated capability identifier that corresponds to the one-based index that the user specifies. If the value that the user passes for the EventIndex parameter is less than one or greater than the value of the Event Count attribute, the function returns an empty string in the EventName parameter and returns an error. For custom event sources added with the Add Event Source function, this function returns the event source name in the original casing used when Add Event Source was called.

Parameter List

instrumentHandle

Variable Type ViSession

Instrument handle.

eventIndex

Variable Type ViInt32

A one-based index that defines which name to return.

eventNameBufferSize

Variable Type ViInt32

The number of bytes in the ViChar array that the user specifies for the EventName parameter.

eventName

Variable Type ViChar[]

The buffer into which the function returns the alarm name that corresponds to the index the user specifies. The caller may pass VI_NULL for this parameter if the EventNameBufferSize parameter is 0.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings

3FFC0000 to 3FFCFFFF	VXIPnP	Driver Warnings
BFFA0000 to BFFA1FFF	IVI	Errors
BFFF0000 to BFFFFFFF	VISA	Errors
BFFC0000 to BFFCFFFF	VXIPnP	Driver Errors

5.5.73. bu6100_IviLxiSync_GetNextEventLogEntry

```
ViStatus bu6100_IviLxiSync_GetNextEventLogEntry
(ViSession instrumentHandle, ViInt32 logEntryBufferSize,
ViChar _VI_FAR logEntry[]);
```

Purpose

This function retrieves and clears the oldest event log entry for the IVI session.

Parameter List

instrumentHandle

Variable Type ViSession
Instrument handle.

logEntryBufferSize

Variable Type ViInt32
The number of bytes in the ViChar array that the user specifies for the LogEntry parameter.

logEntry

Variable Type ViChar[]
The buffer in which the function returns the oldest event log entry. Can be VI_NULL if LogEntryBufferSize is 0.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.74. bu6100_IviLxiSync_GetNextTriggerLogEntry

```
ViStatus bu6100_IviLxiSync_GetNextTriggerLogEntry
(ViSession instrumentHandle, ViInt32 logEntryBufferSize,
 ViChar _VI_FAR logEntry[], ViPReal64 timeSeconds,
 ViPReal64 timeFractional);
```

Purpose

This function retrieves and clears the oldest trigger log entry for the IVI session.

Parameter List

instrumentHandle

Variable Type ViSession

Instrument handle.

logEntryBufferSize

Variable Type ViInt32

The number of bytes in the ViChar array that the user specifies for the LogEntry parameter.

logEntry

Variable Type ViChar[]

The buffer in which the function returns the oldest event log entry. Can be VI_NULL if LogEntryBufferSize is 0.

timeSeconds

Variable Type ViReal64 (passed by reference)

timeFractional

Variable Type ViReal64 (passed by reference)

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings

BFFA0000 to BFFA1FFF	IVI	Errors
BFFF0000 to BFFFFFFF	VISA	Errors
BFFC0000 to BFFCFFFF	VXI PnP	Driver Errors

5.5.75. bu6100_IviLxiSync_GetNumberOfTriggerLogEntries

```
ViStatus bu6100_IviLxiSync_GetNumberOfTriggerLogEntries
    (ViSession instrumentHandle, ViPInt32 number_ofLogEntries);
```

Purpose

Returns the number of records in the trigger log book.

Parameter List

instrumentHandle

Variable Type ViSession

Instrument handle.

number_ofLogEntries

Variable Type ViInt32 (passed by reference)

Returns the number of records in the trigger log book.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXI PnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXI PnP Driver Errors

5.5.76. bu6100_IviLxiSync_GetSystemTime

```
ViStatus bu6100_IviLxiSync_GetSystemTime (ViSession instrumentHandle,
                                          ViPReal64 timeSeconds,
                                          ViPReal64 timeFractional);
```

Purpose

This function retrieves the current 1588 time.

Parameter List

instrumentHandle

Variable Type ViSession
Instrument handle.

timeSeconds

Variable Type ViReal64 (passed by reference)
Indicates the seconds portion of the current 1588 time.

timeFractional

Variable Type ViReal64 (passed by reference)
Indicates the fractional portion of the current 1588 time.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.77. bu6100_IviLxiSync_GetTriggerAlarmName

```
ViStatus bu6100_IviLxiSync_GetTriggerAlarmName
(ViSession instrumentHandle, ViInt32 alarmIndex,
 ViInt32 alarmNameBufferSize, ViChar _VI_FAR alarmName[]);
```

Purpose

This function returns the physical repeated capability identifier that corresponds to the one-based index that the user specifies. If the value that the user passes for the AlarmIndex parameter is less than one or greater than the value of the Trigger Alarm Count attribute, the function returns an empty string in the AlarmName parameter and returns an error. For custom trigger sources added with the Add Arm Source function, this function returns the arm source name in the original casing used when Add Arm Source was called. Only "ALARM0" is supported by ProDAQ 6100.

Parameter List

instrumentHandle

Variable Type ViSession

Instrument handle.

alarmIndex

Variable Type ViInt32

A one-based index that defines which name to return.

alarmNameBufferSize

Variable Type ViInt32

The number of bytes in the ViChar array that the user specifies for the AlarmName parameter.

alarmName

Variable Type ViChar[]

The buffer into which the function returns the alarm name that corresponds to the index the user specifies. The caller may pass VI_NULL for this parameter if the AlarmNameBufferSize parameter is 0.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.78. bu6100_IviLxiSync_GetTriggerSourceName

```
ViStatus bu6100_IviLxiSync_GetTriggerSourceName
(ViSession instrumentHandle, ViInt32 sourceIndex,
ViInt32 sourceNameBufferSize,
ViChar _VI_FAR sourceName[]);
```

Purpose

This function returns the physical repeated capability identifier that corresponds to the one-based index that the user specifies. If the value that the user passes for the SourceIndex parameter is less than one or greater than the value of the Trigger Source Count attribute, the function returns an empty string in the SourceName parameter and returns an error. For custom trigger sources added with the Add Trigger Source function, this function returns the trigger source name in the original casing used when Add Trigger Source was called.

Parameter List

instrumentHandle

Variable Type ViSession

Instrument handle.

sourceIndex

Variable Type ViInt32

A one-based index that defines which name to return.

sourceNameBufferSize

Variable Type ViInt32

The number of bytes in the ViChar array that the user specifies for the SourceName parameter.

sourceName

Variable Type ViChar[]

The buffer into which the function returns the source name that corresponds to the index the user specifies. The caller may pass VI_NULL for this parameter if the SourceNameBufferSize parameter is 0.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.79. bu6100_IviLxiSync_RemoveAllCustomArmAlarms

```
ViStatus bu6100_IviLxiSync_RemoveAllCustomArmAlarms
(ViSession instrumentHandle);
```

Purpose

This function removes all of the custom arm alarms that were added using the Add Arm Alarm function.

ProDAQ 6100 does not support Arm subsystem.

Parameter List

```
instrumentHandle
    Variable Type      ViSession
    Instrument handle.
```

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXI PnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXI PnP Driver Errors

5.5.80. bu6100_IviLxiSync_RemoveAllCustomArmSources

```
ViStatus bu6100_IviLxiSync_RemoveAllCustomArmSources
(ViSession instrumentHandle);
```

Purpose

This function removes all of the custom arm sources that were added using the Add Arm Source function.

ProDAQ 6100 does not support Arm subsystem.

Parameter List

```
instrumentHandle
    Variable Type      ViSession
    Instrument handle.
```

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.81. bu6100_IviLxiSync_RemoveAllCustomEvents

```
ViStatus bu6100_IviLxiSync_RemoveAllCustomEvents
(ViSession instrumentHandle);
```

Purpose

This function removes all of the custom events that were added using the Add Event function.

Parameter List

```
instrumentHandle
    Variable Type      ViSession
    Instrument handle.
```

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.82. bu6100_IviLxiSync_RemoveAllCustomTriggerSources

```
ViStatus bu6100_IviLxiSync_RemoveAllCustomTriggerSources
(ViSession instrumentHandle);
```

Purpose

This function removes all of the custom trigger sources that were added using the Add Trigger Source function.

Parameter List

```
instrumentHandle
    Variable Type      ViSession
    Instrument handle.
```

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.83. bu6100_IviLxiSync_RemoveAllTriggerAlarms

```
ViStatus bu6100_IviLxiSync_RemoveAllTriggerAlarms
(ViSession instrumentHandle);
```

Purpose

This function removes all of the trigger alarms that were added using the Add Trigger Alarm function.

Only "ALARM0" is supported by ProDAQ 6100.

Parameter List

```
instrumentHandle
    Variable Type      ViSession
    Instrument handle.
```

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.84. bu6100_IviLxiSync_RemoveArmAlarm

```
ViStatus bu6100_IviLxiSync_RemoveArmAlarm (ViSession instrumentHandle,
                                           ViConstString alarmName);
```

Purpose

This function removes an Arm Alarm.
 ProDAQ 6100 does not support Arm subsystem.

Parameter List

```
instrumentHandle
    Variable Type      ViSession
    Instrument handle.

alarmName
    Variable Type      ViConstString
    Specifies the name of the arm alarm to remove.
```

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.85. bu6100_IviLxiSync_RemoveArmSource

```
ViStatus bu6100_IviLxiSync_RemoveArmSource (ViSession instrumentHandle,
                                           ViConstString sourceName);
```

Purpose

This function removes an arm source.

ProDAQ 6100 does not support Arm subsystem.

Parameter List

instrumentHandle

Variable Type ViSession

Instrument handle.

sourceName

Variable Type ViConstString

Specifies the name of the arm source to remove.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.86. bu6100_IviLxiSync_RemoveEvent

```
ViStatus bu6100_IviLxiSync_RemoveEvent (ViSession instrumentHandle,
                                       ViConstString eventName);
```

Purpose

This function removes an event.

Parameter List

instrumentHandle

Variable Type ViSession
Instrument handle.

eventName

Variable Type ViConstString
Specifies the name of the event to remove.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.87. bu6100_IviLxiSync_RemoveTriggerAlarm

```
ViStatus bu6100_IviLxiSync_RemoveTriggerAlarm
    (ViSession instrumentHandle, ViConstString alarmName);
```

Purpose

This function removes a trigger alarm.

Only "ALARM0" is supported by ProDAQ 6100.

Parameter List

instrumentHandle

Variable Type ViSession

Instrument handle.

alarmName

Variable Type ViConstString

Specifies the name of the trigger alarm to remove.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.88. bu6100_IviLxiSync_RemoveTriggerSource

```
ViStatus bu6100_IviLxiSync_RemoveTriggerSource
    (ViSession instrumentHandle, ViConstString sourceName);
```

Purpose

This function removes a trigger source.

Parameter List

instrumentHandle

Variable Type ViSession

Instrument handle.

sourceName

Variable Type ViConstString

Specifies the name of the trigger source to remove.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the `bu6100_error_message` function. To obtain additional information about the error condition, call the `bu6100_GetError` function. To clear the error information from the driver, call the `bu6100_ClearError` function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.89. bu6100_IviLxiSync_SetSystemTime

```
ViStatus bu6100_IviLxiSync_SetSystemTime (ViSession instrumentHandle,
                                           ViReal64 timeSeconds,
                                           ViReal64 timeFractional);
```

Purpose

This function sets the 1588 time if the board operates as a 1588 clock master or as a not synchronized slave.

Parameter List

instrumentHandle

Variable Type ViSession

The Instrument Handle is used to identify the unique session or communication channel between the driver and the instrument.

If more than one instrument of the same model type is used, this Handle will be used to differentiate between them.

timeSeconds

Variable Type ViReal64

Sets the seconds portion of the 1588 time.

timeFractional

Variable Type ViReal64

Sets the fractional portion of the 1588 time.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.90. bu6100_killList

```
ViStatus bu6100_killList (ViSession instrumentHandle,
                          ViInt16 functionCard);
```

Purpose

Kills the List currently running by DSP for the specified Function Card.

Parameter List

instrumentHandle

Variable Type ViSession

The Instrument Handle is used to identify the unique session or communication channel between the driver and the instrument.

If more than one instrument of the same model type is used, this Handle will be used to differentiate between them.

functionCard

Variable Type ViInt16

Specifies the Function Card for which List should be killed.

Valid Values: 1, 2, 3, 4

Default Value: 1

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.91. bu6100_loadList

```
ViStatus bu6100_loadList (ViSession instrumentHandle,
                        ViInt16 functionCard, ViInt32 n_ofOperations,
                        ViInt32 _VI_FAR opIndexes[],
                        ViInt32 _VI_FAR varIndexes[],
                        ViInt32 _VI_FAR constants[]);
```

Purpose

Loads the List of Commands into the DSP's table of lists. DSP precompiles the List and store it in its internal memory.

Parameter List

instrumentHandle

Variable Type ViSession

The Instrument Handle is used to identify the unique session or communication channel between the driver and the instrument.

If more than one instrument of the same model type is used, this Handle will be used to differentiate between them.

functionCard

Variable Type ViInt16

Specifies the Function Card for which the List will be loaded.

Valid Values: 1, 2, 3, 4

Default Value: 1

n_ofOperations

Variable Type ViInt32

Number of operations contained in the list to be loaded. The possible values are from 1 to BU6100_MAX_LIST_LENGTH (0x40)

Default Value: 0

opIndexes

Variable Type ViInt32[]

This array should contain indexes of operations in the list.

varIndexes

Variable Type ViInt32[]

This array should contain the indexes of the List variables.

constants

Variable Type ViInt32[]

This array should contain constants.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.92. bu6100_LockSession

```
ViStatus bu6100_LockSession (ViSession instrumentHandle,
                             ViPBoolean callerHasLock);
```

Purpose

This function obtains a multithread lock on the instrument session. Before it does so, it waits until all other execution threads have released their locks on the instrument session.

Other threads might have obtained a lock on this session in the following ways:

- The user's application called bu6100_LockSession.
- A call to the instrument driver locked the session.
- A call to the IVI engine locked the session.

After your call to bu6100_LockSession returns successfully, no other threads can access the instrument session until you call bu6100_UnlockSession.

Use bu6100_LockSession and bu6100_UnlockSession around a sequence of calls to instrument driver functions if you require that the instrument retain its settings through the end of the sequence.

You can safely make nested calls to bu6100_LockSession within the same thread. To completely unlock the session, you must balance each call to bu6100_LockSession with a call to bu6100_UnlockSession. If, however, you use the Caller Has Lock parameter in all calls to bu6100_LockSession and bu6100_UnlockSession within a function, the IVI Library locks the session only once within the function regardless of the number of calls you make to bu6100_LockSession. This allows you to call bu6100_UnlockSession just once at the end of the function.

Parameter List

instrumentHandle

Variable Type ViSession

The ViSession handle that you obtain from the bu6100_init or bu6100_InitWithOptions function. The handle identifies a particular instrument session.

Default Value: None

callerHasLock

Variable Type ViBoolean (passed by reference)

This parameter serves as a convenience. If you do not want to use this parameter, pass VI_NULL.

Use this parameter in complex functions to keep track of whether you obtain a lock and therefore need to unlock the session. Pass the address of a local ViBoolean variable. In the declaration of the local variable, initialize it to VI_FALSE. Pass the address of the same local variable to any other calls you make to bu6100_LockSession or bu6100_UnlockSession in the same function.

The parameter is an input/output parameter. bu6100_LockSession and bu6100_UnlockSession each inspect the current value and take the following actions:

- If the value is VI_TRUE, bu6100_LockSession does not lock the session again. If the value is VI_FALSE, bu6100_LockSession obtains the lock and sets the value of the parameter to VI_TRUE.
- If the value is VI_FALSE, bu6100_UnlockSession does not attempt to unlock the session. If the value is VI_TRUE, bu6100_UnlockSession releases the lock and sets the value of the parameter to VI_FALSE.

Thus, you can, call `bu6100_UnlockSession` at the end of your function without worrying about whether you actually have the lock.

Example:

```

ViStatus TestFunc (ViSession vi, ViInt32 flags)
{
    ViStatus error = VI_SUCCESS;
    ViBoolean haveLock = VI_FALSE;

    if (flags & BIT_1)
    {
        viCheckErr( bu6100_LockSession(vi, &haveLock));
        viCheckErr( TakeAction1(vi));
        if (flags & BIT_2)
        {
            viCheckErr( bu6100_UnlockSession(vi, &haveLock));
            viCheckErr( TakeAction2(vi));
            viCheckErr( bu6100_LockSession(vi, &haveLock);
        }
        if (flags & BIT_3)
            viCheckErr( TakeAction3(vi));
    }

    Error:
    /*
    At this point, you cannot really be sure that
    you have the lock. Fortunately, the haveLock
    variable takes care of that for you.
    */
    bu6100_UnlockSession(vi, &haveLock);
    return error;
}

```

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.93. bu6100_pulseTrig

```
ViStatus bu6100_pulseTrig (ViSession instrumentHandle,
                          ViInt16 destination, ViInt16 function);
```

Purpose

Send a pulse to the specified destination.

Parameter List

instrumentHandle

Variable Type ViSession

The Instrument Handle is used to identify the unique session or communication channel between the driver and the instrument.

If more than one instrument of the same model type is used, this Handle will be used to differentiate between them.

destination

Variable Type ViInt16

Selects the trigger destination.

Valid Values:

BU6100_FCTrigInA1	0	FC 1 Trigger Input A
BU6100_FCTrigInA2	1	FC 2 Trigger Input A
BU6100_FCTrigInA3	2	FC 3 Trigger Input A
BU6100_FCTrigInA4	3	FC 4 Trigger Input A
BU6100_FCTrigInB1	8	FC 1 Trigger Input B
BU6100_FCTrigInB2	9	FC 2 Trigger Input B
BU6100_FCTrigInB3	10	FC 3 Trigger Input B
BU6100_FCTrigInB4	11	FC 4 Trigger Input B
BU6100_lviTrigOut0	16	LXITrig0
BU6100_lviTrigOut1	17	LXITrig1
BU6100_lviTrigOut2	18	LXITrig2
BU6100_lviTrigOut3	19	LXITrig3
BU6100_lviTrigOut4	20	LXITrig4
BU6100_lviTrigOut5	21	LXITrig5
BU6100_lviTrigOut6	22	LXITrig6
BU6100_lviTrigOut7	23	LXITrig7

Default Value: 0 (BU6100_FCTrigInA1)

function

Variable Type ViInt16

Specifies the function which will be performed on the selected trigger line.

Valid Values:

BU6100_TRIG_DEASSERT	0	Put the trigger line to inactive state
BU6100_TRIG_ASSERT	1	Put the trigger line to active state
BU6100_TRIG_PULSE	2	Deasserts, asserts and the deasserts again the trigger line, forming a short pulse.

Default Value: 0 (BU6100_TRIG_DEASSERT)

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the

bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.94. bu6100_pulseTrigSynch

```
ViStatus bu6100_pulseTrigSynch (ViSession instrumentHandle,
                               ViInt32 triggerMask, ViInt16 function);
```

Purpose

Asserts/Deasserts or Sends a pulse to the specified trigger lines.

Parameter List

instrumentHandle

Variable Type ViSession

The Instrument Handle is used to identify the unique session or communication channel between the driver and the instrument.

If more than one instrument of the same model type is used, this Handle will be used to differentiate between them.

triggerMask

Variable Type ViInt32

Selects the trigger lines to be operated. This value is a bitmask of the following bits:

- Bit 0 FC 1 Trigger Input A
- ...
- Bit 3 FC 4 Trigger Input A

- Bit 8 FC 1 Trigger Input B
- ...
- Bit 11 FC 4 Trigger Input B

- Bit 16 LXITrig0
- ..
- Bit 23 LXITrig7

Default Value: 0

function

Variable Type ViInt16

Specifies the function which will be performed on the selected trigger lines.

Valid Values:

- BU6100_TRIG_DEASSERT 0 Put the trigger line to inactive state
- BU6100_TRIG_ASSERT 1 Put the trigger line to active state
- BU6100_TRIG_PULSE 2 Deasserts, asserts and the deasserts again the trigger line, forming a short pulse.

Default Value: 0 (BU6100_TRIG_DEASSERT)

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning

0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types	
3FFA0000 to 3FFA1FFF	IVI	Warnings
3FFF0000 to 3FFFFFFF	VISA	Warnings
3FFC0000 to 3FFCFFFF	VXIbP	Driver Warnings
BFFA0000 to BFFA1FFF	IVI	Errors
BFFF0000 to BFFFFFFF	VISA	Errors
BFFC0000 to BFFCFFFF	VXIbP	Driver Errors

5.5.95. bu6100_readBoardTemp

```
ViStatus bu6100_readBoardTemp (ViSession instrumentHandle,
                               ViPReal64 temperature1,
                               ViPReal64 temperature2);
```

Purpose

This function reads the temperature from the temperature sensors fitted on the module.

Parameter List

instrumentHandle

Variable Type ViSession

The Instrument Handle is used to identify the unique session or communication channel between the driver and the instrument.

If more than one instrument of the same model type is used, this Handle will be used to differentiate between them.

temperature1

Variable Type ViReal64 (passed by reference)

This parameter return the temperature in degrees Celsius from the on-board temperature sensor 1.

temperature2

Variable Type ViReal64 (passed by reference)

This parameter return the temperature in degrees Celsius from the on-board temperature sensor 2.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIIPnP Driver Errors

5.5.96. bu6100_readCB

```
ViStatus bu6100_readCB (ViSession instrumentHandle,
                       ViInt16 functionCard, ViInt32 n_ofSamples,
                       ViInt32 _VI_FAR data[]);
```

Purpose

This function retrieves the specified amount of data from the Circular Buffer for particular Function Card. The function doesn't check for data availability, the program should be sure that the requested data is available by bu6100_getCBstatus() function call.

Parameter List

instrumentHandle

Variable Type ViSession

The Instrument Handle is used to identify the unique session or communication channel between the driver and the instrument.

If more than one instrument of the same model type is used, this Handle will be used to differentiate between them.

functionCard

Variable Type ViInt16

Specifies the Function Card for which the Circular Buffer will be configured.

Valid Values: 1, 2, 3, 4

Default Value: 1

n_ofSamples

Variable Type ViInt32

This parameter specifies the number of 32-bit words to read from the Circular Buffer.

data

Variable Type ViInt32[]

This parameter returns the data retrieved from the Circular Buffer. This array should be allocated prior to function call with appropriate size to hold all requested data.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different

include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.97. bu6100_readDram

```
ViStatus bu6100_readDram (ViSession instrumentHandle, ViInt32 offset,
                          ViInt32 count, ViInt32 _VI_FAR readData[]);
```

Purpose

Reads the block of data from specified address of DRAM module.

Parameter List

instrumentHandle

Variable Type ViSession

The Instrument Handle is used to identify the unique session or communication channel between the driver and the instrument.

If more than one instrument of the same model type is used, this Handle will be used to differentiate between them.

offset

Variable Type ViInt32

Selects the start address in DRAM module.

Default Value: 0

count

Variable Type ViInt32

Number of elements of data (32-bit words) to read from the DRAM module.

Default Value: 1

readData

Variable Type ViInt32[]

An array to receive the block of data read from the DRAM module.

This array must be declared at least as large as the number of elements to be read from the instrument - failure to do so may result in a system failure.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the `bu6100_error_message` function. To obtain additional information about the error condition, call the `bu6100_GetError` function. To clear the error information from the driver, call the `bu6100_ClearError` function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIbP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIbP Driver Errors

5.5.98. bu6100_ReadInstrData

```
ViStatus bu6100_ReadInstrData (ViSession instrumentHandle,
                               ViInt32 number_ofBytesToRead,
                               ViChar _VI_FAR readBuffer[],
                               ViPInt32 numBytesRead);
```

Purpose

This function reads data from the instrument.

Parameter List

instrumentHandle

Variable Type ViSession

The ViSession handle that you obtain from the bu6100_init or bu6100_InitWithOptions function. The handle identifies a particular instrument session.

Default Value: None

number_ofBytesToRead

Variable Type ViInt32

Pass the maximum number of bytes to read from the instruments.

Valid Range: 0 to the number of elements in the Read Buffer

Default Value: 256

readBuffer

Variable Type ViChar[]

After this function executes, this parameter contains the data that was read from the instrument.

numBytesRead

Variable Type ViInt32 (passed by reference)

Returns the number of bytes actually read from the instrument and stored in the Read Buffer.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings

3FFC0000 to 3FFCFFFF	VXIPnP	Driver Warnings
BFFA0000 to BFFA1FFF	IVI	Errors
BFFF0000 to BFFFFFFF	VISA	Errors
BFFC0000 to BFFCFFFF	VXIPnP	Driver Errors

5.5.99. bu6100_readSigLinesStat

```
ViStatus bu6100_readSigLinesStat (ViSession instrumentHandle,
                                  ViPInt32 FCError,
                                  ViPInt32 FCDirectInterrupt);
```

Purpose

Returns the status of the Function Card special signal lines coming to the LIST processor board.

Parameter List

instrumentHandle

Variable Type ViSession

The Instrument Handle is used to identify the unique session or communication channel between the driver and the instrument.

If more than one instrument of the same model type is used, this Handle will be used to differentiate between them.

FCError

Variable Type ViInt32 (passed by reference)

Returns the status of the FC_DE signal lines.

bit 0 corresponds to FC_DE line of Function Card 1
 ...
 bit 3 corresponds to FC_DE line of Function Card 4

FCDirectInterrupt

Variable Type ViInt32 (passed by reference)

Returns the status of the FC_DI signal lines.

bit 0 corresponds to FC_DI line of Function Card 1
 ...
 bit 3 corresponds to FC_DI line of Function Card 4

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
-----	-----
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.100. bu6100_readVRTemp

```
ViStatus bu6100_readVRTemp (ViSession instrumentHandle,
                           ViPReal64 temperature);
```

Purpose

This function reads the temperature from the sensor fitted to voltage reference module.

Parameter List

instrumentHandle

Variable Type ViSession

The Instrument Handle is used to identify the unique session or communication channel between the driver and the instrument.

If more than one instrument of the same model type is used, this Handle will be used to differentiate between them.

temperature

Variable Type ViReal64 (passed by reference)

This parameter return the temperature in degrees Celsius.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.101. bu6100_removeIrqService

```
ViStatus bu6100_removeIrqService (ViSession instrumentHandle,
                                  ViInt16 source);
```

Purpose

Removes the IRQ watcher or IRQ handler from the Interrupt Service dispatching mechanism and releases the system resources.

Parameter List

instrumentHandle

Variable Type ViSession

The Instrument Handle is used to identify the unique session or communication channel between the driver and the instrument.

If more than one instrument of the same model type is used, this Handle will be used to differentiate between them

source

Variable Type ViInt16

The trigger line for which Interrupt Service will be removed.

Valid Values:

bu3100_FCTrigOutA1	0	FC 1 Trigger Output A
bu3100_FCTrigOutA2	1	FC 2 Trigger Output A
bu3100_FCTrigOutA3	2	FC 3 Trigger Output A
bu3100_FCTrigOutA4	3	FC 4 Trigger Output A
bu3100_FCTrigOutB1	8	FC 1 Trigger Output B
bu3100_FCTrigOutB2	9	FC 2 Trigger Output B
bu3100_FCTrigOutB3	10	FC 3 Trigger Output B
bu3100_FCTrigOutB4	11	FC 4 Trigger Output B
bu3100_FCCircBuf1	16	FC 1 Circular Buffer
bu3100_FCCircBuf2	17	FC 2 Circular Buffer
bu3100_FCCircBuf3	18	FC 3 Circular Buffer
bu3100_FCCircBuf4	19	FC 4 Circular Buffer

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPInP Driver Warnings

BFFA0000 to BFFA1FFF	IVI	Errors
BFFF0000 to BFFFFFFF	VISA	Errors
BFFC0000 to BFFCFFFF	VXIIPnP	Driver Errors

5.5.102. bu6100_reset

```
ViStatus bu6100_reset (ViSession instrumentHandle);
```

Purpose

This function resets the instrument to a known state and sends initialization commands to the instrument. The initialization commands set instrument settings such as Headers Off, Short Command form, and Data Transfer Binary to the state necessary for the operation of the instrument driver.

Parameter List

instrumentHandle

Variable Type ViSession

The ViSession handle that you obtain from the bu6100_init or bu6100_initWithOptions function. The handle identifies a particular instrument session.

Default Value: None

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.103. bu6100_ResetInterchangeCheck

```
ViStatus bu6100_ResetInterchangeCheck (ViSession instrumentHandle);
```

Purpose

When developing a complex test system that consists of multiple test modules, it is generally a good idea to design the test modules so that they can run in any order. To do so requires ensuring that each test module completely configures the state of each instrument it uses. If a particular test module does not completely configure the state of an instrument, the state of the instrument depends on the configuration from a previously executed test module. If you execute the test modules in a different order, the behavior of the instrument and therefore the entire test module is likely to change. This change in behavior is generally instrument specific and represents an interchangeability problem.

You can use this function to test for such cases. After you call this function, the interchangeability checking algorithms in the specific driver ignore all previous configuration operations. By calling this function at the beginning of a test module, you can determine whether the test module has dependencies on the operation of previously executed test modules.

This function does not clear the interchangeability warnings from the list of previously recorded interchangeability warnings. If you want to guarantee that the bu6100_GetNextInterchangeWarning function only returns those interchangeability warnings that are generated after calling this function, you must clear the list of interchangeability warnings. You can clear the interchangeability warnings list by repeatedly calling the bu6100_GetNextInterchangeWarning function until no more interchangeability warnings are returned. If you are not interested in the content of those warnings, you can call the bu6100_ClearInterchangeWarnings function.

Parameter List

instrumentHandle

Variable Type	ViSession
---------------	-----------

The ViSession handle that you obtain from the bu6100_init or bu6100_InitWithOptions function. The handle identifies a particular instrument session.

Default Value: None

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.104. bu6100_ResetWithDefaults

```
ViStatus bu6100_ResetWithDefaults (ViSession instrumentHandle);
```

Purpose

This function resets the instrument and applies initial user specified settings from the Logical Name which was used to initialize the session. If the session was created without a Logical Name, this function is equivalent to the bu6100_reset function.

Parameter List

instrumentHandle

Variable Type ViSession

The ViSession handle that you obtain from the bu6100_init or bu6100_initWithOptions function. The handle identifies a particular instrument session.

Default Value: None

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.105. bu6100_revision_query

```
ViStatus bu6100_revision_query (ViSession instrumentHandle,
                               ViChar _VI_FAR instrumentDriverRevision[],
                               ViChar _VI_FAR firmwareRevision[]);
```

Purpose

This function returns the revision numbers of the instrument driver and instrument firmware.

Parameter List

instrumentHandle

Variable Type ViSession

The ViSession handle that you obtain from the bu6100_init or bu6100_initWithOptions function. The handle identifies a particular instrument session.

Default Value: None

instrumentDriverRevision

Variable Type ViChar[]

Returns the instrument driver software revision numbers in the form of a string. You must pass a ViChar array with at least 256 bytes.

firmwareRevision

Variable Type ViChar[]

Returns the instrument firmware revision numbers in the form of a string. You must pass a ViChar array with at least 256 bytes.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors

BFFF0000 to BFFFFFFF	VISA	Errors
BFFC0000 to BFFCFFFF	VXIPInP	Driver Errors

5.5.106. bu6100_self_test

```
ViStatus bu6100_self_test (ViSession instrumentHandle,
                          ViPInt16 selfTestResult,
                          ViChar _VI_FAR selfTestMessage[]);
```

Purpose

This function runs the instrument's self test routine and returns the test result(s).

Parameter List

instrumentHandle

Variable Type ViSession

The ViSession handle that you obtain from the bu6100_init or bu6100_initWithOptions function. The handle identifies a particular instrument session.

Default Value: None

selfTestResult

Variable Type ViInt16 (passed by reference)

This control contains the value returned from the instrument self test. Zero means success. For any other code, see the device's operator's manual.

Self-Test Code	Description
0	Passed self test
1	Self test failed

selfTestMessage

Variable Type ViChar[]

Returns the self-test response string from the instrument. See the device's operation manual for an explanation of the string's contents.

You must pass a ViChar array with at least 256 bytes.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different

include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.107. bu6100_set1588config

```
ViStatus bu6100_set1588config (ViSession instrumentHandle,
                               ViInt32 enabled, ViInt32 threshold,
                               ViInt32 clockDivider, ViInt32 pid_p,
                               ViInt32 pid_i, ViInt32 pid_d);
```

Purpose

This function sets the configuration of the 1588 interface of the ProDAQ 6100 module.

Parameter List

instrumentHandle

Variable Type ViSession

The Instrument Handle is used to identify the unique session or communication channel between the driver and the instrument.

If more than one instrument of the same model type is used, this Handle will be used to differentiate between them.

enabled

Variable Type ViInt32

This parameter sets whether the 1588 interface of the ProDAQ 6100 module is disabled, enabled or enabled in slave-only mode. In the slave-only mode the 6100 will never take a role of the 1588 clock master.

Possible values are:

BU6100_1588_DISABLED	0	1588 interface is disabled;
BU6100_1588_ENABLED	1	1588 interface is enabled;
BU6100_1588_ENABLED_SLAVE_ONLY	2	1588 interface is enabled as a slave-only device;

threshold

Variable Type ViInt32

This parameter sets the synchronization threshold (in nanoseconds). It is used when the 6100 module operates as a 1588 slave device. If the offset from the 1588 Master is less than the specified threshold, the module is considered as synchronized. If the offset is bigger than the threshold, the module status will be "not synchronized".

clockDivider

Variable Type ViInt32

This parameter sets the content of the TCLK divider of the 1588 interface.

pid_p

Variable Type ViInt32

This parameter sets the 'p' coefficient of the PTP PID control loop.

pid_i

Variable Type ViInt32

This parameter sets the 'i' coefficient of the PTP PID control loop.

pid_d

Variable Type ViInt32

This parameter sets the 'd' coefficient of the PTP PID control loop.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the `bu6100_error_message` function. To obtain additional information about the error condition, call the `bu6100_GetError` function. To clear the error information from the driver, call the `bu6100_ClearError` function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.108. bu6100_SetAttributeViBoolean

```
ViStatus bu6100_SetAttributeViBoolean (ViSession instrumentHandle,
                                       ViChar _VI_FAR channelName[],
                                       ViAttr attributeID,
                                       ViBoolean attributeValue);
```

Purpose

This function sets the value of a ViBoolean attribute.

This is a low-level function that you can use to set the values of instrument-specific attributes and inherent IVI attributes. If the attribute represents an instrument state, this function performs instrument I/O in the following cases:

- State caching is disabled for the entire session or for the particular attribute.
- State caching is enabled and the currently cached value is invalid or is different than the value you specify.

This instrument driver contains high-level functions that set most of the instrument attributes. It is best to use the high-level driver functions as much as possible. They handle order dependencies and multithread locking for you. In addition, they perform status checking only after setting all of the attributes. In contrast, when you set multiple attributes using the SetAttribute functions, the functions check the instrument status after each call.

Also, when state caching is enabled, the high-level functions that configure multiple attributes perform instrument I/O only for the attributes whose value you change. Thus, you can safely call the high-level functions without the penalty of redundant instrument I/O.

Parameter List

instrumentHandle

Variable Type ViSession

The ViSession handle that you obtain from the bu6100_init or bu6100_InitWithOptions function. The handle identifies a particular instrument session.

Default Value: None

channelName

Variable Type ViChar[]

If the attribute is channel-based, this parameter specifies the name of the channel on which to set the value of the attribute. If the attribute is not channel-based, then pass VI_NULL or an empty string.

Valid Channel Names: 1

Default Value: ""

attributeID

Variable Type ViAttr

Pass the ID of an attribute.

From the function panel window, you can use this control as follows.

- Click on the control or press <ENTER>, <spacebar>, or <ctrl-down arrow>, to display a dialog box containing a hierarchical list of the available attributes. Attributes whose value cannot be set are dim. Help text is shown for

each attribute. Select an attribute by double-clicking on it or by selecting it and then pressing <ENTER>.

Read-only attributes appear dim in the list box. If you select a read-only attribute, an error message appears.

A ring control at the top of the dialog box allows you to see all IVI attributes or only the attributes of the ViBoolean type. If you choose to see all IVI attributes, the data types appear to the right of the attribute names in the list box. Attributes with data types other than ViBoolean are dim. If you select an attribute data type that is dim, LabWindows/CVI transfers you to the function panel for the corresponding function that is consistent with the data type.

- If you want to enter a variable name, press <CTRL-T> to change this ring control to a manual input box.
- If the attribute in this ring control has named constants as valid values, you can view the constants by moving to the Attribute Value control and pressing <ENTER>.

attributeValue

Variable Type ViBoolean

Pass the value to which you want to set the attribute.

From the function panel window, you can use this control as follows.

- If the attribute currently showing in the Attribute ID ring control has constants as valid values, you can view a list of the constants by pressing <ENTER> on this control. Select a value by double-clicking on it or by selecting it and then pressing <ENTER>.

Note: Some of the values might not be valid depending on the current settings of the instrument session.

Default Value: none

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors

BFFF0000 to BFFFFFFF	VISA	Errors
BFFC0000 to BFFCFFFF	VXIPIpP	Driver Errors

5.5.109. bu6100_SetAttributeViInt32

```
ViStatus bu6100_SetAttributeViInt32 (ViSession instrumentHandle,
                                     ViChar _VI_FAR channelName[],
                                     ViAttr attributeID,
                                     ViInt32 attributeValue);
```

Purpose

This function sets the value of a ViInt32 attribute.

This is a low-level function that you can use to set the values of instrument-specific attributes and inherent IVI attributes. If the attribute represents an instrument state, this function performs instrument I/O in the following cases:

- State caching is disabled for the entire session or for the particular attribute.
- State caching is enabled and the currently cached value is invalid or is different than the value you specify.

This instrument driver contains high-level functions that set most of the instrument attributes. It is best to use the high-level driver functions as much as possible. They handle order dependencies and multithread locking for you. In addition, they perform status checking only after setting all of the attributes. In contrast, when you set multiple attributes using the SetAttribute functions, the functions check the instrument status after each call.

Also, when state caching is enabled, the high-level functions that configure multiple attributes perform instrument I/O only for the attributes whose value you change. Thus, you can safely call the high-level functions without the penalty of redundant instrument I/O.

Parameter List

instrumentHandle

Variable Type ViSession

The ViSession handle that you obtain from the bu6100_init or bu6100_InitWithOptions function. The handle identifies a particular instrument session.

Default Value: None

channelName

Variable Type ViChar[]

If the attribute is channel-based, this parameter specifies the name of the channel on which to set the value of the attribute. If the attribute is not channel-based, then pass VI_NULL or an empty string.

Valid Channel Names: 1

Default Value: ""

attributeID

Variable Type ViAttr

Pass the ID of an attribute.

From the function panel window, you can use this control as follows.

- Click on the control or press <ENTER>, <spacebar>, or <ctrl-down arrow>, to display a dialog box containing a hierarchical list of the available attributes. Attributes

whose value cannot be set are dim. Help text is shown for each attribute. Select an attribute by double-clicking on it or by selecting it and then pressing <ENTER>.

Read-only attributes appear dim in the list box. If you select a read-only attribute, an error message appears.

A ring control at the top of the dialog box allows you to see all IVI attributes or only the attributes of the ViInt32 type. If you choose to see all IVI attributes, the data types appear to the right of the attribute names in the list box. Attributes with data types other than ViInt32 are dim. If you select an attribute data type that is dim, LabWindows/CVI transfers you to the function panel for the corresponding function that is consistent with the data type.

- If you want to enter a variable name, press <CTRL-T> to change this ring control to a manual input box.
- If the attribute in this ring control has named constants as valid values, you can view the constants by moving to the Attribute Value control and pressing <ENTER>.

attributeValue

Variable Type ViInt32

Pass the value to which you want to set the attribute.

From the function panel window, you can use this control as follows.

- If the attribute currently showing in the Attribute ID ring control has constants as valid values, you can view a list of the constants by pressing <ENTER> on this control. Select a value by double-clicking on it or by selecting it and then pressing <ENTER>.

Note: Some of the values might not be valid depending on the current settings of the instrument session.

Default Value: none

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors

BFFF0000 to BFFFFFFF	VISA	Errors
BFFC0000 to BFFCFFFF	VXIIPnP	Driver Errors

5.5.110. bu6100_SetAttributeViReal64

```
ViStatus bu6100_SetAttributeViReal64 (ViSession instrumentHandle,
                                       ViChar _VI_FAR channelName[],
                                       ViAttr attributeID,
                                       ViReal64 attributeValue);
```

Purpose

This function sets the value of a ViReal64 attribute.

This is a low-level function that you can use to set the values of instrument-specific attributes and inherent IVI attributes. If the attribute represents an instrument state, this function performs instrument I/O in the following cases:

- State caching is disabled for the entire session or for the particular attribute.
- State caching is enabled and the currently cached value is invalid or is different than the value you specify.

This instrument driver contains high-level functions that set most of the instrument attributes. It is best to use the high-level driver functions as much as possible. They handle order dependencies and multithread locking for you. In addition, they perform status checking only after setting all of the attributes. In contrast, when you set multiple attributes using the SetAttribute functions, the functions check the instrument status after each call.

Also, when state caching is enabled, the high-level functions that configure multiple attributes perform instrument I/O only for the attributes whose value you change. Thus, you can safely call the high-level functions without the penalty of redundant instrument I/O.

Parameter List

instrumentHandle

Variable Type ViSession

The ViSession handle that you obtain from the bu6100_init or bu6100_InitWithOptions function. The handle identifies a particular instrument session.

Default Value: None

channelName

Variable Type ViChar[]

If the attribute is channel-based, this parameter specifies the name of the channel on which to set the value of the attribute. If the attribute is not channel-based, then pass VI_NULL or an empty string.

Valid Channel Names: 1

Default Value: ""

attributeID

Variable Type ViAttr

Pass the ID of an attribute.

From the function panel window, you can use this control as follows.

- Click on the control or press <ENTER>, <spacebar>, or <ctrl-down arrow>, to display a dialog box containing a hierarchical list of the available attributes. Attributes whose value cannot be set are dim. Help text is shown for

each attribute. Select an attribute by double-clicking on it or by selecting it and then pressing <ENTER>.

Read-only attributes appear dim in the list box. If you select a read-only attribute, an error message appears.

A ring control at the top of the dialog box allows you to see all IVI attributes or only the attributes of the ViReal64 type. If you choose to see all IVI attributes, the data types appear to the right of the attribute names in the list box. Attributes with data types other than ViReal64 are dim. If you select an attribute data type that is dim, LabWindows/CVI transfers you to the function panel for the corresponding function that is consistent with the data type.

- If you want to enter a variable name, press <CTRL-T> to change this ring control to a manual input box.
- If the attribute in this ring control has named constants as valid values, you can view the constants by moving to the Attribute Value control and pressing <ENTER>.

attributeValue

Variable Type ViReal64

Pass the value to which you want to set the attribute.

From the function panel window, you can use this control as follows.

- If the attribute currently showing in the Attribute ID ring control has constants as valid values, you can view a list of the constants by pressing <ENTER> on this control. Select a value by double-clicking on it or by selecting it and then pressing <ENTER>.

Note: Some of the values might not be valid depending on the current settings of the instrument session.

Default Value: none

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors

BFFF0000 to BFFFFFFF	VISA	Errors
BFFC0000 to BFFCFFFF	VXIPInP	Driver Errors

5.5.111. bu6100_SetAttributeViSession

```
ViStatus bu6100_SetAttributeViSession (ViSession instrumentHandle,
                                       ViChar _VI_FAR channelName[],
                                       ViAttr attributeID,
                                       ViSession attributeValue);
```

Purpose

This function sets the value of a ViSession attribute.

This is a low-level function that you can use to set the values of instrument-specific attributes and inherent IVI attributes. If the attribute represents an instrument state, this function performs instrument I/O in the following cases:

- State caching is disabled for the entire session or for the particular attribute.
- State caching is enabled and the currently cached value is invalid or is different than the value you specify.

This instrument driver contains high-level functions that set most of the instrument attributes. It is best to use the high-level driver functions as much as possible. They handle order dependencies and multithread locking for you. In addition, they perform status checking only after setting all of the attributes. In contrast, when you set multiple attributes using the SetAttribute functions, the functions check the instrument status after each call.

Also, when state caching is enabled, the high-level functions that configure multiple attributes perform instrument I/O only for the attributes whose value you change. Thus, you can safely call the high-level functions without the penalty of redundant instrument I/O.

Parameter List

instrumentHandle

Variable Type ViSession

The ViSession handle that you obtain from the bu6100_init or bu6100_InitWithOptions function. The handle identifies a particular instrument session.

Default Value: None

channelName

Variable Type ViChar[]

If the attribute is channel-based, this parameter specifies the name of the channel on which to set the value of the attribute. If the attribute is not channel-based, then pass VI_NULL or an empty string.

Valid Channel Names: 1

Default Value: ""

attributeID

Variable Type ViAttr

Pass the ID of an attribute.

From the function panel window, you can use this control as follows.

- Click on the control or press <ENTER>, <spacebar>, or <ctrl-down arrow>, to display a dialog box containing a hierarchical list of the available attributes. Attributes

whose value cannot be set are dim. Help text is shown for each attribute. Select an attribute by double-clicking on it or by selecting it and then pressing <ENTER>.

Read-only attributes appear dim in the list box. If you select a read-only attribute, an error message appears.

A ring control at the top of the dialog box allows you to see all IVI attributes or only the attributes of the ViSession type. If you choose to see all IVI attributes, the data types appear to the right of the attribute names in the list box. Attributes with data types other than ViSession are dim. If you select an attribute data type that is dim, LabWindows/CVI transfers you to the function panel for the corresponding function that is consistent with the data type.

- If you want to enter a variable name, press <CTRL-T> to change this ring control to a manual input box.
- If the attribute in this ring control has named constants as valid values, you can view the constants by moving to the Attribute Value control and pressing <ENTER>.

attributeValue

Variable Type ViSession

Pass the value to which you want to set the attribute.

From the function panel window, you can use this control as follows.

- If the attribute currently showing in the Attribute ID ring control has constants as valid values, you can view a list of the constants by pressing <ENTER> on this control. Select a value by double-clicking on it or by selecting it and then pressing <ENTER>.

Note: Some of the values might not be valid depending on the current settings of the instrument session.

Default Value: none

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors

BFFF0000 to BFFFFFFF	VISA	Errors
BFFC0000 to BFFCFFFF	VXIPnP	Driver Errors

5.5.112. bu6100_SetAttributeViString

```
ViStatus bu6100_SetAttributeViString (ViSession instrumentHandle,
                                     ViChar _VI_FAR channelName[],
                                     ViAttr attributeID,
                                     ViChar _VI_FAR attributeValue[]);
```

Purpose

This function sets the value of a ViString attribute.

This is a low-level function that you can use to set the values of instrument-specific attributes and inherent IVI attributes. If the attribute represents an instrument state, this function performs instrument I/O in the following cases:

- State caching is disabled for the entire session or for the particular attribute.
- State caching is enabled and the currently cached value is invalid or is different than the value you specify.

This instrument driver contains high-level functions that set most of the instrument attributes. It is best to use the high-level driver functions as much as possible. They handle order dependencies and multithread locking for you. In addition, they perform status checking only after setting all of the attributes. In contrast, when you set multiple attributes using the SetAttribute functions, the functions check the instrument status after each call.

Also, when state caching is enabled, the high-level functions that configure multiple attributes perform instrument I/O only for the attributes whose value you change. Thus, you can safely call the high-level functions without the penalty of redundant instrument I/O.

Parameter List

instrumentHandle

Variable Type ViSession

The ViSession handle that you obtain from the bu6100_init or bu6100_InitWithOptions function. The handle identifies a particular instrument session.

Default Value: None

channelName

Variable Type ViChar[]

If the attribute is channel-based, this parameter specifies the name of the channel on which to set the value of the attribute. If the attribute is not channel-based, then pass VI_NULL or an empty string.

Valid Channel Names: 1

Default Value: ""

attributeID

Variable Type ViAttr

Pass the ID of an attribute.

From the function panel window, you can use this control as follows.

- Click on the control or press <ENTER>, <spacebar>, or <ctrl-down arrow>, to display a dialog box containing a hierarchical list of the available attributes. Attributes whose value cannot be set are dim. Help text is shown for

each attribute. Select an attribute by double-clicking on it or by selecting it and then pressing <ENTER>.

Read-only attributes appear dim in the list box. If you select a read-only attribute, an error message appears.

A ring control at the top of the dialog box allows you to see all IVI attributes or only the attributes of the ViString type. If you choose to see all IVI attributes, the data types appear to the right of the attribute names in the list box. Attributes with data types other than ViString are dim. If you select an attribute data type that is dim, LabWindows/CVI transfers you to the function panel for the corresponding function that is consistent with the data type.

- If you want to enter a variable name, press <CTRL-T> to change this ring control to a manual input box.
- If the attribute in this ring control has named constants as valid values, you can view the constants by moving to the Attribute Value control and pressing <ENTER>.

attributeValue

Variable Type ViChar[]

Pass the value to which you want to set the attribute.

From the function panel window, you can use this control as follows.

- If the attribute currently showing in the Attribute ID ring control has constants as valid values, you can view a list of the constants by pressing <ENTER> on this control. Select a value by double-clicking on it or by selecting it and then pressing <ENTER>.

Note: Some of the values might not be valid depending on the current settings of the instrument session.

Default Value: none

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors

BFFF0000 to BFFFFFFF	VISA	Errors
BFFC0000 to BFFCFFFF	VXIPIpP	Driver Errors

5.5.113. bu6100_setConfigCB

```
ViStatus bu6100_setConfigCB (ViSession instrumentHandle,
                             ViInt16 functionCard, ViInt32 function,
                             ViInt32 FIFOAddress, ViInt32 address,
                             ViInt32 length, ViInt32 threshold);
```

Purpose

Configures the Circular Buffer for particular Function Card.

Parameter List

instrumentHandle

Variable Type ViSession

The Instrument Handle is used to identify the unique session or communication channel between the driver and the instrument.

If more than one instrument of the same model type is used, this Handle will be used to differentiate between them.

functionCard

Variable Type ViInt16

Specifies the Function Card for which the Circular Buffer will be configured.

Valid Values: 1, 2, 3, 4.

function

Variable Type ViInt32

This parameter specifies the type of access to Circular Buffer which will be performed by DSP. If user doesn't want to change the function setting, the value bu3100_NO_CHANGE (-1) should be used.

Valid Values:

bu3100_NO_CHANGE	-1	
bu3100_LIST_READ16	0	16-bit Packed block read
bu3100_LIST_READ32	1	32-bit block read
bu3100_LIST_READ64	2	64-bit block read
bu3100_LIST_WRITE16	3	16-bit packed block write
bu3100_LIST_WRITE32	4	32-bit block write
bu3100_LIST_WRITE64	5	64-bit block write

Default Value: -1

FIFOAddress

Variable Type ViInt32

This parameter specifies the Address of Function Card FIFO in the Function Card address space. If user doesn't want to change the FIFO address setting, the value bu3100_NO_CHANGE (-1) should be used.

Default Value: -1

address

Variable Type ViInt32

This parameter specifies the Starting Address of the Circular Buffer in bu6100 DRAM. If other than default Circular buffer will be used, this address might be obtained by bu6100_allocDram() function call. If user doesn't want to change the address setting, the value bu3100_NO_CHANGE (-1) should be used.

Default Value: -1

length

Variable Type ViInt32

This parameter specifies the length of the Circular Buffer in 32-bit words. If user doesn't want to change the length setting, the value bu3100_NO_CHANGE (-1) should be used.

Default Value: -1

threshold

Variable Type ViInt32

This parameter specifies the threshold value - the number of 32-bit words, after collection of which the DSP will send a signal (interrupt) to the VXI host. If no asynchronous mechanism supposed to be used, value '0' should be written. If user doesn't want to change the threshold setting, the value bu3100_NO_CHANGE (-1) should be used.

Default Value: -1

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.114. bu6100_setFcCclk

```
ViStatus bu6100_setFcCclk (ViSession instrumentHandle,
                          ViInt16 functionCard, ViInt32 CCLKSource);
```

Purpose

This function selects the source of the Common Clock (CCLK) for the given Function Card.

Parameter List

instrumentHandle

Variable Type ViSession

The Instrument Handle is used to identify the unique session or communication channel between the driver and the instrument.

If more than one instrument of the same model type is used, this Handle will be used to differentiate between them.

functionCard

Variable Type ViInt16

The function card to access.
Valid Values: 1, 2, 3, 4.

CCLKSource

Variable Type ViInt32

Specifies the source for the Function Card Common Clock.

Valid Values:

BU6100_CCLK_0	0	CCLK Disabled and forced to '0'
BU6100_CCLK_1	1	CCLK Disabled and forced to '1'
BU6100_CCLK_10	2	CCLK Connected to CLK10
BU6100_CCLK_5	3	CCLK Connected to CLK10/2
BU6100_CCLK_2	4	CCLK Connected to CLK10/5
BU6100_CCLK_1588_PPP	5	CCLK Connected to IEEE1588_PPP
BU6100_CCLK_LXI_TRG_0	8	CCLK Connected to LXI Trig 0
BU6100_CCLK_LXI_TRG_1	9	CCLK Connected to LXI Trig 1
BU6100_CCLK_LXI_TRG_2	10	CCLK Connected to LXI Trig 2
BU6100_CCLK_LXI_TRG_3	11	CCLK Connected to LXI Trig 3
BU6100_CCLK_LXI_TRG_4	12	CCLK Connected to LXI Trig 4
BU6100_CCLK_LXI_TRG_5	13	CCLK Connected to LXI Trig 5
BU6100_CCLK_LXI_TRG_6	14	CCLK Connected to LXI Trig 6
BU6100_CCLK_LXI_TRG_7	15	CCLK Connected to LXI Trig 7

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
-----	-----
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types	

3FFA0000 to 3FFA1FFF	IVI	Warnings
3FFF0000 to 3FFFFFFF	VISA	Warnings
3FFC0000 to 3FFCFFFF	VXIPnP	Driver Warnings
BFFA0000 to BFFA1FFF	IVI	Errors
BFFF0000 to BFFFFFFF	VISA	Errors
BFFC0000 to BFFCFFFF	VXIPnP	Driver Errors

5.5.115. bu6100_setVoltRefOutput

```
ViStatus bu6100_setVoltRefOutput (ViSession instrumentHandle,
                                  ViReal64 voltage);
```

Purpose

Sets the Voltage Reference module output voltage.

Parameter List

instrumentHandle

Variable Type ViSession

The Instrument Handle is used to identify the unique session or communication channel between the driver and the instrument.

If more than one instrument of the same model type is used, this Handle will be used to differentiate between them.

voltage

Variable Type ViReal64

Specifies the output voltage of the Voltage Reference module. The available set of voltages depends on the type of Voltage Reference module fitted to motherboard. If module is not able generate requested message, the function will return error status.

Default Value: 9.0 Volt

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.116. bu6100_startList

```
ViStatus bu6100_startList (ViSession instrumentHandle,
                          ViInt16 functionCard, ViInt16 n_ofVriables,
                          ViInt32 _VI_FAR variables[]);
```

Purpose

Starts the execution of specified List on the DSP. The List must be loaded into DSP memory by using bu6100_loadList() function prior to function call. If The List uses the Circular Buffer, it should be configured prior this function call with bu6100_setConfigCB() function.

Parameter List

instrumentHandle

Variable Type ViSession

The Instrument Handle is used to identify the unique session or communication channel between the driver and the instrument.

If more than one instrument of the same model type is used, this Handle will be used to differentiate between them.

functionCard

Variable Type ViInt16

Specifies the Function Card for which the List will be started.

Valid Values: 1, 2, 3, 4

Default Value: 1

n_ofVriables

Variable Type ViInt16

Number of arguments to be passed to the starting List.

Default Value: 0

variables

Variable Type ViInt32[]

This array contains the arguments for the starting List.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different

include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.117. bu6100_synchronizeListVars

```
ViStatus bu6100_synchronizeListVars (ViSession instrumentHandle,
                                     ViInt16 functionCard,
                                     ViInt32 space, ViInt32 nVarsRead,
                                     ViInt32 startIndexRead,
                                     ViInt32 _VI_FAR readBuffer[],
                                     ViInt32 nVarsWrite,
                                     ViInt32 startIndexWrite,
                                     ViInt32 _VI_FAR writeBuffer[]);
```

Purpose

Retrieves and sends data for the currently running List. This function first reads current values of List data and then sets the new values. It is performed in synchronous way, i.e. List execution will be suspended between reading data and setting of new values.

Parameter List

instrumentHandle

Variable Type ViSession

The Instrument Handle is used to identify the unique session or communication channel between the driver and the instrument.

If more than one instrument of the same model type is used, this Handle will be used to differentiate between them.

functionCard

Variable Type ViInt16

Specifies the Function Card for which the List data will be exchanged.

Valid Values: 1, 2, 3, 4

Default Value: 1

space

Variable Type ViInt32

Specifies whether local or global variables will be synchronized.

Valid Values:

```
BU6100_LIST_SPACE_LOCAL 0
BU6100_LIST_SPACE_GLOBAL 1
```

Default Value: 0 (BU6100_LIST_SPACE_LOCAL)

nVarsRead

Variable Type ViInt32

Number of variables to retrieve.

Default Value: 0

startIndexRead

Variable Type ViInt32

Start Index of variables to be retrieved.

Default Value: 0

readBuffer

Variable Type ViInt32[]

This array will contain data retrieved form the List.

nVarsWrite

Variable Type ViInt32

Number of variables to set.

Default Value: 0

startIndexWrite

Variable Type ViInt32

Start Index of variables to set.

Default Value: 0

writeBuffer

Variable Type ViInt32[]

This array should contain the values of variables to set.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.118. bu6100_UnlockSession

```
ViStatus bu6100_UnlockSession (ViSession instrumentHandle,
                              ViPBoolean callerHasLock);
```

Purpose

This function releases a lock that you acquired on an instrument session using `bu6100_LockSession`. Refer to `bu6100_LockSession` for additional information on session locks.

Parameter List

instrumentHandle

Variable Type ViSession

The ViSession handle that you obtain from the `bu6100_init` or `bu6100_InitWithOptions` function. The handle identifies a particular instrument session.

Default Value: None

callerHasLock

Variable Type ViBoolean (passed by reference)

This parameter serves as a convenience. If you do not want to use this parameter, pass `VI_NULL`.

Use this parameter in complex functions to keep track of whether you obtain a lock and therefore need to unlock the session.

Pass the address of a local ViBoolean variable. In the declaration of the local variable, initialize it to `VI_FALSE`. Pass the address of the same local variable to any other calls you make to `bu6100_LockSession` or `bu6100_UnlockSession` in the same function.

The parameter is an input/output parameter. `bu6100_LockSession` and `bu6100_UnlockSession` each inspect the current value and take the following actions:

- If the value is `VI_TRUE`, `bu6100_LockSession` does not lock the session again. If the value is `VI_FALSE`, `bu6100_LockSession` obtains the lock and sets the value of the parameter to `VI_TRUE`.
- If the value is `VI_FALSE`, `bu6100_UnlockSession` does not attempt to unlock the session. If the value is `VI_TRUE`, `bu6100_UnlockSession` releases the lock and sets the value of the parameter to `VI_FALSE`.

Thus, you can, call `bu6100_UnlockSession` at the end of your function without worrying about whether you actually have the lock.

Example:

```
ViStatus TestFunc (ViSession vi, ViInt32 flags)
{
    ViStatus error = VI_SUCCESS;
    ViBoolean haveLock = VI_FALSE;

    if (flags & BIT_1)
    {
        viCheckErr( bu6100_LockSession(vi, &haveLock));
        viCheckErr( TakeAction1(vi));
        if (flags & BIT_2)
        {
            viCheckErr( bu6100_UnlockSession(vi, &haveLock));
            viCheckErr( TakeAction2(vi));
            viCheckErr( bu6100_LockSession(vi, &haveLock));
        }
    }
    if (flags & BIT_3)
        viCheckErr( TakeAction3(vi));
}
```

```
Error:
  /*
   * At this point, you cannot really be sure that
   * you have the lock. Fortunately, the haveLock
   * variable takes care of that for you.
   */
  bu6100_UnlockSession(vi, &haveLock);
  return error;
}
```

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.119. bu6100_waitIrqWatcher

```
ViStatus bu6100_waitIrqWatcher (ViSession instrumentHandle,
                               ViInt16 source,
                               ViInt32 timeoutValue_msec);
```

Purpose

Waits for the Interrupt watched by the given IRQ Watcher specified number of milliseconds. Before use this function the IRQ Watcher has to be created using bu6100_installIrqWatcher() function.

Parameter List

instrumentHandle

Variable Type ViSession

The Instrument Handle is used to identify the unique session or communication channel between the driver and the instrument.

If more than one instrument of the same model type is used, this Handle will be used to differentiate between them.

source

Variable Type ViInt16

The trigger line for which Interrupt Watcher the function will wait.

Valid Values:

BU6100_FCTrigOutA1	0	FC 1 Trigger Output A
BU6100_FCTrigOutA2	1	FC 2 Trigger Output A
BU6100_FCTrigOutA3	2	FC 3 Trigger Output A
BU6100_FCTrigOutA4	3	FC 4 Trigger Output A
BU6100_FCTrigOutB1	8	FC 1 Trigger Output B
BU6100_FCTrigOutB2	9	FC 2 Trigger Output B
BU6100_FCTrigOutB3	10	FC 3 Trigger Output B
BU6100_FCTrigOutB4	11	FC 4 Trigger Output B
BU6100_FCCircBuf1	16	FC 1 Circular Buffer
BU6100_FCCircBuf2	17	FC 2 Circular Buffer
BU6100_FCCircBuf3	18	FC 3 Circular Buffer
BU6100_FCCircBuf4	19	FC 4 Circular Buffer

Default Value: 0 (BU6100_FCTrigOutA1)

timeoutValue_msec

Variable Type ViInt32

Specifies the timeout in milliseconds of the wait operation.

Default Value: 1000 ms

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
-----	-----
0	Success

Positive Values Warnings
Negative Values Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
-----	-----
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.120. bu6100_waitList

```
ViStatus bu6100_waitList (ViSession instrumentHandle,
                        ViInt16 functionCard, ViInt32 timeout_ms);
```

Purpose

Waits until the currently active List is terminated or timeout reached.

Parameter List

instrumentHandle

Variable Type ViSession

The Instrument Handle is used to identify the unique session or communication channel between the driver and the instrument.

If more than one instrument of the same model type is used, this Handle will be used to differentiate between them.

functionCard

Variable Type ViInt16

The function card for which the active list will be waited.

Valid Values: 1, 2, 3, 4

Default Value: 1

timeout_ms

Variable Type ViInt32

Specifies the timeout of the wait operation.

Default Value: 10 ms

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors

BFFC0000 to BFFCFFFF VXIPnP Driver Errors

5.5.121. bu6100_writeCB

```
ViStatus bu6100_writeCB (ViSession instrumentHandle,
                        ViInt16 functionCard, ViInt32 n_ofSamples,
                        ViInt32 _VI_FAR data[]);
```

Purpose

This function writes the specified amount of data to the Circular Buffer for particular Function Card.

Parameter List

instrumentHandle

Variable Type ViSession

The Instrument Handle is used to identify the unique session or communication channel between the driver and the instrument.

If more than one instrument of the same model type is used, this Handle will be used to differentiate between them.

functionCard

Variable Type ViInt16

Specifies the Function Card for which the Circular Buffer will be configured.

Valid Values: 1, 2, 3, 4

Default Value: 1

n_ofSamples

Variable Type ViInt32

This parameter specifies the number of 32-bit words to be written to the Circular Buffer.

data

Variable Type ViInt32[]

This array should contain the data to be written to the Circular Buffer.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIPnP Driver Errors

5.5.122. bu6100_writeDram

```
ViStatus bu6100_writeDram (ViSession instrumentHandle, ViInt32 offset,
                          ViInt32 count, ViInt32 _VI_FAR writeData[]);
```

Purpose

Writes the data to the specified address of DRAM module.

Parameter List

instrumentHandle

Variable Type ViSession

The Instrument Handle is used to identify the unique session or communication channel between the driver and the instrument.

If more than one instrument of the same model type is used, this Handle will be used to differentiate between them.

offset

Variable Type ViInt32

Selects the start address in DRAM module.

Default Value: 0

count

Variable Type ViInt32

Number of elements of data (32-bit words) to write to the DRAM module.

Default Value: 1

writeData

Variable Type ViInt32[]

An array of data to write to the DRAM module.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIPnP Driver Warnings

BFFA0000 to BFFA1FFF	IVI	Errors
BFFF0000 to BFFFFFFF	VISA	Errors
BFFC0000 to BFFCFFFF	VXIIPnP	Driver Errors

5.5.123. bu6100_WriteInstrData

```
ViStatus bu6100_WriteInstrData (ViSession instrumentHandle,
                               ViChar _VI_FAR writeBuffer[]);
```

Purpose

This function writes a user-specified string to the instrument.

Note: This function bypasses IVI attribute state caching. Therefore, when you call this function, the cached values for all attributes will be invalidated.

Parameter List

instrumentHandle

Variable Type ViSession

The ViSession handle that you obtain from the bu6100_init or bu6100_initWithOptions function. The handle identifies a particular instrument session.

Default Value: None

writeBuffer

Variable Type ViChar[]

Pass the string to be written to the instrument.

Return Value

Returns the status code of this operation. The status code either indicates success or describes an error or warning condition. You examine the status code from each call to an instrument driver function to determine if an error occurred.

To obtain a text description of the status code, call the bu6100_error_message function. To obtain additional information about the error condition, call the bu6100_GetError function. To clear the error information from the driver, call the bu6100_ClearError function.

The general meaning of the status code is as follows:

Value	Meaning
0	Success
Positive Values	Warnings
Negative Values	Errors

This instrument driver returns errors and warnings defined by other sources. The following table defines the ranges of additional status codes that this driver can return. The table lists the different include files that contain the defined constants for the particular status codes:

Numeric Range (in Hex)	Status Code Types
3FFA0000 to 3FFA1FFF	IVI Warnings
3FFF0000 to 3FFFFFFF	VISA Warnings
3FFC0000 to 3FFCFFFF	VXIIPnP Driver Warnings
BFFA0000 to BFFA1FFF	IVI Errors
BFFF0000 to BFFFFFFF	VISA Errors
BFFC0000 to BFFCFFFF	VXIIPnP Driver Errors

5.6. IVI-C Driver Attributes

Attribute Information for the Following Functions:

```

bu6100_SetAttributeViInt32
bu6100_GetAttributeViInt32
bu6100_CheckAttributeViInt32
bu6100_SetAttributeViReal64
bu6100_GetAttributeViReal64
bu6100_CheckAttributeViReal64
bu6100_SetAttributeViSession
bu6100_GetAttributeViSession
bu6100_CheckAttributeViSession
bu6100_SetAttributeViBoolean
bu6100_GetAttributeViBoolean
bu6100_CheckAttributeViBoolean
bu6100_SetAttributeViString
bu6100_GetAttributeViString
bu6100_CheckAttributeViString

```

LxiSync Attributes

Arm

```

Arm Count BU6100_ATTR_IVILXISYNC_ARM_COUNT
LxiSync Arm Delay BU6100_ATTR_IVILXISYNC_ARM_DELAY
Alarm
  LxiSync Arm Alarm Count BU6100_ATTR_IVILXISYNC_ARM_ALARM_COUNT
  LxiSync Arm Alarm Enabled BU6100_ATTR_IVILXISYNC_ARM_ALARM_ENABLED
  LxiSync Arm Alarm Period BU6100_ATTR_IVILXISYNC_ARM_ALARM_PERIOD
  LxiSync Arm Alarm Repeat Count BU6100_ATTR_IVILXISYNC_ARM_ALARM_REPEAT_COUNT
  LxiSync Arm Alarm Time Seconds BU6100_ATTR_IVILXISYNC_ARM_ALARM_TIME_SECONDS
  LxiSync Arm Alarm Time Fraction BU6100_ATTR_IVILXISYNC_ARM_ALARM_TIME_FRACTION

```

Source

```

LxiSync Arm Source Count BU6100_ATTR_IVILXISYNC_ARM_SOURCE_COUNT
LxiSync Arm Source Detection BU6100_ATTR_IVILXISYNC_ARM_SOURCE_DETECTION
LxiSync Arm Source Enabled BU6100_ATTR_IVILXISYNC_ARM_SOURCE_ENABLED
LxiSync Arm Source Event ID BU6100_ATTR_IVILXISYNC_ARM_SOURCE_EVENTID
LxiSync Arm Source Filter BU6100_ATTR_IVILXISYNC_ARM_SOURCE_FILTER
LxiSync Arm Source Or Enabled BU6100_ATTR_IVILXISYNC_ARM_SOURCE_OR_ENABLED

```

Trigger

```

LxiSync Trigger Count BU6100_ATTR_IVILXISYNC_TRIGGER_COUNT
LxiSync Trigger Source BU6100_ATTR_IVILXISYNC_TRIGGER_SOURCE
Alarm
  LxiSync Trigger Alarm Count BU6100_ATTR_IVILXISYNC_TRIGGER_ALARM_COUNT
  LxiSync Trigger Alarm Enabled BU6100_ATTR_IVILXISYNC_TRIGGER_ALARM_ENABLED
  LxiSync TRigger Alarm Period BU6100_ATTR_IVILXISYNC_TRIGGER_ALARM_PERIOD
  LxiSync Trigger Alarm Repeat Count BU6100_ATTR_IVILXISYNC_TRIGGER_ALARM_REPEAT_COUNT
  LxiSync Trigger Alarm Time Seconds BU6100_ATTR_IVILXISYNC_TRIGGER_ALARM_TIME_SECONDS
  LxiSync Trigger Alarm Time Fractional BU6100_ATTR_IVILXISYNC_TRIGGER_ALARM_TIME_FRACTION

```

BU6100_ATTR_IVILXISYNC_TRIGGER_ALARM_TIME_FRACTION

Source

```

LxiSync Trigger Source Count BU6100_ATTR_IVILXISYNC_TRIGGER_SOURCE_COUNT
LxiSync Trigger Source Delay BU6100_ATTR_IVILXISYNC_TRIGGER_SOURCE_DELAY
LxiSync Trigger Source Detection BU6100_ATTR_IVILXISYNC_TRIGGER_SOURCE_DETECTION
LxiSync Trigger Source Event ID BU6100_ATTR_IVILXISYNC_TRIGGER_SOURCE_EVENTID
LxiSync Trigger Source Filter BU6100_ATTR_IVILXISYNC_TRIGGER_SOURCE_FILTER

```

Event

```

LxiSync Event Count BU6100_ATTR_IVILXISYNC_EVENT_COUNT
LxiSync Event Destination Path BU6100_ATTR_IVILXISYNC_EVENT_DESTINATION_PATH
LxiSync Event Drive Mode BU6100_ATTR_IVILXISYNC_EVENT_DRIVE_MODE
LxiSync Event Slope BU6100_ATTR_IVILXISYNC_EVENT_SLOPE
LxiSync Event Source BU6100_ATTR_IVILXISYNC_EVENT_SOURCE
LxiSync Event Wired OR Bias Mode BU6100_ATTR_IVILXISYNC_EVENT_WIRED_OR_BIAS_MODE

```

Event Log

```

LxiSync Event Log Entry Count BU6100_ATTR_IVILXISYNC_EVENT_LOG_ENTRY_COUNT
LxiSync Event Log Enabled BU6100_ATTR_IVILXISYNC_EVENT_LOG_ENABLED

```

Time

```

LxiSync Is Time Master BU6100_ATTR_IVILXISYNC_IS_TIME_MASTER
LxiSync Is Time Synchronized BU6100_ATTR_IVILXISYNC_IS_TIME_SYNCHRONIZED

```

Inherent IVI Attributes

User Options

```

Range Check BU6100_ATTR_RANGE_CHECK
Query Instrument Status BU6100_ATTR_QUERY_INSTRUMENT_STATUS
Cache BU6100_ATTR_CACHE
Simulate BU6100_ATTR_SIMULATE

```

Record Value Coercions	BU6100_ATTR_RECORD_COERCIONS
Interchange Check	BU6100_ATTR_INTERCHANGE_CHECK
Driver Identification	
Description	BU6100_ATTR_SPECIFIC_DRIVER_DESCRIPTION
Driver Prefix	BU6100_ATTR_SPECIFIC_DRIVER_PREFIX
Driver Vendor	BU6100_ATTR_SPECIFIC_DRIVER_VENDOR
Revision	BU6100_ATTR_SPECIFIC_DRIVER_REVISION
Class Specification Major Version	BU6100_ATTR_SPECIFIC_DRIVER_CLASS_SPEC_MAJOR_VERSION
Class Specification Minor Version	BU6100_ATTR_SPECIFIC_DRIVER_CLASS_SPEC_MINOR_VERSION
Driver Capabilities	
Supported Instrument Models	BU6100_ATTR_SUPPORTED_INSTRUMENT_MODELS
Class Group Capabilities	BU6100_ATTR_GROUP_CAPABILITIES
Instrument Identification	
Manufacturer	BU6100_ATTR_INSTRUMENT_MANUFACTURER
Model	BU6100_ATTR_INSTRUMENT_MODEL
Firmware Revision	BU6100_ATTR_INSTRUMENT_FIRMWARE_REVISION
Advanced Session Information	
Logical Name	BU6100_ATTR_LOGICAL_NAME
I/O Resource Descriptor	BU6100_ATTR_IO_RESOURCE_DESCRIPTOR
Driver Setup	BU6100_ATTR_DRIVER_SETUP
Miscellaneous Attributes	
ID Query Response	BU6100_ATTR_ID_QUERY_RESPONSE

BU6100_ATTR_CACHE

Data Type: ViBoolean

Description: Specifies whether to cache the value of attributes. When caching is enabled, the instrument driver keeps track of the current instrument settings and avoids sending redundant commands to the instrument. Thus, you can significantly increase execution speed.

The instrument driver can choose always to cache or never to cache particular attributes regardless of the setting of this attribute.

The default value is VI_TRUE. Use the bu6100_InitWithOptions function to override this value.

BU6100_ATTR_DRIVER_SETUP

Data Type: ViString

Restrictions: Not settable.

Description: Some cases exist where you must specify instrument driver options at initialization time. An example of this is specifying a particular instrument model from among a family of instruments that the driver supports. This is useful when using simulation. You can specify driver-specific options through the DriverSetup keyword in the optionsString parameter to the bu6100_InitWithOptions function. If you open an instrument using a logical name, you can also specify the options through the IVI Configuration Utility.

The default value is an empty string.

BU6100_ATTR_GROUP_CAPABILITIES

Data Type: ViString

Restrictions: Not settable.

Description: A string that contains a comma-separated list of class-extension groups that this driver implements.

BU6100_ATTR_ID_QUERY_RESPONSE

Data Type: ViString

Restrictions: Not settable.

Description: Returns the ID Query response string. The instrument driver gets the value of this attribute when you pass VI_TRUE for the ID Query parameter to the bu6100_init or bu6100_InitWithOptions function.

BU6100_ATTR_INSTRUMENT_FIRMWARE_REVISION

Data Type: ViString

Restrictions: Not settable.

Description: A string that contains the firmware revision information for the instrument you are currently using.

BU6100_ATTR_INSTRUMENT_MANUFACTURER

Data Type: ViString

Restrictions: Not settable.

Description: A string that contains the name of the instrument manufacturer you are currently using.

BU6100_ATTR_INSTRUMENT_MODEL

Data Type: ViString

Restrictions: Not settable.

Description: A string that contains the model number or name of the instrument that you are currently using.

BU6100_ATTR_INTERCHANGE_CHECK

Data Type: ViBoolean

Description: Specifies whether to perform interchangeability checking and retrieve interchangeability warnings.

The default value is VI_FALSE.

Interchangeability warnings indicate that using your application with a different instrument might cause different behavior. You call bu6100 Get Next Interchange Warning to extract interchange warnings. Call the bu6100_ClearInterchangeWarnings function to clear the list of interchangeability warnings without reading them. Interchangeability checking logs a warning for each attribute you have not set that affects the behavior of the instrument.

BU6100_ATTR_IO_RESOURCE_DESCRIPTOR

Data Type: ViString

Restrictions: Not settable.

Description: Indicates the resource descriptor the driver uses to identify the physical device.

If you initialize the driver with a logical name, this attribute contains the resource descriptor that corresponds to the entry in the IVI Configuration utility.

If you initialize the instrument driver with the resource descriptor, this attribute contains that value.

BU6100_ATTR_IVILXISYNC_ARM_ALARM_COUNT

Data Type: ViInt32

Description: Returns the number of arm alarms created with Arm Add Alarm

BU6100_ATTR_IVILXISYNC_ARM_ALARM_ENABLED

Data Type: ViBoolean

Description: Enables or disables the arm alarm.

BU6100_ATTR_IVILXISYNC_ARM_ALARM_PERIOD

Data Type: ViReal64

Description: Specifies the period of the arm alarm in seconds; that is, the amount of time in seconds that transpire before the alarm repeats. A period of zero means there is no repeat and a single alarm generated.

BU6100_ATTR_IVILXISYNC_ARM_ALARM_REPEAT_COUNT

Data Type: ViInt32

Description: Specifies the number of times the trigger will occur at the period specified by the Arm Alarm Period attribute. If Arm Alarm Repeat Counter is zero, then the alarm shall repeat forever at the Arm Alarm Period.

BU6100_ATTR_IVILXISYNC_ARM_ALARM_TIME_FRACTION

Data Type: ViReal64

Description: Specifies the fractional portion of time at which the alarm will go off. Note that the actual time of the alarm is the sum of Arm Alarm Time Seconds and Arm Alarm Time Fraction. The time is specified as the sum of two values because a single double-precision floating-point number does not have sufficient range and resolution to specify the time.

Once the alarm goes off, it will repeat at the period set by Arm Alarm Period the number of times set by Arm Alarm Count.

BU6100_ATTR_IVILXISYNC_ARM_ALARM_TIME_SECONDS

Data Type: ViReal64

Description: Specifies the seconds portion of time at which the alarm will go off. Note that the actual time of the alarm is the sum of Arm Alarm Time Seconds and Arm Alarm Time Fraction. The time is specified as the sum of two

values because a single double-precision floating-point number does not have sufficient range and resolution to specify the time. Once the alarm goes off, it will repeat at the period set by Arm Alarm Period the number of times set by Arm Alarm Count.

BU6100_ATTR_IVILXISYNC_ARM_COUNT

Data Type: ViInt32

Description: Specifies the number of times the arm has to occur to complete the arm loop; that is, the number of arms that are accepted before the measurement must be initiated again.

BU6100_ATTR_IVILXISYNC_ARM_DELAY

Data Type: ViReal64

Description: Specifies the delay from when the arm logic satisfied until the waiting for the trigger state is entered. The units are seconds

BU6100_ATTR_IVILXISYNC_ARM_SOURCE_COUNT

Data Type: ViInt32

Restrictions: Not settable.

Description: Returns the number of currently available arm sources.

BU6100_ATTR_IVILXISYNC_ARM_SOURCE_DETECTION

Data Type: ViInt32

Description: Specifies the style of arm source detection.

If the source is a LAN event and the source detection is set to rise, this Arm repeated capability will be satisfied when the designated LAN packet arrives with a True indication. If the source detection is set to fall, this Arm repeated capability will be satisfied when a LAN packet arrives with a False indication. If the detection is set to high, the source will be satisfied when the designated LAN packet arrives with a True indication and remain satisfied until the designated LAN packet arrives with a False indication. If the detection is to low, the source will be satisfied when the designated LAN packet arrives with a False indication and remain satisfied until the designated LAN packet arrives with a True indication.

Defined values:

bu6100_VAL_IVILXISYNC_DETECTION_RISE - Configures the LXI device to arm on the rising edge of the arm source.

bu6100_VAL_IVILXISYNC_DETECTION_FALL - Configures the LXI device to arm on the falling edge of the arm source.

bu6100_VAL_IVILXISYNC_DETECTION_HIGH - Configures the LXI device to arm while the arm source is high, that is, while it remains true

bu6100_VAL_IVILXISYNC_DETECTION_LOW - Configures the LXI device to arm while the arm source is low, that is, while it remains low

BU6100_ATTR_IVILXISYNC_ARM_SOURCE_ENABLED

Data Type: ViBoolean

Description: Enables or disables the arm source. If a source is disabled, it has no affect on the summary arm signal.

BU6100_ATTR_IVILXISYNC_ARM_SOURCE_EVENTID

Data Type: ViString

Description: This specifies the LAN event identifier that is associated with this arm source. LAN Events with this identifier are accepted from the source described in the filter.

The default value for EventId is the repeated capability specifier for this arm source.

BU6100_ATTR_IVILXISYNC_ARM_SOURCE_FILTER

Data Type: ViString

Description: Specifies a filter for restricting arm sources. The filter specified by this attribute denotes the accepted sources. The syntax for specifying a filter is as follows:

```
<Filter> == [( <tcp> | <udp> | <any> ) [, <Filter> ]]
```

```
<tcp> == <host> [:<port>]
```

```
<udp> == ALL [:<port>]
```

```
<any> == :<port>
```

<host> is either a hostname or host number. Note that the hostname can not be "ALL" since that would indicate the <udp> construct.

<port> is a series of decimal digits indicating the port number.

Specifying an empty string or VI_NULL means that LXI arm packets are accepted

via either TCP or UDP multicast from any host. Note that ":5044" is equivalent to the empty string since 5044 is the IANA registered port for LXI events (lxi-evntsvc).

In the <tcp>, <udp> and <any> constructs, <port> refers to the port the device receives the LAN message on. If <port> is omitted from <tcp> or <udp>, packets are only accepted on the IANA registered port for LXI events (lxi-evntsvc).

Specifying the <host> (<tcp> construct) indicates that packets via TCP on the port indicated are accepted.

Specifying ALL (<udp> construct) indicates that UDP multicast packets are accepted if they are directed to the IANA registered port for LXI events (lxi-evntsvc) on the IANA registered multicast address (LXI-EVENT). No TCP packets are accepted unless a <tcp> syntax is also included in the filter. The multicast address can not be altered with this syntax.

Specifying any protocol (<any> construct) indicates that both packets via TCP and UDP multicast packets are accepted if they are directed to the specified port. UDP multicast packets must be received at the IANA registered multicast address (LXI-EVENT).

The send port is not monitored. This allows the transmitter to use any available port.

Drivers (and the corresponding instruments) that support this syntax are permitted to not support all possible filters syntaxes.

White space shall be ignored. The <Filter> string is case insensitive.

Conventional devices should consider restricting the <port> to only the IANA registered port for LXI events (lxi-evntsvc) and not accepting the generalized syntax.

BU6100_ATTR_IVILXISYNC_ARM_SOURCE_OR_ENABLED

Data Type: ViBoolean

Description: Enables or disables the OR-summing of the arm sources. When set to True, the arm sources use OR-summing. When set to False, the arm sources use AND-summing.

BU6100_ATTR_IVILXISYNC_EVENT_COUNT

Data Type: ViInt32

Restrictions: Not settable.

Description: Returns the number of defined events. The count returned includes any of the supported reserved repeated capability names defined in Reserved Repeated Capability Identifiers as well as any custom repeated capability identifiers.

BU6100_ATTR_IVILXISYNC_EVENT_DESTINATION_PATH

Data Type: ViString

Description: Specifies a list of places to send the event.

The default value for this attribute is the repeated capability name.

The grammar for the parameter is:

```
<DestinationPath>== [(<tcp>|<udp>|<TriggerBus>)[, <DestinationPath>]]
```

```
<tcp> == <host> [: <port>] [/<LANIdent>]
```

```
<udp> == [ALL] [: <port> ] [/<LANIdent>]
```

```
<TriggerBus> == LXI0|LXI1|LXI2|LXI3|LXI4|LXI5|LXI6|LXI7
```

host is either a hostname or host number, and port is a series of decimal digits indicating the port number. Note that the hostname can not be "ALL" or one of the <TriggerBus> designations since that would indicate the <udp> or <TriggerBus> construct.

<LANIdent> is a string indicating the LAN identifier that will be sent in the LAN message. The <LANIdent> is not case sensitive. <LANIdent> is from one to 16 ASCII characters inclusive. The characters may be numeric or underscore or hyphen or upper or lower-case alphabetic characters.

Defaults:

The default <DestinationPath> is the repeated capability name. This may either be a <TriggerBus> identifier or a <LANIdent> identifier.

<LANIdent> defaults to the repeated capability name.

<port> defaults to the IANA registered port for LXI events (lxi-evntsvc).

If the repeated capability name is not a trigger bus specifier then the default <DestinationPath> is 'ALL' with the <LANIdent> as the repeated capability name.

If the repeated capability name corresponds to a <TriggerBus>, the default <DestinationPath> is the repeated capability name. If multiple <DestinationPath>s are specified, the event is transmitted to each. The <tcp> construct specifies that a TCP message will be sent to the destination when the bound event occurs. The <udp> construct specifies that a UDP multicast message will be sent to the IANA registered multi-cast address (LXI-EVENT) on the designated port. UDP unicast and UDP broadcasts are not supported by this syntax. The <TriggerBus> construct specifies that a physical LXI wired trigger bus is used to signal the event. Note that the LXI specification reserves event identifiers that begin with the characters "LXI" for LXI use. The strings "LXI0", "LXI1", ... , "LXI7" refer to the 8 LXI wired trigger bus triggers. White space shall be ignored. The <Destination> string is case insensitive. Drivers may accept additional vendor-defined syntaxes Drivers (and the corresponding instruments) that support this syntax are permitted to not support all possible destination syntaxes. Conventional devices should consider restricting the port to only the IANA registered port for LXI events (lxi-evntsvc) and not accepting the generalized syntax.

BU6100_ATTR_IVILXISYNC_EVENT_DRIVE_MODE
Data Type: ViInt32
Description: Specifies how this event is transmitted

It is an error to turn on the Wired OR Bias Mode for this device for a particular LXI trigger line and then set the Event Enabled attribute to On instead of Wired OR for an event whose destination path includes that LXI trigger line.

BU6100_ATTR_IVILXISYNC_EVENT_LOG_ENABLED
Data Type: ViBoolean
Description: Enables or disables the event logging feature.

BU6100_ATTR_IVILXISYNC_EVENT_LOG_ENTRY_COUNT
Data Type: ViInt32
Restrictions: Not settable.
Description: Returns the number of event log entries available.

BU6100_ATTR_IVILXISYNC_EVENT_SLOPE
Data Type: ViInt32
Description: Specifies the slope of the event that is inbound to the event subsystem that will cause the generation of an outbound event. The outbound event shall be transmitted with the same slope as the inbound event. Possible values are:
bu6100_VAL_IVILXISYNC_SLOPE_POSITIVE - The event will be transmitted with a rising edge.
bu6100_VAL_IVILXISYNC_SLOPE_NEGATIVE - The event will be transmitted with a falling edge.

BU6100_ATTR_IVILXISYNC_EVENT_SOURCE
Data Type: ViString
Description: Specifies the signal which causes an event to be transmitted. This attribute is case-insensitive but case-preserving.

BU6100_ATTR_IVILXISYNC_EVENT_WIRED_OR_BIAS_MODE
Data Type: ViInt32
Description: Specifies whether this LXI device will serve as the wired-OR bias for specific LXI trigger bus lines. The allowed values for this attribute are 0 to 255. This attribute is a bit field, where bit 0 represents LXI0, bit 1 represents LXI1, and so on. A value of one in a particular bit indicates that the LXI device shall serve as the bias for the corresponding trigger bus line. A value of zero in a particular bit disables the bias for the corresponding trigger bus line. To use a trigger bus line in driven mode, the bias must be disabled. Enabling wired-OR bias has no impact on the device's ability to either respond to signals on trigger bus lines or to send events on trigger bus lines. One and only one LXI device can serve as the wired-OR bias for a particular trigger bus line, although different devices can serve as the wired-OR bias for different trigger bus lines.

BU6100_ATTR_IVILXISYNC_IS_TIME_MASTER

Data Type: ViBoolean

Restrictions: Not settable.

Description: Indicates if this device is the 1588 master.

BU6100_ATTR_IVILXISYNC_IS_TIME_SYNCHRONIZED

Data Type: ViBoolean

Restrictions: Not settable.

Description: Indicates if the device is synchronized.

BU6100_ATTR_IVILXISYNC_TRIGGER_ALARM_COUNT

Data Type: ViInt32

Restrictions: Not settable.

Description: Returns the number of currently available trigger alarms. The count returned includes the reserved repeated capability named "ALARM0" as well as any custom repeated capability identifiers.

BU6100_ATTR_IVILXISYNC_TRIGGER_ALARM_ENABLED

Data Type: ViBoolean

Description: Enables or disables the trigger alarm.

BU6100_ATTR_IVILXISYNC_TRIGGER_ALARM_PERIOD

Data Type: ViReal64

Description: Specifies the period of the trigger alarm in seconds; that is, the amount of time in seconds that transpire before the alarm repeats. A period of zero means there is no repeat and a single trigger is generated.

BU6100_ATTR_IVILXISYNC_TRIGGER_ALARM_REPEAT_COUNT

Data Type: ViInt32

Description: Specifies the number of times the trigger will occur at the period specified by the Trigger Alarm Period attribute. If Trigger Alarm Repeat Period is non-zero and Trigger Alarm Repeat Count is zero, then the alarm shall repeat forever at the Trigger Alarm Period.

bu6100_VAL_IVILXISYNC_REPEAT_CONTINUOUS is provided to set the repeat count to forever.

BU6100_ATTR_IVILXISYNC_TRIGGER_ALARM_TIME_FRACTION

Data Type: ViReal64

Description: Specifies the fractional seconds portion of the time at which the alarm will go off. Note that the actual time of the alarm is the sum of Trigger Alarm Time Seconds and Trigger Alarm Time Fraction. The time is specified as the sum of two values because a single double-precision floating-point does not have sufficient range and resolution to specify the time.

Once the alarm goes off, it will repeat at the period set by Trigger Alarm Period the number of times set by Trigger Alarm Count.

BU6100_ATTR_IVILXISYNC_TRIGGER_ALARM_TIME_SECONDS

Data Type: ViReal64

Description: Specifies the seconds portion of the time at which the alarm will go off. Note that the actual time of the alarm is the sum of Trigger Alarm Time Seconds and Trigger Alarm Time Fraction. The time is specified as the sum of two values because a single double-precision floating-point does not have sufficient range and resolution to specify the time.

Once the alarm goes off, it will repeat at the period set by Trigger Alarm Period the number of times set by Trigger Alarm Count.

BU6100_ATTR_IVILXISYNC_TRIGGER_COUNT

Data Type: ViInt32

Description: Specifies the number of times a trigger has to occur to complete a measurement; that is, the number of triggers that are accepted before the measurement must be armed again.

BU6100_ATTR_IVILXISYNC_TRIGGER_SOURCE

Data Type: ViString

Description: Specifies which of the available trigger sources to use as the signal for triggering the device-specific operation (for example, a measurement).

The value specified for this attribute may be one of the names in the IviLxiSyncTriggerSource repeated capability collection as returned from the GetTriggerSourceName function.

The value specified for this attribute may also be one of the names in the IviLxiSyncTriggerAlarm repeated capability collection as returned from the GetTriggerAlarmName function.

The name specified here may also correspond to a non-LXI trigger event. For instance, the caller can use this attribute to program the trigger source to external or immediate triggering, by specifying values such as "EXT" or "INT". Such trigger source names are device-dependent.

If the device trigger source has been programmed to a non-LXI event using an attribute or function other than the Trigger Source attribute, then this attribute shall return that value when read. For instance, if the specific driver implements an IVI instrument class and the class-compliant API is used to set the trigger source to external, then this property shall return a string that reflects the value set through the class-compliant API.

This attribute is case-insensitive but case-preserving. For more information on this requirement,

BU6100_ATTR_IVILXISYNC_TRIGGER_SOURCE_COUNT

Data Type: ViInt32

Restrictions: Not settable.

Description: Returns the number of currently available trigger sources. The count returned includes any of the supported reserved repeated capability names defined in Section 2.1.6, Reserved Repeated Capability Identifiers as well as any custom repeated capability identifiers.

BU6100_ATTR_IVILXISYNC_TRIGGER_SOURCE_DELAY

Data Type: ViReal64

Description: Specifies the trigger source delay from when the trigger logic is satisfied until the device specific action (for instance a measurement) is triggered. A negative value implies pre-trigger acquisition. The units are seconds.

BU6100_ATTR_IVILXISYNC_TRIGGER_SOURCE_DETECTION

Data Type: ViInt32

Description: Specifies the slope of the trigger source.

If the source is a LAN event and the source slope is set to positive, this Trigger repeated capability will be satisfied when the designated LAN packet arrives with a true indication. If the source slope is set to negative, this Trigger repeated capability will be satisfied when a LAN packet arrives with a false indication.

Possible values are:

bu6100_VAL_IVILXISYNC_DETECTION_RISE - Configures the LXI device to trigger on the rising edge of the trigger source.

bu6100_VAL_IVILXISYNC_DETECTION_FALL - Configures the LXI device to trigger on the falling edge of the trigger source.

BU6100_ATTR_IVILXISYNC_TRIGGER_SOURCE_EVENTID

Data Type: ViString

Description: This specifies the LAN event identifier that is associated with this trigger source. LAN Events with this identifier are accepted from the source described in the filter.

The default value for EventId is the repeated capability specifier for this trigger source.

BU6100_ATTR_IVILXISYNC_TRIGGER_SOURCE_FILTER

Data Type: ViString

Description: Specifies a filter for restricting trigger sources. The filter specified by this attribute denotes the accepted sources. The syntax for specifying a filter is as follows:

```
<Filter> == [( <tcp> | <udp> | <any> ) [, <Filter> ]]
```

```
<tcp> == <host> [:<port>]
```

```
<udp> == ALL [:<port>]
```

```
<any> == : <port>
```

<host> is either a hostname or host number. Note that the hostname can not be

"ALL" since that would indicate the <udp> construct. <port> is a series of decimal digits indicating the port number. Specifying an empty string or VI_NULL means that LXI trigger packets are accepted via either TCP or UDP multicast from any host. ":5044" is equivalent to the empty string since 5044 is the IANA registered port for LXI events (lxi-evntsvc).

In the <tcp>, <udp> and <any> constructs, <port> refers to the port the device receives the LAN message on. If <port> is omitted from <tcp> or <udp>, packets are only accepted on the IANA registered port for LXI events (lxi-evntsvc).

Specifying the <host> (<tcp> construct) indicates that packets via TCP on the port indicated are accepted.

Specifying ALL (<udp> construct) indicates that UDP multicast packets are accepted if they are directed to the IANA registered port for LXI events (lxi-evntsvc) on the IANA registered multicast address (LXI-EVENT). No TCP packets are accepted unless a <tcp> syntax is also included in the filter. The multicast address can not be altered with this syntax.

Specifying any protocol (<any> construct) indicates that both TCP and UDP multicast packets are accepted if they are directed to the specified port. UDP multicast packets must be received at the IANA registered multicast address (LXI-EVENT).

The send port is not monitored. This allows the transmitter to use any available port.

Drivers (and the corresponding instruments) that support this syntax are permitted to not support all possible filters syntaxes. White space shall be ignored. The <Filter> string is case insensitive. Conventional devices should consider restricting the <port> to only the IANA registered port for LXI events (lxi-eventsvc) and not accepting the generalized syntax.

BU6100_ATTR_LOGICAL_NAME

Data Type: ViString

Restrictions: Not settable.

Description: A string containing the logical name you specified when opening the current IVI session.

You may pass a logical name to the bu6100_init or bu6100_InitWithOptions functions. The IVI Configuration utility must contain an entry for the logical name. The logical name entry refers to a virtual instrument section in the IVI Configuration file. The virtual instrument section specifies a physical device and initial user options.

BU6100_ATTR_QUERY_INSTRUMENT_STATUS

Data Type: ViBoolean

Description: Specifies whether the instrument driver queries the instrument status after each operation. Querying the instrument status is very useful for debugging. After you validate your program, you can set this attribute to VI_FALSE to disable status checking and maximize performance.

The instrument driver can choose to ignore status checking for particular attributes regardless of the setting of this attribute.

The default value is VI_FALSE. Use the bu6100_InitWithOptions function to override this value.

BU6100_ATTR_RANGE_CHECK

Data Type: ViBoolean

Description: Specifies whether to validate attribute values and function parameters. If enabled, the instrument driver validates the parameter values that you pass to driver functions. Range checking parameters is very useful for debugging. After you validate your program, you can set this attribute to VI_FALSE to disable range checking and maximize performance.

The default value is VI_TRUE. Use the bu6100_InitWithOptions function to override this value.

BU6100_ATTR_RECORD_COERCIONS

Data Type: ViBoolean

Description: Specifies whether the IVI engine keeps a list of the value coercions it makes for integer and real type attributes. You call bu6100_GetNextCoercionRecord to extract and delete the oldest coercion record from the

list.

The default value is VI_FALSE. Use the bu6100_InitWithOptions function to override this value.

BU6100_ATTR_SIMULATE

Data Type: ViBoolean

Description: Specifies whether or not to simulate instrument driver I/O operations. If simulation is enabled, instrument driver functions perform range checking and call Ivi_GetAttribute and Ivi_SetAttribute functions, but they do not perform instrument I/O. For output parameters that represent instrument data, the instrument driver functions return calculated values.

The default value is VI_FALSE. Use the bu6100_InitWithOptions function to override this value.

BU6100_ATTR_SPECIFIC_DRIVER_CLASS_SPEC_MAJOR_VERSION

Data Type: ViInt32

Restrictions: Not settable.

Description: The major version number of the class specification with which this driver is compliant.

BU6100_ATTR_SPECIFIC_DRIVER_CLASS_SPEC_MINOR_VERSION

Data Type: ViInt32

Restrictions: Not settable.

Description: The minor version number of the class specification with which this driver is compliant.

BU6100_ATTR_SPECIFIC_DRIVER_DESCRIPTION

Data Type: ViString

Restrictions: Not settable.

Description: A string that contains a brief description of the specific driver.

BU6100_ATTR_SPECIFIC_DRIVER_PREFIX

Data Type: ViString

Restrictions: Not settable.

Description: A string that contains the prefix for the instrument driver. The name of each user-callable function in this driver starts with this prefix.

BU6100_ATTR_SPECIFIC_DRIVER_REVISION

Data Type: ViString

Restrictions: Not settable.

Description: A string that contains additional version information about this instrument driver.

BU6100_ATTR_SPECIFIC_DRIVER_VENDOR

Data Type: ViString

Restrictions: Not settable.

Description: A string that contains the name of the vendor that supplies this driver.

(This page was intentionally left blank.)

